



# **GASBOY**

---

**SERIES 1000**

**FUEL MANAGEMENT SYSTEM**

**START-UP MANUAL**

**C08921**

---

**GASBOY INTERNATIONAL LLC**

**GASBOY**  
**SERIES 1000**  
**FUEL MANAGEMENT SYSTEM**  
**START-UP MANUAL**

**C08921**

Rev. 03/07/03

**GASBOY INTERNATIONAL LLC**  
LANSDALE, PA

Copyright 2003 by Gasboy International LLC  
All rights reserved

The information in this document is confidential and proprietary. No further disclosure shall be made without permission from Gasboy International LLC.

Gasboy International LLC believes that the information in this document is accurate and reliable. However, we assume no responsibility for its use, nor for any infringements of patents or other rights of third parties resulting from its use. We reserve the right to make changes at any time without notice.

---

# CONTENTS

---

<b>Section 1:</b>	<b>STARTING A SERIES 1000 SYSTEM</b>	
	Introduction.....	1-1
	Start-Up Overview.....	1-2
	What You Need For Testing.....	1-2
	Filling Out the Start-up Form.....	1-2
	Using This Book.....	1-3
<b>Section 2:</b>	<b>SITE INFORMATION.....</b>	<b>2-1</b>
<b>Section 3:</b>	<b>BEGIN START-UP FORM</b>	
	Parts 1 Through 4.....	3-1
<b>Section 4:</b>	<b>SYSTEM LAYOUT.....</b>	<b>4-1</b>
<b>Section 5:</b>	<b>JUMPERS AND SWITCH SETTINGS.....</b>	<b>5-1</b>
	Series 1000 Jumpers.....	5-1
	Auxiliary Communications Port PCB Assembly.....	5-6
	Veeder-Root TLS-250 Tank Monitor Switch Settings.....	5-6
	Veeder-Root TLS-350 Tank Monitor Switch Settings.....	5-7
	Fuel Point Reader Port and Baud Rate Jumpers.....	5-7
	Gasboy Fuel Point Reader Switch Settings.....	5-8
	Link MC5 Terminal Setup.....	5-9
	Okidata 184 Printer Setup.....	5-11
<b>Section 6:</b>	<b>PUMP/DISPENSER MANUAL TEST.....</b>	<b>6-1</b>
<b>Section 7:</b>	<b>SYSTEM POWER.....</b>	<b>7-1</b>
<b>Section 8:</b>	<b>DC POWER.....</b>	<b>8-1</b>
	Series 1000.....	8-1
	Fuel Point Reader.....	8-2
<b>Section 9:</b>	<b>COMMUNICATIONS TESTS.....</b>	<b>9-1</b>
<b>Section 10:</b>	<b>PUMP/DISPENSER AUTOMATIC TEST.....</b>	<b>10-1</b>
<b>Section 11:</b>	<b>START-UP COMMANDS.....</b>	<b>11-1</b>
<b>Section 12:</b>	<b>CUSTOMER TRAINING.....</b>	<b>12-1</b>
<b>Section 13:</b>	<b>FINISH START-UP.....</b>	<b>13-1</b>

**SAMPLE START-UP FORM**

**WARRANTY**



---

# STARTING A SERIES 1000 SYSTEM

---

## INTRODUCTION

This *Start-Up Manual* is provided to assist you in the start-up of a GASBOY Series 1000 System. As the start-up person, you should already be familiar with all of the Series 1000 manuals. Proper installation is critical to ensure correct and trouble-free operation. The Series 1000 includes a one-year parts warranty against defective material and/or workmanship. See the **Warranty** page at the back of this book for details.

**NOTE:** *Noncompliance with the specifications of the Series 1000 Installation Manual and the checks in the accompanying Start-Up Form could void the warranty.*

As you are performing the start-up process, any deviations from the specifications listed in the *Installation Manual* should be corrected. If any tests fail, correct the wiring or system problem and perform the test again. If you have any questions, cannot proceed to the next step, or you want authorization for exceptions, please contact GASBOY Customer Service at:

 1-800-444-5529

In addition to this manual, the customer should have the following GASBOY Series 1000 Fuel Management System manuals.

- *Installation Manual, C08922*  
Contains instructions, restrictions and guidelines for planning, laying out, and wiring the Series 1000 System.
- *Card Encoding Manual, C08924 (Card Systems Only)*  
Describes the process of card encoding, including card layout, field descriptions, and filling out the card encoding form.
- *Operation Manual, C08923 (Card Systems Only)*  
or  
*Cardless Operation Manual, C08926*  
or  
*FleetKey Operation Manual, C08379*  
Contains detailed descriptions of system features, data terminal commands, transaction processing and additional system options.
- *Diagnostic Manual, C08925*  
Contains descriptions of system components, diagnostic tests, troubleshooting procedures, and replacement parts listings.

Customers having the Fuel Point option should also have the following manuals:

- *Fuel Point Reader Installation Manual, C35628*
- *Fuel Point Dispenser and Hose Retrofit Manual, C35593*
- *Fuel Point Vehicle Module Installation Manual, C35699*
- *Fuel Point Vehicle Module Programming Manual, C35629*

## START-UP OVERVIEW

Start-up for the Series 1000 System consists of:

- verifying the system layout
- making sure the system complies with the guidelines and restrictions outlined in the system *Installation Guide* and this manual.
- testing the system
- helping the system user execute the commands needed to start the system
- making sure the customer understands how the system works
- filling out the GASBOY Series 1000 Start-up Form, 55F065

## WHAT YOU NEED FOR TESTING

To perform the testing portion of start-up, you will need:

- a digital voltmeter
- a 1/4 inch flat blade screwdriver
- a Phillips head #1 screwdriver
- a Phillips head #2 screwdriver
- a plastic 1/8 inch or smaller flat blade screwdriver
- a tape measure

We recommend that you bring all your tools and spare parts when doing a start-up.

## FILLING OUT THE START-UP FORM

A sample filled-out Start-Up form appears at the end of this manual. You should already have blank copies of the Start-up form; however, if you do not, you can obtain more by calling GASBOY Office Services Department. Throughout the procedures in this manual, you will find double-outlined boxes preceded by this symbol . This writing hand symbol tells you to "fill in" the start-up information for the entries contained in the box.

When you encounter a box, fill in all the information requested. If an option is not used or does not apply, fill in **N/A** (not applicable) in that space. It may be helpful to have the terminal operator review the *Series 1000 Operation Manual*, if he has not already done so, while you are starting up the system.

The Start-Up Form must be filled out completely and sent to:

**Gasboy International LLC**  
Customer Service Dept.  
707 N. Valley Forge Rd.  
P.O. Box 309  
Lansdale, Pa 19446

## **USING THIS BOOK**

This book is designed to be followed from start to finish. The procedures are listed in a logical order and correspond to the layout of the Start-up form. Please follow the step-by-step procedures in this manual.

The following symbols are used in this manual:



Means fill in the Start-up form entries explained in the box.



Means mail the form to GASBOY.



Means press the RETURN key.



## Section 2

---

# SITE INFORMATION

---

Before you can use the Series 1000, you must load in certain operating information. This section provides a template for you to fill in the information needed to perform the start-up commands in Section 11. Do not perform the commands at this time. Confirm with the customer the information that he will be using (e.g., fuel authorizations, limitations, etc.). Successful start-up requires coordination between separate components of the system: installation, card or key encoding, and operation. Each item listed contains a manual reference where you can find additional information.

For mag and optical card and FleetKey systems, the system identification, product authorization and product limitation codes are encoded on the access cards or keys and then entered into the system via commands. The commands you enter must match what is encoded on the cards. The *Series 1000 Card Encoding Manual* and the *FleetKey Operation Manual* explain the encoding of these items.

For cardless systems, the authorization and limitation codes are stored in the vehicle record. The commands you enter must match what is stored in the vehicle record. See **Fueling Restriction Commands** in the *Series 1000 Cardless Operation Manual* for more information.

### 1. COMMUNICATION PORT SETTINGS (Reference: *Operation Manual: Communicating with the Series 1000*)

Port 1	RS-232/RS-422	_____	Baud rate	_____
Port 2	RS-232/RS-422	_____	Baud rate	_____
Aux. Port 1	RS-232/RS-422	_____	Baud rate	_____
Aux. Port 2	RS-232	_____	Baud rate	_____

*NOTE: If you have a tank monitoring system, receipt printer, or Fuel Point Reader (FPR), you also have the auxiliary communications port PCB. Port 1 is configurable for RS-232 or RS-422; Port 2 is RS-232 only. If the system does not have a FPR, Port 1 is always used for a tank monitor; port 2 is for the receipt printer. If a FPR is used, it is always Port 1, RS-422, 1200 Baud; port 2 can be used for a tank monitor or receipt printer. In all cases, the receipt printer must be set for 9600 baud.*

### 2. SIGN ON PASSWORD (Reference: *Operation Manual: LS Command*)

Password (up to 10 characters) \_\_\_\_\_

### 3. SYSTEM CONFIGURATION (Reference: *Operation Manual: SC Command*)

Site Number: \_\_\_\_\_ (0000-9999)

Idle Message: \_\_\_\_\_ (20 characters maximum)

Number of pumps: \_\_\_\_ (1-8)      Number of tanks: \_\_\_\_ (1-8)

Receipt Printer?: \_\_\_\_

Pump No.	Pulser Type (Reed, Elec.)	Pulses Per Gallon (\$, 1000, 500, 100, 10, 1)	Tank Number (1-8)	Fuel Code (1-99)
1				
2				
3				
4				
5				
6				
7				
8				

Price Data Format: \_\_\_\_\_ No Data

\_\_\_\_\_ Unit Price Only (valid option for \$ pulsing only)

\_\_\_\_\_ Unit and Total Price

System ID: \_\_\_\_\_ **(Card or FleetKey Systems)**

Number of zero quantity transactions to disable a pump: \_\_\_\_\_ (01-99)

Card (Key) Expiration Date: \_\_\_\_\_ Enable \_\_\_\_\_ Disable **(Card or FleetKey Systems)**

Auto PIN lock out: \_\_\_\_\_ Enable \_\_\_\_\_ Disable **(Card or FleetKey Systems)**

PIN Entry: \_\_\_\_\_ Enable \_\_\_\_\_ Disable **(Cardless Systems Only)**

**4. SITE SHUT DOWN** (Reference: *Operation Manual: SC and SD Commands*)

Site Shut Down: Enable \_\_\_\_\_ Disable \_\_\_\_\_

Begin Time \_\_\_\_\_ End Time \_\_\_\_\_

**5. PRODUCT AUTHORIZATION TABLE** (Reference: *Operation Manuals: LF Command*)  
*Card Encoding Manual: Product Authorization Code*

Auth. Code	Allowable Fuel Types (01-99) Per Code								
1									
2									
3									
4									
5									
6									
7									
8									
9									

**6. PRODUCT LIMITATION TABLE** (Reference: *Operation Manuals: LL Command*)  
*Card Encoding Manual: Product Limitation Code*

Limit Cutoff (0-99999)

Limitation Code	Limit Cutoff
1	
2	
3	
4	
5	
6	
7	
8	
9	





**FLEETKEY SYSTEMS ONLY**

**10. MAINTENANCE TABLE** (Reference: *FleetKey Operation Manual: Maintenance Option*)

Class	MAINT A		MAINT B		MAINT C	
	Miles	Days	Miles	Days	Miles	Days
1						
2						
3						
4						
5						
6						
7						
8						
9						
10						
11						
12						
13						
14						
15						
16						
17						
18						
19						
20						

---

# BEGIN START-UP FORM

---

## PARTS 1 THROUGH 4

This section covers Parts 1 through 4 of the Start-up form. Parts 5 through 12 are covered in subsequent sections. A sample filled-out Start-up form appears at the end of this book.



### 1. SITE IDENTIFICATION

<b>Customer:</b>	The name of the company that owns the system.
<b>Location:</b>	The address of the site where the system is located.
<b>Contact:</b>	The name of a responsible contact person at the site.
<b>Customer Phone No.:</b>	The phone number where the contact person can be reached.
<b>Date:</b>	Today's date (date of the start-up).
<b>Distributor:</b>	The distributor involved with the sale and/or installation of the system.
<b>Distributor Phone No.:</b>	The phone number where the distributor can be reached.
<b>Start-up Person:</b>	The name of the person performing the start-up.
<b>Installer:</b>	The firm that installed the system.



### 2. PUMPS/DISPENSERS

<b>Fuel Type:</b>	The type of fuel dispensed by that pump or dispenser (e.g., No-Lead, Regular, etc.).
<b>Fuel Code:</b>	The product code number assigned to that fuel type.
<b>Pump Make:</b>	The name of the manufacturer of the pump or dispenser.
<b>Pump Model #:</b>	The model number of the pump or dispenser.
<b>Pump Serial #:</b>	The serial number of the pump or dispenser.
<b>Motor Size:</b>	The size of the motor used (e.g., 3/4HP, 1 1/2HP).
<b>Pump Type:</b>	The type of pump used to dispense the fuel. Is it a submersible pump ( <b>Sub</b> ) located in the tank or is it a suction pump ( <b>Suc</b> ) located in the pump housing? Circle one.
<b>Starter Relay:</b>	Is an external starter relay used to supply power to the pump. Circle <b>Y</b> for yes or <b>N</b> for no.
<b>Pulser Rate:</b>	The pulser rate of the pulser used by that pump or dispenser (e.g., \$, 10:1, 100:1).



### 3. COMMUNICATION

<b>Data Terminal:</b>	The make and model number of the data terminal connected to the system. If a data terminal is not being used, indicate not applicable ( <b>N/A</b> ).
<b>External Modem:</b>	The make and model number of the external modem that is connected to the system. This can include Short Haul Modems used for distances over 1500 feet. If no external modems are used, indicate not applicable ( <b>N/A</b> ).
<b>Modem Phone No:</b>	The area code and phone number for the internal or external phone modem connected to the system. If a modem is not used, indicate not applicable ( <b>N/A</b> ).
<b>Port 1:</b>	The method of communication used for Port 1 (direct printout port). Circle either <b>RS-232</b> or <b>RS-422</b> . Indicate the baud rate.
<b>Port 2:</b>	The method of communication used for Port 2 (secondary port). Circle either <b>RS-232</b> , <b>RS-422</b> , or internal modem ( <b>Int. Modem</b> ). Internal modem should be circled when the internal modem is connected to Port 2 via the ribbon cable directly above the Port 2 RS-232 and RS-422 connectors. Nothing should be connected to the RS-232 or RS-422 ports when the ribbon cable is connected. Indicate the baud rate.
<b>Aux. Port 1:</b>	If auxiliary port 1 is used with a tank monitor, indicate the method of communication. Circle either <b>RS-232</b> or <b>RS-422</b> . Auxiliary port 2 is always RS-232. Indicate the baud rate.



### 4. BREAKERS

Enter the breaker number for each of the items listed. When multiple breakers are used for powering a device (e.g., a breaker for the dispenser and a breaker for the submersible pump), list both breakers. All breakers pertaining to the system should be in the **OFF** position at this time.

## Section 4

---

# SYSTEM LAYOUT

---

1. Verify that the system is installed with a minimum clearance of 18 inches between the post and any of the pumps or dispensers. This clearance meets the NFPA 30A and NFPA 70 requirements and allows room for wiring and maintenance of the system. Adequate clearance around the head of the unit is important to provide room for maintenance of the system. A minimum of 14 inches of clearance from the rear of the unit must be provided to allow the rear door to open.
2. Remove the 10 screws from the upper side pedestal cover. Unlock and remove the cover. Remove the 10 screws from the lower side pedestal cover and remove the cover (same side of post as the upper pedestal cover).
3. Verify that the conduit is installed according to the following specifications:

All wiring (AC and DC) connecting the different components of the Series 1000 System must be installed in **metal conduit**. **PVC IS NOT ACCEPTABLE**. Components of the system include pumps, dispensers, submersible pumps, submersible starter relays, Series 1000 System, and circuit breaker panels. Communications equipment signal wires should also be run in **metal conduit**, (except for RS-422 wiring as noted below).

**High voltage AC power wires** must be installed in separate conduit from the low voltage DC signal wires. The AC power wires and DC signal wires must not be run in any sort of common conduit or trough (except for RS-422 wiring as noted below). All conduits should be connected to the Series 1000 pedestal through the holes and knockouts provided by the factory. No other holes should be made in either of these units unless previously approved by GASBOY.

All wiring and conduit runs must conform with the National Electrical Code (NFPA 70), the Automotive and Marine Service Stations Code (NFPA 30A), and State and Local Electrical Codes.

Conduits for the system port wiring must be as follows:

**RS-232** wires must be installed in a metal conduit separate from any AC wires.

**RS-422** wires should be installed in a metal conduit separate from any AC wires. The use of shielded two twisted pair cable (Belden 8102 or equivalent - GASBOY P/N C08728) allows for the following exceptions:

- The cable can be run with AC wires in metal conduit. The shield drain wire must be connected to the system AC ground.
- The cable can be run indoors without the use of metal conduit. The shield drain wire must be connected to the system AC ground. In no case should the cable be run outdoors without the use of metal conduit. Whenever possible the conduit should be run underground and not overhead.
- A short haul modem (SHM) must be used for RS-422 communications.



## 5. CONDUIT

### All Metal Conduit:

Indicate if all conduit is metal and not PVC. Circle **Y** for yes (all metal) or **N** for no (not all metal conduit).

### AC and DC in Separate Conduits:

Indicate if all wiring is separated in the appropriate conduits according to the conduit specifications. Circle **Y** for yes if all AC and DC wiring is in separate conduits. Circle **N** for no if AC and DC wiring is combined in conduits where it should not be.

*NOTE: In cases where the RS-422 communication lines are in the AC conduit using the correct shielded cable, and all other AC and DC lines are in separate conduits, indicate a **Y** for yes.*

### Communication Wires:

Indicate through which conduit the communication wires (from the ports) are run. **Separate** indicates they have their own conduit, **DC** indicates they are included with DC wires, **AC** indicates they are included with AC wires.

### Wiring Neatness:

Indicate the overall neatness of the installer's wiring. Is the appearance of the wiring neat and orderly or is it very disorderly? Circle **Good**, **Fair**, **Poor**, or **Bad**.

# JUMPER AND SWITCH SETTINGS

## SERIES 1000 JUMPERS

All jumpers and connectors must be set properly to ensure correct operation of the Series 1000 System.

1. Make sure all of the pump override switches, located in the pedestal (see Figure 5-1), are in the **OFF** position.




Figure 5-1. System and Pump/Dispenser Wiring Terminal Block ID

2. Unlock and lower the rear door of the Series 1000.
3. Make sure the Series 1000 **AC POWER** switch, located in the rear of the unit, is in the **OFF** position.
4. Loosen and remove the two inside knobs.
5. Remove the four screws from the outside of the hood.
6. Standing alongside of the unit, place one hand on the top rear of the hood assembly and one hand on the front plastic shield. (Be careful not to break or shatter the shield).
7. Lift the hood straight up and remove it.
8. Locate the microprocessor PCB mounted on the right side of the unit (see Figure 5-2 for Steps 9-12).



## 6. SYSTEM IDENTIFICATION

**System Serial #:** The serial number of the system. This number can be found on a tag mounted to the outside of the rear door.

**Program Name/Date:** The program name and date. This information is located on the system's ROM (program chip). The ROM is an integrated circuit (IC) located approximately in the center of the system's microprocessor PCB (see Figure 5-2). The program name is seven alphanumeric characters consisting of an alphabetic character followed by six numerics, e.g., A123456.

9. Port 1 - If necessary, move the cable for Port 1 to the appropriate connector for either RS-232 or RS-422 communication.
10. Port 1 - Jumper Port 1 for the appropriate baud rate.
11. Port 2 - If necessary, move the cable for Port 2 to the appropriate connector for either RS-232 or RS-422 communication. If an internal 1200 baud modem is supplied by GASBOY, make sure the Port 2 cable is not connected to either connector.
12. Port 2 - Jumper Port 2 for the appropriate baud rate.
13. If using the Fuel Point option, a tank monitoring system or a receipt printer, verify the connectors and jumpers for the auxiliary communications port. The auxiliary communications port PCB assembly is shown in Figure 5-4. With the Fuel Point option, Port 1 is always the Fuel Point; a tank monitor or receipt printer may be connected to Port 2. Without the Fuel Point option, the tank monitor cable must be connected to Port 1 and may be RS-232 or RS-422; the receipt printer is always connected to Port 2.
14. Auxiliary port jumpers - The K1 jumper patch contains 12 pins; the six at the left are for Port 1 and the six at the right are for Port 2. Ports 1 and 2 can be jumpered for 300 or 1200 baud. To eliminate problems, the data terminal must run at the same (or higher) baud rate as the tank monitor. Port 2 should always be jumpered at 9600 baud for receipt printer and 1200 baud for tank monitor.



15. If your Series 1000 system has a Tripp Lite battery backup installed, remove the jumper or wire wrap on jumper patch JP8. This jumper must be removed to allow normal operation of the data terminal in a power fail condition. The JP8 jumper patch is located next to the diagnostic and reset switches on the right edge of the MPU PCB.
16. Pulse Rate - The pulse rate switch is mounted on the back side of the microprocessor PCB and can be accessed through a hole in the sheet metal on which the microprocessor PCB is mounted. Move this switch towards the rear of the unit to enable the pulse rate to be set during the configuration of the system. *NOTE: When the pulse rate switch is set to enabled, no transactions can occur at the system and the message **REMOTE CONFIGURATION** appears on the display. Be sure to set it to disabled when pulse rate setting is complete.*
17. Locate the pump control PCB(s) mounted to the rear door of the Series 1000 System (see Figure 5-3 for Steps 18-28).
18. Remove the flat ribbon cable connector from each of the pump control PCB's. (Ribbon cable is not shown in Figure 5-3. It attaches at the top right of the board).
19. Remove the two Phillips head screws which attach the pump control PCB bracket to the pump control card cage.
20. Note the orientation of the three black connectors on the opposite side of the pump control PCB for hoses 1 and 2. Remove these cables from the rear of the PCB. Slide the pump control PCB out of the card cage.
21. Pulse Configuration - Set the pulser configuration jumpers for hose 1 according to the type of pulser used. Set the pulser configuration jumpers for hose 2 according to the type of pulser used.
22. Pulse Rate (Debounce) - Set the pulse rate jumper according to the highest resolution pulser that is used on either hose (e.g., if hose 1 has a 10:1 pulser and hose 2 has a 100:1 pulser, set the jumper for 100:1).
23. Address - Verify that the pump control PCB is set for the proper address. This is jumpered at the factory and should be correct.
24. Slide the pump control PCB into the pump control card cage and screw it into place. Re-attach the three cables to the rear of the PCB. *(NOTE: These cables are keyed to prevent them from being installed upside down).* The cable for hose 1 attaches to side 1 (J1) and the cable for hose 2 attaches to side 2 (J2). The orientation of the sides is shown in Figure 5-3.
25. If the hardware for hoses 3 and 4 is installed, repeat Steps 19-24 substituting hose 3 for hose 1 and hose 4 for hose 2. If not available, skip to Step 28.
26. If the hardware for hoses 5 and 6 is installed, repeat Steps 19-24 substituting hose 5 for hose 1 and hose 6 for hose 2. If not available, skip to Step 28.
27. If the hardware for hoses 7 and 8 is installed, repeat Steps 19-24 substituting hose 7 for hose 1 and hose 8 for hose 2. If not available, skip to Step 28.
28. Reconnect the ribbon cable to the pump control PCB(s).





Figure 5-3. Series 1000 Pump Control Configuration

## AUXILIARY COMMUNICATIONS PORT PCB ASSEMBLY

When the system is equipped with a receipt printer, tank monitoring system, or Fuel Point Reader, an additional board is required. The Auxiliary Communications Port PCB assembly (Figure 5-4) is attached to the Series 1000 MPU Board via the expansion port (shown in Figure 5-2).



**Figure 5-4. Auxiliary Communications Port Board**

### Veeder-Root TLS-250 Tank Monitor Switch Settings

When the Series 1000 is connected to a Veeder Root TLS-250 tank level sensor, set the baud rate jumper for 300 or 1200 baud. Setting the baud rate at 9600 is not recommended and may result in a loss of data received from the TLS-250.

The Option PCB, located inside the right hinged cover of the TLS-250 contains a rotary switch which must also be set. The switch is located at the lefthand center of the PCB and shows a numbered switch position. This switch should be set to 4 (1200 baud) or 6 (300 baud) to match the setting used in the Series 1000.

The TLS-250 Main PCB is located in the back of the TLS-250 box and accessed by opening the right hinged cover. It contains a 5-position DIP switch bank, located at the upper left of the Main PCB. These switches should be set as follows:

Switch	Function	Status
1-3	Control Interboard Communication Rate	Always Closed
4	Parity: Closed, Odd; Open Even	Set to Open
5	Security Code option. Open, disable; Closed, enable. Before setting this switch, see the Veeder Root Communications Manual for additional details.	Set to user preference

### **Veeder-Root TLS-350 Tank Monitor Switch Settings**

When the Series 1000 is connected to a Veeder Root TLS-350 tank level sensor, set the baud rate jumper for 300 or 1200 baud. Setting the baud rate at 9600 is not recommended and may result in a loss of data received from the TLS-350.

The TLS-350 communications parameters are configured via the TLS-350 front panel keypad. Refer to the TLS-350 manuals for configuration options and how to change them.

The TLS-350 CPU board is located in the TLS-350 console printer compartment (lefthand door). It contains a 4-position DIP switch bank, located in the lower righthand corner of the printer compartment. These switches should be set as follows:

Switch	Function	Status
1	Front Panel Security Code Feature	Open, Disable; Closed, Enable
2	RS-232 Security Code Feature	Open, Disable; Closed, Enable
3 & 4	Not used	


### **Fuel Point Reader Port and Baud Rate Jumpers**

When a Fuel Point Reader (FPR) is connected to a FleetKey, it is connected to P3 (RS-422 Port 1). The K1 baud rate jumper for port 1 must be set for 1200 baud.

## GASBOY FUEL POINT READER SWITCHES

When the system is used with the Fuel Point Reader (FPR), verify that the switches on the FPR CPU PCB are set as shown.

Switch	Setting
1	ON
2	OFF
3	OFF
4	OFF



**Figure 5-5. Fuel Point Reader (FPR) CPU PCB**

## LINK MC5 TERMINAL SETUP

Install and complete the setup of the terminal as specified in the manufacturer's setup instructions. Then you'll need to enter the Setup Mode and change parameters on five screens. This enables the terminal to function properly with both the Okidata printer and the Series 1000 system. Be sure to set the **LINES PER PAGE** in the **SC** command (Section 5) to 62.

When setting up the terminal, use the following keys as needed.

SHIFT and SELECT	Used together to enter Setup Mode.
Up/Down Arrows	Move to a menu item.
Left/Right Arrows	Change values for parameter.
TAB	Move to next column.
PAGE DOWN/UP	Move to next or previous screen.
F1 to F8	Select specific screens from 1 to 8.
E or F9	Exit Setup Mode.
S	Save current values.
P	Toggle between Main and Aux ports.
D	Defaults all values.
R	Restores values to previously saved settings.

**In the steps that follow, setup parameters shown in bold are non-critical and can be configured to your preference.**

1. Press CAPS LOCK to activate the caps lock feature. **CAPS** will appear in the upper lefthand corner of the status line.
2. Enter Setup Mode by pressing SHIFT and SELECT. Be careful not to press CTRL and SELECT. Doing so switches terminal control to Aux. If you find yourself in Aux mode, CTRL and SELECT will return you to Main mode. The first Setup Screen, General Setup displays:

**Important:** Before you begin to change parameters, check to be sure the message **HOST IS ON MAIN PORT** is displayed. If the message reads **HOST IS ON AUX PORT**, press **P** to return to the Main port configuration.

General Setup			
Emulation	VT220-7	Auto Page	Off
Enhancements	Off	<b>Warning Bell</b>	<b>On</b>
Virtual Terminal	Off	<b>Margin Bell</b>	<b>Off</b>
Scroll Style	Jump	<b>Bell Sound</b>	<b>1</b>
Auto Scroll	On	Block Terminator	US/CR
Auto Wrap	On	Send ACK	Off
Received CR	CR	Monitor Mode	Off

3. Press F2 or PAGE DOWN to display the next Setup Screen, Communications Setup.

Communications Setup			
Main Baud	1200	Aux Baud	9600
Main Data/Parity	8/None	Aux Data/Parity	8/None
Main Stop Bits	1	Aux Stop Bits	1
Main Rcv Hndsk	XON/XOFF	Aux Rcv Hndsk	NONE
Main Xmt Hndsk	NONE	Aux Xmt Hndsk	XON/XOFF
Main Rcv Level	50%	Aux Rcv Level	50%
Ignore 8th Bit	Off	Aux Port	RS232
Comm Mode	Full Duplex	Aux Interface	RS232
Disconnect	2 Sec	Printer	Serial

**NOTE:** Series 1000 software prior to version 8.1 and FleetKey software prior to version 2.1 does not support XON/XOFF protocol. For these software versions, set the **Main Rcv Hndsk, Main Xmt Hndsk, Aux Rcv Hndsk and Aux Xmt Hndsk** parameters to **NONE** and set the **Main Baud** parameter to 1200 and **Aux Baud** parameter to 9600.

4. Press F3 or PAGE DOWN to display the next Setup Screen, Display Setup.

Display Setup			
<b>Columns</b>	<b>132</b>	Background	Dark
80/132 Clear	On	Attributes	Char
Lines	24	Wprt Intensity	Dim
Pages	1X Lines	Wprt Reverse	Off
Status Line	Ext	Wprt Underline	Off
<b>Cursor Style</b>	<b>Blink Block</b>	Refresh Rate	60Hz
Cursor	On	Pound Char	US
<b>Screen Saver</b>	<b>15 Min</b>	Auto Font Load	On

**NOTE:** The **Columns** setting of 132 may be changed to 80 if desired; however, this may cause transactions displayed on the screen (and on the Okidata printer) to wrap, hindering readability.

5. Press F4 or PAGE DOWN to display the next Setup Screen, Keyboard Setup.

Keyboard Setup			
<b>Key Click</b>	<b>Off</b>	Break	250 ms
<b>Key Repeat</b>	<b>On</b>	Xmt Limit	None
Key Lock	Caps	FKey Xmt Limit	None
Return Key	CR	Key Code	ASCII
Enter Key	CR	WP Keyboard Mode	Off
Back Space Key	DEL/BS	Lock Keyboard	Disable
Left Alt Key	Funct	Language	US
Delete Key	Normal		

- Press F5 or PAGE DOWN to display the next Setup Screen, ANSI Setup.

ANSI Setup			
FKey Lock	Off	Send	All
Feature Lock	Off	Print	National
Keypad	Numeric	Send Area	Screen
Cursor Keys	Normal	Print Area	Screen
Xfer Term	EOS	Send Term	None
Char Mode	Multinational	Print Term	None
Char Set	DEC-MCS	Print Mode	Auto
Keys	Typewriter	Auto Answerback	Off
VT100 ID	VT 100		

- Press **S** to save Setup changes.
- Press F9 or **E** to exit Setup Mode.

## OKIDATA 184 SETUP

To prepare the Okidata printer for operation with the LINK MC5 terminal and your GASBOY Fuel Management System, perform the following steps. Install and complete the setup of the printer as specified in the manufacturer's setup instructions. Then set up the switches as follows:

- |       |     |   |
|-------|-----|---|
| SW1-1 | ON  | Parity: Odd                                     |
| SW1-2 | ON  | Parity: Without                                 |
| SW1-3 | ON  | Data bits: 8                                    |
| SW1-4 | OFF | Protocol: XON/XOFF (Series 1000 V8.1 or higher) |
|       | ON  | Ready/Busy (Series 1000 versions prior to V8.1) |
| SW1-5 | ON  | Test select: Circuit                            |
| SW1-6 | ON  | Mode select: Print                              |
| SW1-7 | ON  | Busy line selection: DTR - Pin 20               |
| SW1-8 | ON  | Busy line selection: DTR - Pin 20               |
|       |     |   |
| SW2-1 | OFF | Baud rate: 9600                                 |
| SW2-2 | ON  | Baud rate: 9600                                 |
| SW2-3 | ON  | Baud rate: 9600                                 |
| SW2-4 | ON  | DSR output signal: Active                       |
| SW2-5 | ON  | Buffer threshold: 32 bytes                      |
| SW2-6 | OFF | Busy signal timing: 1 sec (min.)                |
| SW2-7 | ON  | DTR signal: Space after power on                |
| SW2-8 | OFF | Not used  |

- Turn the printer offline by pressing SELECT. The SELECT light should go off.
- Position the print head at the top of the paper and press the TOF SET button.
- Put the printer back online by pressing SELECT. The SELECT light should go on.
- Press the MODE button until the light next to **HSD** is lit.
- Press the PITCH button until the light next to **17** is lit.

*NOTE: Pitch may be set to a lower number (resulting in larger print) if transactions are less than 80 characters.*



## Section 6

---

# PUMP/DISPENSER MANUAL TEST

---

1. Verify that the general guidelines listed below were met when installing the system's pumps and dispensers.

### Suction Pumps

The Series 1000 System is capable of directly driving pump motors up to 3/4 HP at 115 VAC or 230 VAC. A starter relay must be used with pump motors over 3/4 HP. A separate circuit breaker should be supplied for each pump to meet the current requirements and to allow for isolated control with the circuit breaker panel in case of problems.

### Dispensers

The Series 1000 System is capable of directly driving submersible pumps up to 3/4 HP at 115 VAC or 230 VAC. A separate circuit breaker should be supplied for each dispenser in cases where it will directly drive the submersible pump. A dispenser with a submersible pump rated over 3/4 HP will require the use of a submersible starter relay. Dispensers may be grouped together on a single breaker when the submersible pump has its own breaker. It is recommended that no more than two dispensers be powered from one breaker to maintain isolated control with the circuit breaker panel in case of problems.

2. **Manual Override Test:** The pumps and/or dispensers should be tested to verify the AC wiring. **DO NOT TURN ON THE SYSTEM POWER DURING THESE TESTS!** The steps below indicate the proper procedure for testing and the expected results. If any of these tests fail, correct the wiring and then perform the test again. See Figure 5-1 for location of the override switches.
  - a. Turn on the breakers for all pumps and/or dispensers. **DO NOT TURN ON THE BREAKER FOR THE SERIES 1000.**

**CAUTION**

**AC power is present on the terminal blocks in the pedestal. Electrical shock may occur if the operator comes in contact with these connections.**

- b. Place the system override switch for Hose 1 in the **MANUAL** position.
- c. Turn on Hose 1. After completing reset, the hose should be able to dispense product.
- d. Turn on all other hoses. No other hoses beside 1 should activate.
- e. Turn off all hoses.
- f. Place the system override switch, for Hose 1 in the **OFF** position.
- g. Repeat Steps **b** through **f** for all remaining hoses. Substitute the hose number being tested for Hose 1.



## SYSTEM POWER

1. Verify that the AC Power for the Series 1000 System comes from a separate, dedicated circuit breaker. No other equipment, except for data terminals or external modems should be powered from this breaker. The system's pumps or dispensers must not be on this breaker. Whenever possible, one breaker should be used to supply the system, terminal, and modem. However, if necessary, the terminal or modem may be on a separate, dedicated breaker.

Power for the system should be 115 VAC  $\pm$  10%, 47-63 HZ. The system draws 135 watts maximum. An unstable power source may require the use of a voltage conditioner. (GASBOY P/N C01862). If the Series 1000 is going to be used for the resale of fuel, Weights & Measures regulations require a backup power supply (GASBOY P/N C04395).

### CAUTION

**AC power is present on the terminal blocks in the pedestal. Electrical shock may occur if the operator comes in contact with these connections.**

2. Turn on the circuit breaker for the system.
3. Locate the **SYSTEM POWER** terminal block in the pedestal on the chassis assembly (see Figure 5-1). Use a digital AC voltmeter to measure the following voltages. Holes in the plastic cover provide access to the terminal block for your meter leads.

**Hot to Neutral:** AC voltage measured between the **H** and **N** screws. This voltage should be 115 VAC  $\pm$  10% (104 VAC to 126 VAC).

**Hot to Ground:** AC voltage measured between the **H** and **G** screws. This voltage should be 115 VAC  $\pm$  10% (104 VAC to 126 VAC).

**Neutral to Ground:** AC voltage measured between the **N** and **G** screws. This voltage should be 0 VAC  $\pm$  1 volt (-1 VAC to 1 VAC).

*NOTE: If power is not within these specifications, correct it before you continue.*

4. **Grounding Method:** Proper system grounding is an extremely important part of the system installation. Grounds for all system devices should be wired to the breaker panel ground bus bar which, in turn, should be grounded to a ground rod. A conduit ground does not provide a sufficient ground. It is recommended that the neutral and ground bus bars be bonded together unless prohibited by local codes.



### 7. SYSTEM POWER

Record voltage readings from Step 3 for **Hot to Neutral**, **Hot to Ground**, **Neutral to Ground**, and the grounding method from Step 4 for **Grounding Method** (e.g., system to circuit breaker panel bus to ground rod).



## Section 8

# DC POWER

### SERIES 1000

1. Turn on the system **AC POWER** switch located in the rear of the unit. The fluorescent lamp should light and the system should begin to operate.
2. Using a digital DC voltmeter, measure the following voltages. If any of the measured DC voltages are outside of the tolerance noted below (except for +5 which can be adjusted), immediately shut off the **AC POWER** switch and diagnose the problem. Do not record any other DC voltages until this voltage is properly adjusted. Test points are provided on the rear edge of the microprocessor PCB (see Figure 5-2). All voltage measurements should be taken with the negative lead of the meter on the ground (**GND**) test point. This is the black test point and is easily identifiable.



#### 8. DC POWER

As you are measuring the noted voltages, fill in the readings for each in this section of the Start-up form.

#### **+5VDC**

Measure to the **+5** orange test point. The tolerance for this voltage is **+5.0** to **+5.1**; however, this voltage is adjustable and should be adjusted as close to **5.0** as possible. If an adjustment needs to be made, follow steps **a** through **f** below.

- a. Turn the **AC POWER** switch off.
- b. Remove the three screws from the mesh cover protecting the power supply and remove the cover.
- c. Turn the **AC POWER** switch back on.

#### **CAUTION**

**Be careful not to touch anything but the white adjustment screw located in the upper right hand corner. High voltage exists around the power supply and electrical shock may occur.**

- d. Using an 1/8 inch or smaller plastic flat blade screwdriver, adjust the power supply to **+5.0VDC** by turning the voltage adjustment screw clockwise to increase voltage, counterclockwise to decrease voltage. (The screw is located at the top and slightly to the right of the center of the power supply board.) Turn the screw slightly to judge the sensitivity.
- e. Turn the **AC POWER** switch off and replace the mesh cover.
- f. Turn the **AC POWER** switch back on.

**+12VDC**

Measure to the **+12** red test point. The tolerance for this voltage is **+11.8** to **+14.00** and is not adjustable.

**-5VDC**

Measure to the **-5** blue test point. The tolerance for this voltage is **-4.8** to **-5.2** and is not adjustable.

**-12VDC**

Measure to the **-12** white test point. The tolerance for this voltage is **-11.7** to **-14.00** and is not adjustable.

## **GASBOY FUEL POINT READER**

Using a digital DC voltmeter, measure between the GND test point and the right side of resistor R26 of the FPR CPU PCB (See Section 5 for illustration).

The acceptable voltage range is +5.0 to +5.1 VDC, but try to adjust it as close as possible to +5.0 VDC. There is an access hole in the power supply bracket for adjustment.

---

## COMMUNICATIONS TESTS

---

1. Verify that the external communication devices are located in the proper environments as described below.

### Data Terminal

When a data terminal is used with the system, it should be located in a clean, office-type environment. It should not be installed over a hazardous location. Data terminals supplied by GASBOY have an operative temperature range of 0° C to 40° C. Locating the terminal in a dirty environment may cause premature failures.

### External Modems

When an external modem is used with the system, the modem should be located in an office-type environment. If this is not possible, it should be housed in a protective enclosure. It should not be installed over a hazardous location. External modems supplied by GASBOY have an operative temperature range of 0° C to 40° C.

2. Verify that the wiring for the communication ports meets the following installation requirements.

- All wiring is to be installed and used in accordance with the National Electrical Code (NFPA 70) and the Automotive and Marine Service Station Code (NFPA 30A). Wiring is also to conform to local codes.
- All peripheral equipment connected to the RS-232 ports should be UL-Listed, have an Electronics Industry Association (EIA) standard RS-232 communications protocol, and not be installed over a hazardous location.
- The AC power for the peripheral equipment must be on a separate breaker (which can be the same as the system's breaker).
- RS-232 distance is limited to 100 feet; RS-422 is limited to 1500 feet.

*NOTE: For distances over 1500 feet, see the Series 1000 Installation Manual for use of ME800 Short Haul Modems.*

- Wire

**RS-232**            22 gauge for use with RS-232D connectors; 18 or 22 gauge for use with the GASBOY RS-232 termination box

**RS-422**            Two twisted-pair cable (metal conduit separate from any AC wires)  
Two twisted-pair cable, shielded, Belden 8102 or equivalent (metal conduit not separate from AC wires or indoors with no metal conduit)

3. Test the communication ports. The required tests will vary according to the type of devices connected to the ports and the ports used. When testing the ports, the equipment and communication lines that will be used at the site should be used in the test whenever possible. It is recommended that a data terminal always be connected to Port 1 (direct printout port) so that transactions can be logged as they occur.

### Testing the Direct Connect Device

- a. Turn on the direct connect device (e.g., data terminal).
- b. Locate the ON-LINE switch on the terminal and place it in the **ON** position.
- c. Press CTRL F or press RETURN. The system should respond: **SIGN ON**.
- d. Type **GASBOY** and press RETURN. The system should respond with an asterisk (\*).

*NOTE: For security reasons, **GASBOY** does not print as you type it.*

- e. Type **PD**. The system prints the date, time, and transaction numbers followed by another asterisk (\*).
- f. Type **EX**. The system prints **EXIT**. When connected to Port 1, the system goes into the direct printout mode by printing the transaction header.

### Testing the Modem

- a. Turn on the modem/terminal device from which the call will originate.
- b. Dial the Series 1000 site and establish a communication link with the system (See the modem operator's manual).
- c. Press CTRL F or press RETURN. The system should respond: **SIGN ON**.
- d. Type **GASBOY** and press RETURN. The system should respond with an asterisk (\*).

*NOTE: For security reasons, **GASBOY** does not print as you type it.*

- e. Type **PD**. The system prints the date, time, and transaction numbers followed by another asterisk (\*).
- f. Type **EX**. The system prints **EXIT**.
- g. Hang up the phone to terminate the communication link.

4. Lower the hood onto the unit so that the four slots (two each side) on the hood side brackets go over the pins on the base of the head assembly.
5. Replace the four screws on the outside of the hood.
6. Replace the two inside knobs.
7. Close and lock the rear door of the hood assembly.

### Testing the Tank Monitor

- a. Determine the device (direct connect or modem) from which the tank monitor will be contacted and follow steps **a** through **d** of **Testing the Direct Connect Device** or **Testing the Modem**.
- b. Type **TM**. The system prints **TANK MONITOR LINK? <Y OR N>**.
- c. Type **Y** and press RETURN. The system should respond with the **>** symbol indicating connection to the tank monitor.
- d. Type any valid tank monitor command and the tank monitor should return the appropriate response.
- e. Press CTRL E. The system should respond with an asterisk (\*) indicating it has terminated communications with the tank monitor and has resumed communications with the Series 1000.
- f. Type **EX**. The system prints **EXIT**.

### Testing the Fuel Point Reader

- a. Connect a terminal to port 1 (direct printout port).
- b. Turn FPR power switch on. The terminal should respond **FPR communications established @date time**.
- c. Turn FPR power switch off. The terminal should respond **FPR communications lost @date time**.



## Section 10

---

# PUMP/DISPENSER AUTOMATIC TEST

---

The automatic test verifies the wiring and operation of the system in respect to the connections between the pumps and/or dispensers and the system. As each transaction is completed it should print on the direct printout data terminal (Port 1). For systems not using direct printout either a data terminal can be temporarily connected to Port 1 or the information will have to be manually polled.

In order to perform this test on a card system, you must have a test card. For a cardless system, a dummy vehicle number, zero (0), has been defined.

The steps below indicate the proper procedure for testing and the expected results.

1. Turn all the override switches, located in the pedestal (see Figure 5-1), into the **AUTO** position.
2. On a card system, use the test card (provided with each system); on a cardless system, enter vehicle number **0** and press ENT. Select Hose 1, then turn on Hose 1 using the pump handle. Hose 1 should reset and be able to dispense product.
3. Dispense some product with Hose 1.
4. Turn on all other hose handles. No other hoses besides 1 should activate.
5. Turn off all other hose handles.
6. Turn off the handle for Hose 1. Place the handle for Hose 1 back into the on position. Hose 1 should not reset and should not dispense product.
7. Verify that the quantity displayed on the Hose 1 register matches the quantity recorded on the system printout.
8. Repeat Steps 2 through 7 for all hose outlets.

*NOTE: Steps 9 through 13 should be done in addition to the above only if you are using dispensers or dual hose single motor suction pumps.*

9. Again, using the test card or vehicle number **0**, select two hose outlets of the same product type (use the same pump).
10. Turn on both pump handles. Both hose outlets should reset and be able to dispense product.
11. While dispensing product from one hose (A), allow the other hose (B), to time out.
12. When Hose B has timed out, try to dispense product from it by squeezing the nozzle. You should not be able to dispense product from Hose B. If you can, verify that the dispensers use solenoids rather than hydraulic valves.

13. Repeat Steps 9 through 12 for all combinations of hose outlets of the same product type.
14. Replace and lock the upper side pedestal cover and secure it with the 10 screws. Replace the lower side pedestal cover and secure it with the 10 screws.

## Section 11

---

# START-UP COMMANDS

---

Use the following commands to set up the system at the initial start-up. The *Series 1000 Operation Manual* describes these commands in more detail. If you have the Fuel Point option, refer to Appendix D of the *FleetKey Operation Manual* for command changes. If you filled in the checklist in Section 2 of this manual, you already have all the information you need to start up your system. In the examples, bold represents the information that you enter, and this symbol ↵ represents the RETURN key.

1. Press CTRL F or RETURN. The system displays: **SIGN ON:**
2. Type **GASBOY** and press RETURN. (The word **GASBOY** is shown in the illustration for example only. You will not see the word **GASBOY** as you are typing it.) The asterisk prompt \* appears indicating that you are in Command Mode and can begin entering commands to configure your Series 1000 System.

```
SIGN ON: GASBOY↵
*
```

3. Type **LS** to change the initial password (**GASBOY**) to one of your choice (up to 10 characters).

```
*LS
PASSWORD: PASSWORD↵
*
```

4. Type **SC** to load your system configuration data.

**CARD OR CARDLESS SYSTEM**

```

*sc
RESETTING SYSTEM CONFIGURATION
ARE YOU SURE? <Y OR N> Y↓

SITE NO.: <XXXX> 0003↓

IDLE MESSAGE: <20 CHARS> GASBOY SERIES 1000↓

NUMBER OF PUMPS: <1-8> 4↓

PUMP #1
  $ OR QTY PULSES? <$ OR Q>$↓

PUMP #2
  $ OR QTY PULSES? <$ OR Q>Q↓
  PULSES PER GAL. <1000,500,250,100,10,1>100↓

PUMP #3
  $ OR QTY PULSES? <$ OR Q>Q↓
  PULSES PER GAL. <1000,500,250,100,10,1>10↓

PUMP #4
  $ OR QTY PULSES? <$ OR Q>Q↓
  PULSES PER GAL. <1000,500,250,100,10,1>10↓

NO. OF TANKS: <1-8> 4↓

PRICE DATA FORMAT
  0 = NO PRICE DATA
  1 = UNIT PRICE
  2 = UNIT & TOTAL PRICE
  ENTER FORMAT: <0,1,2>0↓

SYSTEM ID:<XXXX>↓                                (Card Systems Only)

AUTO PUMP DISABLE
  NO. OF ZERO QTY. TRAN. <1-99> 5↓

LINES PER PAGE <0-62>: 62↓

CARD EXPIRATION DATE
  ENABLE OR DISABLE? <E OR D> E↓                (Mag Card Only)

AUTO PIN LOCKOUT                                  (Card Systems Only)
  ENABLE OR DISABLE? <E OR D> E↓

PIN ENTRY                                          (Cardless Systems Only)
  ENABLE OR DISABLE? <E OR D> E↓

AUTO SITE SHUT DOWN
  ENABLE OR DISABLE? <E OR D> D↓
  
```

*NOTE: Additional system configuration prompts may appear depending on the options available on your system. See the description of your option in the Operation Manual for command differences.*

## FLEETKEY SYSTEM

```
*sc
RESETTING SYSTEM CONFIGURATION
ARE YOU SURE? <Y OR N> Y↓

SITE NO.: <XXXX> 0003↓

IDLE MESSAGE: <20 CHARS> GASBOY FLEETKEY↓

ENTER KEY TYPE 1 PROMPT: INSERT GRAY KEY↓
ENTER KEY TYPE 2 PROMPT: INSERT GREEN KEY↓

NUMBER OF PUMPS: <1-8> 4↓

PUMP #1
  $ OR QTY PULSES? <$ OR Q>$↓

PUMP #2
  $ OR QTY PULSES? <$ OR Q>Q↓
  PULSES PER GAL. <1000,500,100,10,1>100↓

PUMP #3
  $ OR QTY PULSES? <$ OR Q>Q↓
  PULSES PER GAL. <1000,500,100,10,1>10↓

PUMP #4
  $ OR QTY PULSES? <$ OR Q>Q↓
  PULSES PER GAL. <1000,500,100,10,1>10↓

NO. OF TANKS: <1-8> 4↓

PRICE DATA FORMAT
  0 = NO PRICE DATA
  1 = UNIT PRICE
  2 = UNIT & TOTAL PRICE
  ENTER FORMAT: <0,1,2>0↓

SYSTEM ID:<XXXX>↓

AUTO PUMP DISABLE
  NO. OF ZERO QTY. TRANS. <1-99> 5↓

KEY EXPIRATION DATE
  ENABLE OR DISABLE? <E OR D> E↓

AUTO PIN LOCKOUT
  ENABLE OR DISABLE? <E OR D> E↓

AUTO SITE SHUT DOWN
  ENABLE OR DISABLE? <E OR D> D↓

TRANSACTION MPG
  ENABLE OR DISABLE? <E OR D> D↓
```

5. For FleetKey systems only, type **CT** to clear the key receptacle read and error table.

```
*CT
CLEAR KEY READ TOTALIZERS? <Y or N>: Y↓
*
```

6. Type **RT** to initialize the transaction file.

```
*RT
RESET TRANS FILE ? <Y OR N> Y↓
*
```

7. Type **LN** to load the starting transaction number into the system.

```
*LN
ENTER NO. : 0000↓
*
```

8. Type **LD** to load the date and time into the system.

```
*LD
YEAR: 96↓
MONTH: 1↓
DAY: 23↓
HOURS: 9↓
MINS: 30↓
*
```

9. Type **MO** if you have a CRT attached and wish to display output one screen at a time.

```
*MO
DISPLAY OUTPUT ONE SCREEN AT A TIME <Y OR N>: Y↓
*
```

10. For Card or Cardless systems only, type **LK** to load the 4-digit PIN key that is assigned to your system at the time of order. This is used in calculating PIN numbers.

```
*LK  
  
PIN KEY NO. 0015.↓  
*
```

*NOTE: The value shown is for example only. Use the PIN key assigned to your system. If you have a card system, the PIN key is listed on the card layout sheet attached to the Card Encoding Manual; cardless systems list the PIN key on the Field Information Form.*

11. For FleetKey systems only, type **WK** to load the 4-digit working key that is assigned to your system at the time of order. This is used in calculating PIN numbers.

```
*WK  
  
WORKING KEY NO. 0015.↓  
*
```

*NOTE: The value shown is for example only. Use the working key assigned to your system. The working key is listed on the key layout sheet provided with your system.*

12. Type **SD** to load the start and end times for site shut down. If you disabled the Auto Site Shut Down feature through the **SC** command, you can skip this step.

```
*SD  
  
SITE SHUT DOWN START TIME:  
HOURS: 23.↓  
MINS: 00.↓  
  
SITE SHUT DOWN END TIME:  
HOURS: 7.↓  
MINS: 00.↓  
*
```

13. Type **LI** to assign the initial inventory of each tank. For example, if Tank 2 currently contains 1700 gallons, the entries are:

```
*LI  
  
TANK #2↵  
AMOUNT: 1700↵  
  
TANK #↵  
*
```

14. Type **LR** to assign the inventory reorder point for each tank.

```
*LR  
  
TANK #2↵  
REORDER: 700↵  
  
TANK #↵  
*
```

15. Type **LP** to assign specific fuels, prices, tanks, totalizer readings, and timeouts to your pumps.

```
*LP  
  
PUMP NO. 1  
FUEL CODE: 1  
FUEL NAME: REGULAR  
PRICE $1.189  
TANK #1  
AMOUNT: 0  
BEFORE PUMP ACTIVATION TIME = 80  
AFTER PUMP ACTIVATION TIME = 80  
  
PUMP NO.↵  
*
```

**NOTES:** ***PRICE** may not appear if you selected 0 for price data format in the SC command.*

16. Type **LF** to assign the fuel codes to the proper authorization codes. For initial start-up, assign fuel codes to all authorization codes, beginning with code 1 and continuing through code 9.

```
*LF

AUTH NO. : 1↵
ALLOW: 03 26↵
ALLOW: 00 13↵
ALLOW: 02↵
ALLOW: 16↵
ALLOW: 00 01↵

AUTH NO. : 2↵
ALLOW: 01↵
ALLOW: 00 20↵
.
.
.
AUTH NO. : 9↵
ALLOW: 03↵
ALLOW: 00↵

AUTH NO. : ↵
*
```

17. Type **LL** to assign the maximum fuel quantities to the limitation codes. For initial start-up, assign quantities to all codes, beginning with Code 0 and continuing through Code 9.

```
*LL

CODE=1↵
MAX =25↵
.
.
.
CODE=9↵
MAX =100↵

CODE=↵
*
```

18. For cardless systems only, type **CV** to clear the vehicle file of any test data that may be present.

```
*CV
CLEAR VEHICLE FILE <Y OR N>: Y↵
*
```

19. For cardless systems only, type **LV** to load the vehicle records. You must load a record for each vehicle number you wish to be active.

```
*LV
VEH NO.: 0543↵
LIM. CODE: 2↵
AUTH CODE: 5↵
CHECK DIGIT: 1↵
VEH NO.:↵
*
```

*NOTE: Data shown is for example only. Enter your own data in response to the prompts.*

20. If you plan to use a *negative* card, key, or vehicle record file (validate all cards/keys/vehicle records and invalidate individual cards/keys/vehicle records), type **VA**.

```
*VA
VALIDATE ALL CARDS? <Y OR N> Y↵
*
```

*NOTE: The examples shown are for card systems. Your prompts will vary if you have a cardless or FleetKey system.*

21. If you plan to use a *positive* card, key, or vehicle record file (invalidate all cards/records and validate individual cards/keys/records), type **IA**.

```
*IA
INVALIDATE ALL CARDS? <Y OR N> Y↵
*
```

---

## CUSTOMER TRAINING

---

1. Explain to the terminal operator how the CRT terminal responds to commands. Review all relevant commands in the appropriate *Series 1000 Operation Manual*. Pay particular attention to **Card (or Key) Validation Commands** and **Polling Transaction Information**. For cardless systems, review **Record Validation Commands**.
2. See **Fueling with the Series 1000** in the appropriate *Operation Manual* and demonstrate how to dispense product with the Series 1000. If demonstrating a card or FleetKey system, use the customer's cards or keys, or, if none are available, use the demonstration cards or keys provided with the system.
3. Demonstrate how to clean the card reader, if applicable.

### For Magnetic Card Readers

- a. Use the GASBOY cleaning card. Order part number C08757 for a box of 50 cleaning cards.
- b. Insert the cleaning card with the fuzzy side facing down. Insert and remove the card several times.
- c. Turn the card around (fuzzy side still facing down) and insert and remove the card several times. By turning the card around you will utilize the entire cleaning area.
- d. Clean the card reader at least once a week. The frequency of cleaning required depends on the environment the system is in and how heavily it is used. Failure to clean the card reader regularly could result in premature failure.

### For Optical Card Readers

- a. Wrap a lint-free cloth (e.g., cheese cloth) around any optical card.
- b. Insert the card lengthwise and move it from side to side.



### 9. SYSTEM APPROVALS

Note any remarks or comments from the customer in the space provided.

Have a responsible contact person sign the Start-Up Form and sign it yourself. This indicates that the system has been accepted by the customer and the installation is approved by you.



## Section 13

# FINISH START-UP

1. Unlock and lower the rear door of the Series 1000 head assembly.
2. Move the Pulse Rate switch (located on backside of the microprocessor and accessed through a hole in the sheet metal) towards the front of the unit.
3. Close and lock the rear door.



At the top of page 2, after **Customer:**, write the customer's name. This is used as a reference in case the two forms become separated.

### 10. CUSTOMER KNOWLEDGE

Briefly describe the customer's understanding of the Series 1000 system.

### 11. PARTS USED

Fill in the Source of Parts Used section. Write down any parts used in the start-up of the system. Include the serial numbers of old and new parts and why the part was changed.

### 12. SITE LAYOUT

Sketch a layout of the site. Be sure to include the location of the system, hose outlets, data terminals, external modems, circuit breakers and wiring distances.

4. Generate a printout showing transactions with quantity, pump fuel assignments, limitation codes, authorization codes, and pulse rates/timeouts. Use the commands **PT**, **PP**, **PL**, **PF**, and **XP**). Include this printout with the Start-up form.
5. Turn over the keys for the system (and test cards or data keys) to the person in charge of the site.



Make a copy of the Start-up form for your records and send the form and the printout from Step 4 above to:

**GASBOY**  
Technical Service Department  
707 N. Valley Forge Rd.  
P.O. Box 309  
Lansdale, Pa 19446

# WARRANTY

## General Statements:

Gasboy International LLC. warrants all new equipment manufactured by Gasboy against defective material and/or workmanship, for the warranty period specified below, when the equipment is installed in accordance with specifications prepared by Gasboy.

This warranty does not cover damage caused by accident, abuse, Acts of God, lack of surveillance of automatic recording systems, negligence, mis-application, faulty installation, improper or unauthorized maintenance, installation or use in violation of product manuals, instructions, or warnings. Under no circumstance shall Gasboy be liable for any indirect, special, or consequential damages, losses, or expenses to include, but not limited to, loss of product, loss of profits, litigation fees, or the use, or inability to use, our product for any for any purpose whatsoever.

Parts Only - During the warranty period, Gasboy will, at its option, repair or replace defective parts returned transportation prepaid to its factory.

On-Site Labor Included - Gasboy will also provide, within the Continental United States and during the warranty period, the services of an Authorized Service Representative (ASR) for on-site repair or replacement of defective parts.

Replacement Parts - Any system components that are not part of the original system order, including Island Card Readers, Pump Control Units, etc., are considered replacement parts.

Equipment	Term	Coverage
Commercial Pumps and Dispensers Full-Cabinet Consumer Pumps	One year from date of installation or 18 mos. from date of Gasboy International's invoice to the purchaser, whichever comes first.	Parts and Labor.
Small Transfer Pumps, Meters, Pressure Regulators	One year from date of installation or 18 mos. from date of Gasboy International's invoice to the purchaser, whichever comes first.- Excepting the Model 2020 Hand Pump, which has a 90-day warranty from date of GASBOY International's invoice.	Parts Only.
Keytrol	One year from date of installation or 18 mos. from date of Gasboy International's invoice to the purchaser, whichever comes first.	Parts and Labor.
Fuel Management Systems: - CFN/ Profit Point - Series 1000/Fleetkey - TopKAT - Fuel Point Readers (sold with new systems)	One year from date of start-up or 15 mos. from date of Gasboy International's invoice to the purchaser, whichever comes first.- The basic warranty only applies to systems which have been started up by a Gasboy Authorized Service Representative (ASR).	Parts and Labor.
Additional Fuel Point Items: - Fuel Point Readers sold for retrofitting existing systems. - Fuel Point vehicle and dispenser components.	One year from date of start-up or 15 mos. from date of Gasboy International's invoice to the purchaser, whichever comes first.	Parts Only.
Encoders, Embossers, Modems, CRTs, and Logger Printers	Purchased with Fuel Management System (Encoders, Embossers only): 90 days from the date of start-up by a Gasboy ASR, or 180 days from date of Gasboy International's invoice, whichever occurs first.  Purchased with Fuel Management System (Modems, CRTs, and Logger Printers only): Matches system warranty.  Purchased Separately: 90 days from date of Gasboy International's invoice to the purchaser.	Purchased with System (Encoders, Embossers only): Parts only.  Purchased with System (Modems, CRTs, Logger Printers only): Matches system warranty.  Purchased Separately: Parts Only.
Air Diaphragm Pumps	Three years from date of purchase (for full warranty description, see Price List).	Parts Only.
Items not manufactured by Gasboy (ex. automatic nozzles, hoses, swivels, etc.)	Not warranted by Gasboy International (consult original manufacturer's warranty).	Not Applicable.
Replacement Parts	One year from date of Gasboy International's invoice to the purchaser.	Parts Only.

To the extent permitted by law, this warranty is made in lieu of all other warranties, expressed or implied, including warranties of freedom from patent infringement, or merchantability, or fitness for a particular purpose, or arising from a course of dealing or usage of trade. No one is authorized to vary the terms of the warranty nor may anyone make any warranty of representation, or assume any liability other than that herein stated, in connection with the sale described herein. The acceptance of any order by Gasboy International is expressly made subject to the purchaser's agreement to these conditions.



**GASBOY INTERNATIONAL LLC**

P.O. Box 309, Lansdale, PA 19446 ● (800) 444-5579 ● FAX: (800) 444-5569 ● [www.gasboy.com](http://www.gasboy.com)

# GASBOY SERIES 1000 START-UP FORM

## 1. SITE IDENTIFICATION

Customer \_\_\_\_\_ Date: \_\_\_\_\_  
 Location: \_\_\_\_\_ Distributor: \_\_\_\_\_  
 \_\_\_\_\_ Distributor Phone No: \_\_\_\_\_  
 Contact: \_\_\_\_\_ Start-Up Person: \_\_\_\_\_  
 Customer Phone No: \_\_\_\_\_ Installer: \_\_\_\_\_

## 2. PUMPS/DISPENSERS

Hose #	Fuel Type	Fuel Code	Pump Make	Pump Model #	Pump Serial #	Motor Size	Pump Type	Starter Relay	Pulser Rate
1	_____	_____	_____	_____	_____	_____	Sub/Suc	Y/N	_____:1
2	_____	_____	_____	_____	_____	_____	Sub/Suc	Y/N	_____:1
3	_____	_____	_____	_____	_____	_____	Sub/Suc	Y/N	_____:1
4	_____	_____	_____	_____	_____	_____	Sub/Suc	Y/N	_____:1
5	_____	_____	_____	_____	_____	_____	Sub/Suc	Y/N	_____:1
6	_____	_____	_____	_____	_____	_____	Sub/Suc	Y/N	_____:1
7	_____	_____	_____	_____	_____	_____	Sub/Suc	Y/N	_____:1
8	_____	_____	_____	_____	_____	_____	Sub/Suc	Y/N	_____:1

## 3. COMMUNICATION

Data Terminal: \_\_\_\_\_ Port 1 - RS232/422 \_\_\_\_\_ baud  
 External Modem: \_\_\_\_\_ Port 2 - RS232/422/Int. Modem \_\_\_\_\_ baud  
 Modem Phone No: \_\_\_\_\_ Aux. Port 1 - RS232/422 \_\_\_\_\_ baud

## 4. BREAKERS

Series 1000 System: _____	Breaker # _____	Hose Outlet #1: _____	Breaker # _____	Hose Outlet #5: _____
Data Terminal: _____	_____	Hose Outlet #2: _____	_____	Hose Outlet #6: _____
External Modem: _____	_____	Hose Outlet #3: _____	_____	Hose Outlet #7: _____
FPR: _____	_____	Hose Outlet #4: _____	_____	Hose Outlet #8: _____

## 5. CONDUIT

All Metal Conduit: Y/N \_\_\_\_\_ Communication Wires: Separate/DC/AC conduit  
 AC and DC in Separate Conduits: Y/N \_\_\_\_\_ Wiring Neatness: Good/Fair/Poor/Bad

## 6. SYSTEM IDENTIFICATION

System Serial #: \_\_\_\_\_ Program Name/Date: \_\_\_\_\_  
 FPR Serial #: \_\_\_\_\_

## 7. SYSTEM POWER

Hot to Neutral \_\_\_\_\_ VAC      Hot to Ground \_\_\_\_\_ VAC      Neutral to Ground \_\_\_\_\_ VAC  
 Grounding Method: \_\_\_\_\_

## 8. DC POWER

System: +5VDC: \_\_\_\_\_.\_\_\_\_ +12VDC: \_\_\_\_\_.\_\_\_\_ -5VDC: \_\_\_\_\_.\_\_\_\_ -12VDC: \_\_\_\_\_.\_\_\_\_  
 FPR: +5VDC: \_\_\_\_\_.\_\_\_\_

## 9. SYSTEM APPROVALS

I am satisfied with the installation of the Series 1000 System and have been trained in its use and operation.

_____ Customer Signature	_____ Date	_____ Start-Up Tech Signature	_____ Date
-----------------------------	---------------	----------------------------------	---------------

Please supply any additional customer comments in the space below:

---

---

---

**10. CUSTOMER KNOWLEDGE**

---

---

---

---

---

**11. SITE LAYOUT (Include wiring distances):**