DL4 Console

Installation and Setup Manual



Veeder-Root makes no warranty of any kind with regard to this publication, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

Veeder-Root shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this publication.

Veeder-Root reserves the right to change system options or features, or the information contained in this publication.

This publication contains proprietary information which is protected by copyright. All rights reserved. No part of this publication may be photocopied, reproduced, or translated to another language without the prior written consent of Veeder-Root.

Contact TLS Systems Technical Support for additional troubleshooting information at 800-323-1799.

DAMAGE CLAIMS / LOST EQUIPMENT

Thoroughly examine all components and units as soon as they are received. If any cartons are damaged or missing, write a complete and detailed description of the damage or shortage on the face of the freight bill. The carrier's agent must verify the inspection and sign the description. Refuse only the damaged product, not the entire shipment.

Veeder-Root must be notified of any damages and/or shortages within 30 days of receipt of the shipment, as stated in our Terms and Conditions.

VEEDER-ROOT'S PREFERRED CARRIER

- 1. Contact Veeder-Root Customer Service at 800-873-3313 with the specific part numbers and quantities that were missing or received damaged.
- 2. Fax signed Bill of Lading (BOL) to Veeder-Root Customer Service at 800-234-5350.
- 3. Veeder-Root will file the claim with the carrier and replace the damaged/missing product at no charge to the customer. Customer Service will work with production facility to have the replacement product shipped as soon as possible.

CUSTOMER'S PREFERRED CARRIER

- 1. It is the customer's responsibility to file a claim with their carrier.
- 2. Customer may submit a replacement purchase order. Customer is responsible for all charges and freight associated with replacement order. Customer Service will work with production facility to have the replacement product shipped as soon as possible.
- 3. If "lost" equipment is delivered at a later date and is not needed, Veeder-Root will allow a Return to Stock without a restocking fee.
- 4. Veeder-Root will NOT be responsible for any compensation when a customer chooses their own carrier.

RETURN SHIPPING

For the parts return procedure, please follow the appropriate instructions in the "General Returned Goods Policy" pages in the "Policies and Literature" section of the Veeder-Root North American Environmental Products price list. Veeder-Root will not accept any return product without a Return Goods Authorization (RGA) number clearly printed on the outside of the package.

Contractor Contribution requiremente
Related Documents1
Documents Required to Install Equipment1
Safety Precautions2
National Electrical Code Compliance3
Power Wiring3
DI 4 Dimensions and Component Locations
Dimensions
Component Locations
Console Specifications and Features
Console Specifications and Features7
Console Specifications and Features
Console Specifications and Features
Console Specifications and Features
Console Specifications and Features7 Console Installation8 Connecting AC Power Wiring to the DL49
Console Specifications and Features7 Console Installation8 Connecting AC Power Wiring to the DL49
Console Specifications and Features7 Console Installation8 Connecting AC Power Wiring to the DL49
Console Specifications and Features7 Console Installation8 Connecting AC Power Wiring to the DL49 Initial Startup Procedure10

Configuring DL4 for Site Monitoring and Data Transmission

BIR Protocol DIM11
POS System Requirements and Limitations11
DL4 Site Connection and Initialization11

Figures

Introduction

Figure 1.	DL4 Console - Dimensions	4
Figure 2.	Bottom Panel Communication Connectors	5
Figure 3.	Component Locations with Cover Removed	5
Figure 4.	Component Locations - Underside of Display Holder/CPU Board A	ssembly6
Figure 5.	Wiring AC Power to the DL4 Console	9
Figure 6.	Configuring LAN	
Figure 7.	Local Area Connection 'X' Properties dialog box selections	
Figure 8.	Internet Protocol Version 4 (TCP/IPv4) Properties dialog box selec	tions 13
Figure 9.	Ethernet Port Setup	15
Figure 10.	Switching between Data Logger Applications	15
Figure 11.	Serial Port Setup, SERIAL 1 - ATG	
Figure 12.	Serial Port Setup, SERIAL 2- POS	
Figure 13.	Entering ATG Command	17
Figure 14.	Deleting ATG Command	
Figure 15.	TDIM Setup	
Figure 16.	Entering Host name	
Figure 17.	Verifying DIM Communication	19
Figure 18.	Entering Date and Time	19
Figure 19.	Selecting System Units	19
Figure 20.	Switching to DL Setup	
Figure 21.	Example Environmental Configuration Page Settings - Scenario 1	21

Example Environmental Configuration Page Settings - Scenario 2	21
Example Environmental Configuration Page Settings - Scenario 3	
Example FMS ID Entry	
Inventory Command Results	
POS Protocol Type Query	
POS Protocol Type Results	
FMS Heartbeat Screen	
	Example Environmental Configuration Page Settings - Scenario 2 Example Environmental Configuration Page Settings - Scenario 3 Example FMS ID Entry Inventory Command Results POS Protocol Type Query POS Protocol Type Results FMS Heartbeat Screen

Tables

Table 1. DL4 Console Specifications and Features	7
Table 2. POS Systems Using V-R Protocol	11
Table 3. DL4 User Interface Screens	14

Introduction

This manual assumes that you are installing the DL4 Console in a site predetermined to have a compatible tank gauge and point of sale system as well as connectivity to the Fuel Management Service. Among the topics covered are:

- Introduction and safety precautions
- · Console dimensions and component locations
- Console specifications and features
- Console installation
- Connecting AC power wiring to the console
- Initial startup procedure
- Configuring the DL4 for site monitoring and data transmission

Contractor Certification Requirements

Veeder-Root requires the following minimum training certifications for contractors who will install and setup the equipment discussed in this manual:

Installer (Level 1) Certification: Contractors holding valid Installer Certification are approved to perform wiring and conduit routing; equipment mounting; probe, sensor and carbon canister vapor polisher installation; wireless equipment installation; tank and line preparation; and line leak detector installation.

ATG Technician (Level 2/3 or 4) Certification: Contractors holding valid ATG Technician Certifications are approved to perform installation checkout, startup, programming and operations training, system tests, troubleshooting and servicing for all Veeder-Root Series Tank Monitoring Systems, including Line Leak Detection. In addition, Contractors with the following sub-certification designations are approved to perform installation checkout, startup, programming, system tests, troubleshooting, service techniques and operations training on the designated system.

- Wireless 2
- Tall Tank

Warranty Registrations may only be submitted by selected Distributors.

Related Documents

DOCUMENTS REQUIRED TO INSTALL EQUIPMENT

To install intrinsically safe apparatus, use the specific control drawing that appears on the nameplate of the applicable associated apparatus (DL4 Console).

Associated Apparatus	UL/cUL Control Drawing Document No.	ATEX Descriptive System Document No.	IECEx Descriptive System Document No.
8601 (DL4)	331940-018	331940-017	331940-117

Control drawings can be found on the accompanying Compact Disk (TECH DOCS CD) or on the internet at veeder.com under SUPPORT; VR TECHNICAL DOCUMENTS; DRAWINGS.

Safety Precautions

The following safety symbols may be used throughout this manual to alert you to important safety hazards and precautions.

Ø	EXPLOSIVE Fuels and their vapors are extremely explosive if ignited.	FLAMMABLE Fuels and their vapors are extremely flamma- ble.
(F)	ELECTRICITY High voltage exists in, and is supplied to, the device. A potential shock haz- ard exists.	TURN ELECTICAL POWER OFF Live power to a device creates a potential shock hazard. Turn Off electrical power to the device and associated accessories when ser- vicing the unit.
	WARNING Heed the adjacent instructions to avoid damage to equipment, prop- erty, environment or personal injury.	WEAR EYE PROTECTION Wear eye protection when working with pres- surized fuel lines or epoxy sealant to avoid possible eye injury.
	GLOVES Wear gloves to protect hands from irritation or injury.	INJURY Careless or improper handling of materials can result in bodily injury.
	READ ALL RELATED MANUALS Knowledge of all related procedures before you begin work is important. Read and understand all manuals thoroughly. If you do not understand a procedure, ask someone who does.	STATIC SENSITIVE COMPONENTS Wear grounded anti-static wrist strap before handling the printed circuit boards and mounted components.

 FAILURE TO COMPLY WITH THE FOLLOWING WARNINGS AND SAFETY PRECAUTIONS COULD CAUSE DAMAGE TO PROPERTY, ENVIRONMENT, RESULTING IN SERIOUS INJURY OR DEATH.
 Explosive vapors or flammable liquids could be present near locations where fuels are stored or being dispensed.
 For use with intrinsically safe devices in Class I, Group D and Class I, Zone 0, Group IIA hazardous locations when installed in accordance with the installation manual and applicable Control Drawing.
 This console is not explosion proof. Do not install this console in a volatile, combustible, or explosive atmosphere.
 An explosion or fire resulting in serious injury or death, property loss and equipment damage could occur if the console is installed in a volatile, combustible or explosive atmosphere (Class I, Division 1 or 2) or (Group IIA, Zone 0).

National Electrical Code Compliance

The following information is for general reference and is not intended to replace recommended National Electric Code (NEC) procedures. It is important for the installer to understand that electrical equipment and wiring located in Class I, Division 1 and 2 installations shall comply with the latest appropriate Articles found in the National Electric Code (NFPA 70) and the Code for Motor Fuel Dispensing Facilities and Repair Garages, (NFPA 30A).

POWER WIRING

Wires carrying 120 or 240 Vac from the power panel to the console should be #14 AWG (or larger) copper wire for line, neutral and chassis ground (3). Use one 4 sq. mm (#10 AWG) minimum wire for barrier ground.

DL4 Dimensions and Component Locations

Dimensions

Figure 1 illustrates the DL4 Console's dimensions.



Figure 1. DL4 Console - Dimensions

Component Locations

Figure 2 illustrates the communication ports of the DL4. Figure 3 shows component locations and console mounting holes with cover removed.



Figure 2. Bottom Panel Communication Connectors



Figure 3. Component Locations with Cover Removed

Figure 4 shows component locations on underside of display holder panel/CPU board assembly. To remove this assembly, remove the two T15 screws securing the assembly, slide the assembly up as far as it will go and lift the assembly out. Disconnect the attached ribbon cable and wire cable to completely remove the assembly.

If necessary to remove the CPU board assembly to replace the SD card or iButton, avoid touching other electronic components on the underside of the CPU board as static electricity may damage them. Wear grounding strap when handling CPU board.



Underside of display holder panel /CPU board ass'y.

Figure 4. Component Locations - Underside of Display Holder/CPU Board Assembly

Console Specifications and Features

The DL4 console specifications and features are shown in Table 1.

Feature	Description				
Front panel Indicators	3 LED status indicators - The Power (Check) green LED is on when applications are running, flashing when applications are starting, and off when no apps running/no power to DL4. The Warning (!) yellow LED is flashing when a warning condition is active. The Red (X) LED is on when an alarm is active.				
Input Power	Universal AC power supply:100 to 249Vac, 50/60Hz, 2A maximum				
RS-232 Ports	2 optically isolated serial ports standard, labeled SERIAL 1 supporting full handshaking and SERIAL 2. The RS-232 D-connector is a panel mount, 9-pin female type, wired in a Data Terminal Equipment (DTE) configuration. The system does not require or activate any handshake signals.				
	SERIAL 1				
	Pin Signal Pin Signal 1 Data Carrier Detect 6 Data Set Ready 2 Received Data 7 Request to Send 3 Transmitted Data 8 Clear to Send 4 Data Terminal Ready 9 Ring Indicator				
	SERIAL 2 6 7 8 9				
	Pin Signal 1 6 2 Received Data 3 Transmitted Data 4 9 5 Signal Ground				
USB Ports	2 powered USB ports, labeled USB 1 and USB 2				
Ethernet 1 Port	10/100 Ethernet port. TCP/IP, labeled ETH 1				
Ethernet 2/3 Ports	Labeled ETH 2 and ETH 3 (Not Used)				

Table 1. DL4 Console Specifications and Features

Console Installation

Select an indoor mounting location where you have access to the POS and ATG for connection to the DL4. The console must be protected from severe vibration, extremes in temperature and humidity, rain, and other conditions that could harm computerized electronic equipment. The console's operating temperature range is 32 to 104°F (0 to 40°C), and its storage temperature range is -40 to +162°F (-40 to +74°C).

The mounting surface should be strong enough to support the console's weight of 4 pounds (1.81kg). You should also consider wall space for routing the power wiring conduit and communication cables that must be connected to the console.

To mount the console, remove the two T15 screws in the bottom of the cover (see Figure 1). As you lift up the bottom of the cover it pivots on two tabs that project from the top of the console's chassis into slots in the top of the cover. Lift the cover off the chassis tabs and set it aside. Notice the two 0.28" (7.1mm) diameter mounting holes in the base of the chassis at the left top and right bottom corners (see Figure 3). Locate the chassis on the wall in the desired mounting location, mark the hole locations, drill appropriate pilot holes; and using 1/4-inch (6mm) maximum fasteners (customer supplied), attach the chassis to the mounting surface.

Connecting AC Power Wiring to the DL4

Check the Input Power Rating on the label affixed to the underside of the DL4 console to verify input power requirements.



- 1. Pull four wires between the power panel and the console; three #14 AWG or larger color-coded wires for AC line (hot), AC neutral and chassis ground and one 4 sq. mm (#10 AWG) minimum wire for barrier ground.
- 2. Connect the input 120 or 240 Vac power wires as shown in Figure 5.



Figure 5. Wiring AC Power to the DL4 Console

Initial Startup Procedure

Once the communication devices, etc., are connected to the console, remove and discard the backup battery isolator strip (see Figure 5).

Replace the front cover. Attach a label to the breaker feeding the console. This allows others to know how to disconnect power to the console when servicing the system. Communicate to facility personnel which breaker feeds the console.

Switch the dedicated circuit breaker ON to apply power to the console.

Configuring DL4 for Site Monitoring and Data Transmission

BIR Protocol DIM

POS SYSTEM REQUIREMENTS AND LIMITATIONS

For sites using the DL4 DIM, the Point of Sales (POS) system must conform to established Veeder-Root protocol and allow the DL4 to collect the metered sales data necessary for it to perform its Business Inventory Reconciliation (BIR) and Wet Stock Management (WSM) tasks. This protocol is separate and distinct from the inventory protocol commonly used by POS and other systems to collect inventory data from Veeder-Root TLS consoles.

The following POS systems are known to have implemented the Veeder-Root protocol and thus support BIR protocol DIM (Dispenser Interface Module).

Forecourt Controller	Protocol Name	TLS-350R	TLS-450
Allied	Station Site Controller (SSC)	Х	Х
Gilbarco	T-4 (Australia)	х	
PEC	8850	Х	
POSTEC	RCC	х	
Wayne	Marketer 2000 (Sweden)	х	

Table 2. POS Systems Using V-R Protocol*

*When the proper hardware/software combinations are used.

DL4 Site Connection and Initialization

After you are connected the DL4 to the appropriate site equipment follow the steps below to setup the DL4.

NOTE: You must wait at least 5 minutes after powering on the DL4 before starting this procedure.

- 1. Using an ethernet crossover cable, connect a laptop PC to ethernet port ETH 1 on the DL4 (see Figure 2).
- 2. You must configure the laptop's wired integrated Local Area Network by clicking on the Windows Globe in the lower right of the task bar, and typing in network connections in the 'Search programs and files' field and then pressing Enter (see below):

click 📀 —►		→ Press Enter
	type: network connections	

3. NOTE: The screen shots contained in this manual are for reference purposes only. The actual settings and data shown in the following examples are dependent on the laptop or PC operating system used to configure this hardware.

In the Network Connections screen, double click on the wired (not wireless) integrated Local Area Connection. In the example below (Figure 6), you would double-click Local Area Connection 2.

🕞 🕞 🔹 Control Panel 🕨 Network and Int	ernet 🕨 Network Connections 🕨		•
File Edit View Tools Advanced Help			
Organize Disable this network device Di	agnose this connection Rename th	is connection Change settings of this connection	
Name	Status	Device Name	Connectivity
💭 Local Area Connection	Network cable unplugged	Realtek PCIe GBE Family Controller	
💭 Local Area Connection 2	Network cable unplugged	Intel(R) Centrino(R) WiMAX 6150	
Local Area Connection 3	Enabled	Cisco Systems VPN Adapter for 64-bit Windows	
VPN Connection	Disconnected	WAN Miniport (IKEv2)	
aff. Wireless Network Connection	D1LR1	Intel(R) Centrino(R) Wireless-N 6150	Internet access
بِتِلْأَا Wireless Network Connection 2	Not connected	Microsoft Virtual WiFi Miniport Adapter	
🛒 🛙 Wireless Network Connection 3	Not connected	Microsoft Virtual WiFi Miniport Adapter #2	

Figure 6. Configuring LAN

4. When the selected Local Area Connection Properties dialog box opens make the selection shown in Figure 7.



Figure 7. Local Area Connection 'X' Properties dialog box selections

5. When the Internet Protocol Version 4 (TCP/IPv4) Properties dialog box opens make the selections shown in Figure 8.



Figure 8. Internet Protocol Version 4 (TCP/IPv4) Properties dialog box selections

6. On the laptop, open an internet browser and enter the IP address **https://169.254.21.12/GeneralSetup** in the browser's address bar. When the login page displays, enter 'guest' for both User name and Password.

NOTE: The DL4 simultaneously runs two applications; one programs the general communication protocols (GeneralSetup), and the other programs how the DL4 gathers its information (DLSetup). Pressing the blue arrow at the top middle of the screen will toggle you between the two programs (see Figure 9). After entering selections/changes to fields on any page, click the Save button to save your entries, or Cancel to discard them. Programming screens used to setup the DL4 are listed in Table 3.

Genera Applicati	alSetup on Pages	See Example	DLS Applicati	etup on Pages	See Example
	Ethernet Port Setup	Step 7.		Communication	Step 18.
	Serial Port Setup	Step 8.	System Setup	FMS Identification	Step 19.
Communication Setup	CDIM Setup	Diag. use only		ATG Commands	Step 13.
	TDIM Setup	Step 12.		DIM Commands	Step 13.
	Site Id Server Setup	Diag. use only		FMS Heartbeat	Step 22.
	Hostname	Step 13.	Communication Testing	ATG	Step 20.
Sustan Satur	Date and Time	Step 15.	Ű.	POS	Step 21.
System Setup	Units	Step 16.		DIM	Diag. use only
	Alarm Filtering	Diag. use only			
	DIM Communica- tions	Step 14.			
Diagnostics	Ping				
	Traceroute				
	DB Backup				
	DB Restore	Diag use only			
Software Mainte- nance	Download New Version	Diag. use only			
	Activate/Revert				
	Upgrade Fea- tures				

Table 3. DL4 User Interface Screens

7. On the "Communication Setup" page (see Figure 9), click on "Ethernet Port Setup" (1) and select the Device type "ETH 1" (2) from the drop-down menu. In the IP Address Type field (3):

If the site is using a static IP address, select "Static IP"; and enter the IP address assigned by your network administrator. Once this is complete, click the "Save" button to keep these settings (see example in Figure 9).

If the site is using a dynamic IP address, select "Dynamic IP" (the remaining parameters will auto-fill once the DL4 is reconnected to the site network). Click "Save" (4) to accept your entries.

NOTE: If you receive an error message after clicking "Save", click "OK" and refresh the page.



Figure 9. Ethernet Port Setup

8. On the "Communication Setup" page, select "Serial Port" setup and for "Device" select "SERIAL 1" (see Figure 10).

	Firefox 🔻	+			
	10.20.95.33 https://10.20.95.	33/GeneralSetup/#Screen2		🏫 ⊽ 😋 🚼 ▾ Google	۹
2	Most Visited 🗌 Getting Started				🔝 Bookmarks
	🚫 VEEDER-ROOT	V004.X.201.1	2012-02-26 05:22		veeder Log Out
	Main Menu 🕠 Home	Communication Setup . Se	rial Port Setup		🕒 Print
	Communication Setup	Device: Select Device -	Click the down a	arrow and select S	FRIAL 1
	Ethernet Port Setup				
Select —	② Serial Port Setup				
	CDIM Setup				
	UIM Setup				

Figure 10. Switching between Data Logger Applications

9. Use this port (SERIAL 1) for the connection to the ATG, and enter "ATG" for the Label. Set the correct communications parameters for the ATG using the drop down menus. For HandShaking, select "No Hand Shaking". Click the "Save" button to keep these settings (see example in Figure 11).

VEEDER-ROOT	V004.X.201.1	2012-02-26 04:35	veeder	Log Out
Main Menu 🕢 Home	Communication Setup - Serial	Port Setup		() Print
Communication Setup	Device: SERIAL 1:ATG -			
Ethernet Port Setup	General			
② Serial Port Setup	Card Type:	PS 232 -		
CDIM Setup	Card Type:	110 232		
B TDIM Setup	Label:	ATG 🛈		
	Baudrate:	9600 -	Recommended Baudrate	
	Stop Bits:	One 🔻		
	Byte Size:	Seven -		
	Parity:	Even -		
	Other			
	HandShaking:	No Hand Shaking 🔻	— Select No	
			Cancel	Save

Figure 11. Serial Port Setup, SERIAL 1 - ATG

10. Still on the Serial Port Setup page, in the "Device" field, select "SERIAL 2". Use this connection for the connection to the POS, and enter "POS" for the Label. Set the correct communications parameters for the POS using the drop down menus. For HandShaking, select "No Hand Shaking".Click the "Save" button to keep these settings (see example in Figure 12).

TLS-450 Web Interface	+			~
10.20.95.33 https://10.20.9	5.33/GeneralSetup/#Screen2		☆ マ C 🚼 र Google	۶ 🏫
Most Visited 🗌 Getting Started				🔝 Bookmark
🚫 VEEDER-ROOT	V004.X.201.1	2012-02-26 04:36		veeder Log Out
Main Menu 🙆 Home	Communication Setup - Serial	Port Setup		🕒 Print
Communication Setup	Device: SERIAL 2:POS -			
Ethernet Port Setup	General			
③ Serial Port Setup	Card Type:	RS 232 👻		
CDIM Setup	Label:	POS		
IDIM Setup	Baudrate:	9600 - Re	commended Baudrat	te
	Stop Bits:	One 💌		
	Byte Size:	Seven -		
	Parity:	Even -		
	Other			
	HandShaking:	No Hand Shaking 👻 🗲	– Select No	

Figure 12. Serial Port Setup, SERIAL 2- POS

11. If the DL4 is not connected to the POS, perform this step. If the DL4 is connected to the POS, skip to step 12.

Go to the "DLSetup" application by clicking on white arrow in blue circle top center of screen (see Figure 10), and under "System Setup", click on "ATG Commands (1 in Figure 13)". Then click on the "+ Add New Command" text at top right of screen (2 in figure). When the Add Command dialog box appears enter the command "i@C300", add the Description "DIM_EVENTS", set the Repeat Interval to "60" (3 in figure) and click Save (4 in figure).

	VEEDER-ROOT	V004.X.201.1	L	2011-10-	27 01:25		veeder Log O
	Main Menu 🕢 Home	System Set	up ► ATG Comma	nds			🖨 Pri
	System Setup					2	Add Now Command
	Communication		-				Add New Command
	⑦ FMS Identification	Command	Add Command		2	K	
1 —	ATG Commands	i20100	Command:	i@C300	١		Ø 🕤
	DIM Commands	i11300	Description:	DIM_EVENTS	(i)	_ 3	Ø
		i@5500	Repeat Interval:	60	i		0 6
					Reset Save		
					↑		
					4		

Figure 13. Entering ATG Command

Click on the DIM Command page and then click on the trash can icon on the right end of the i@C300 command line to delete the i@C300 command (see Figure 14). Jump back to the "GeneralSetup" application by clicking on arrow top center of screen.



Figure 14. Deleting ATG Command

12. If the DL4 is connected to the POS, perform this step

Select "TDIM" set-up. Select "TDIM (ETH1)" from the drop-down menu. On the "TDIM Enable" drop down, select "TRUE" and type in a label (maximum of 20 characters). Then select the DIM protocol being used and click "Save". Accept the default Listen Port (unless there is a conflict with another device) and select the desired units (see example in Figure 15). Once this is complete, click on "Save" to keep these settings.



Figure 15. TDIM Setup

13. Select the "System Setup" page and type in the Host name and then click the "Save" button (see example in Figure 16). It is recommended that you use the network name assigned by the network administrator or some other name that identifies the location. While on this page click the Diagnostic Page link (bottom Left).



Figure 16. Entering Host name

14. In the "Diagnostics" page (lower left in above figure), click on "DIM Communications" to verify that the DIM communications are successfully being recorded by the DL4. Any transactions occurring after the DL4 was configured will be shown on the screen (see example in Figure 17).

	ĺ	F	irefox 🔻						
		10	TLS-450 Web Interface	+					2
	ск раск —	• (•) []] 10.20.95.33 https://.	10.20.95.33/GeneralSetup/#Screen6				☆ マ C 🚼 - Google	۹ م
arr	ow to return	0	Most Visited 💮 Getting St	arted					🔝 Bookmar
to	System Set-		🔘 VEEDER-ROO	T V004.X.201.1	0	2012-02	-26 10:34		veeder Log Out
up	screen		Main Menu	Home Diagnostics > DIM	Communications	6			Print
			Communication Setu	IP					🔇 Refresh
			System Setup	Date / Time	Fuel Position	Meter	User FP	Event Type	Transaction Volume
			Diagnostics	2012-02-26 10:34	8	0	0	Start	0.0000
			BIM Communic	ations 2012-02-26 10:34	7	0	0	Start	0.0000
	Select —		Ping	2012-02-26 10:33	1	1	0	End	2.4700
			Traceroute	2012-02-26 10:33	5	0	0	Start	0.0000
				2012-02-26 10:33	16	1	0	End	9.1400
				2012-02-26 10:33	15	0	0	Start	0.0000
				2012-02-26 10:33	12	1	0	End	5.1600
				2012-02-26 10:33	14	0	0	Start	0.0000
				2012-02-26 10:33	11	1	0	End	4.6800
				2012-02-26 10:33	9	1	0	End	4.6800

Figure 17. Verifying DIM Communication

15. From the System Setup menu, select Date and Time link to access the current date/time entry screen (see example in Figure 18).



Figure 18. Entering Date and Time

16. From the System Setup menu, click on the Units page(1), select the desired units (2), click Save (3) (see example in Figure 19).



Figure 19. Selecting System Units

17. Click on arrow just to the left of the date to switch to DLSetup application (see Figure 20).

		ſ	—— Cli	ick on this a	arrow icon to	jump to DLS	etu
Firefox TLS-450 Web Interface	+						×
(10.20.95.33 https://10.20.9	5.33/GeneralSetup/#Screen6		_		☆ マ C 🛃 - Google	٩	
Most Visited C Getting Started						Book	cmarks
VEEDER-ROOT	V004.X.201.1	C	2012-0	2-26 10:34		veeder Log Ou	<u>ıt</u>
Main Menu 🙆 Home	Diagnostics . DIM	I Communication	ns	😑 Prin	() Print		
Communication Setup						(Refrest	h
System Setup	Date / Time	Fuel Position	Meter	User FP	Event Type	Transaction Volume	
Diagnostics	2012-02-26 10:34	8	0	0	Start	0.0000	
DIM Communication	2012-02-26 10:34	7	0	0	Start	0.0000	
Ping	2012-02-26 10:33	1	1	0	End	2.4700	
							_

Figure 20. Switching to DL Setup

- 18. On the DLSetup "Communication" page, under "Environment Configuration" there are three possible configurations:
 - Scenario 1 POS connects to ATG (w/DIM), DL4 polls for transactions and inventory from ATG.



• Scenario 2 - POS connects to DL4 and passes transactions through to ATG (w/DIM).



• Scenario 3 - POS connects to DL4 (w/DIM), but transactions do not pass through to ATG (w/o DIM)..



Based on the ATG type at the site and whether it has an available RS232 port, determine which Scenario will be used. To simplify the installation, it is preferable to use Scenario 1 whenever the ATG has a spare RS232 port available.

Scenario 1 - make the selections shown below if the POS is connected to the ATG, and the ATG is providing the DIM function and the DL4 is connected to a spare RS232 port on the ATG (see example in Figure 21). NOTE: VR Protocol is pre-selected and cannot be changed (currently it is the only supported protocol).

$\epsilon \rightarrow \epsilon$	C 🖹 https://10.20.95.33/D	LSetup/#Screen1	公 💽 🕚
😒 7-Day F	precast for L 🛞 Chip It! 🖲 1	'he New York Time 🐻 Business News & Fi 🚫 Log In 🔣 Litchfield County C 🟦 TCM Turner Classic 🏾 🔭 🗋	Other bookma
× 🛛 - [Search Safe Web - 🕐 Identity Safe -	
	VEEDER-ROOT	DL4 V004-001.aX.200.10 S/31/12 5:52 PM vruser Loc	Out
	Main Menu O Home	System Setup - Communication	Print
	System Setup	Environment Configuration	
	(Communication		Scenar
	⑦ FMS Identification	POS R5232 ATG (DIM)	
	ATG Commands		
	DIM Commands	Data Logger	
		ATG Configuration	
		Port: Serial Port 1: (Card Type RS 232)	
		ATG Type: TLS 350 R 🗨 — Example ATG type has DIM	
		ATG Protocol: VR 🗸 🗸 VR	
		POS Configuration	

Figure 21. Example Environmental Configuration Page Settings - Scenario 1

Scenario 2 - Make the selections shown below if the DL4 is connected between the POS and the ATG, and the ATG is providing the DIM function, and select applicable ATG (see example in Figure 22). NOTE: VR Protocol is pre-selected and cannot be changed (currently it is the only supported protocol).

ile Edit View Favorites Tools	Help
🔘 VEEDER-ROOT	DL4 V004-001.aX.200.10 S/21/12 6:33 AM guest Log Out
Main Menu O Home	System Setup + Communication
System Setup	Environment Configuration
(1) Communication	ATG Mode: External ATG - External (default) SCENARIO 2 SCENARIO
(2) FMS Identification	POS ATG (DIM)
ATG Commands	POS Mode: Pass-tirrough Enabled
DIM Commands	Pass through enabled $TIS-4$
	ATG Configuration
	Port: Serial Port 1: ATG (Card Type RS 232) 💌
	ATG Type: TLS 350 R - Select ATG type with DIM
	ATG Protocol: VR 💌
	POS Configuration
Select port cor	nected to POS
	Cancel Save

Figure 22. Example Environmental Configuration Page Settings - Scenario 2

Scenario 3 - Make the selections shown below if the DL4 is providing the DIM function. Verify that the connections between the POS, DL4 and ATG are consistent with the scenario illustration shown on the upper right-hand side of the screen. Note: the illustration requires a few seconds to update after you make a change to the screen selections (see example settings in Figure 23). Note: TDIM setup in GeneralSetup must e completed first (ref. Step 12).

File Edit View Favorites Too	is Help	
🚫 VEEDER-ROOT	DL4 V004-001.aX.200.10 O 6/4/12 1:56 PM Vrus	ser Log Out
Main Menu 🗿 Home	System Setup + Communication	Print
System Setup (a) Communication	ATG Mode: External ATG - External (default)	— Scénario 3
⑦ FMS Identification	POS Mode: Pass-through Disabled	
ATG Commands	Pass-through Disabled	2 / net
DIM Commands	ATG Configuration	
	Port: Serial Port 1: ATG (Card Type RS 232)	
	ATG Type: TLS 350 🗨 Select ATG type	E
	ATG Protocol: VR -	
	POS Configuration	
Salact part on	Post Configuration	

Figure 23. Example Environmental Configuration Page Settings - Scenario 3

Under "ATG Configuration", select the port that is connected to the ATG on the "Port" drop down menu. Then select the "ATG type" that the DL4 is connected to from the drop down menu. ATG Protocol current only allows "VR" so this selection cannot be changed. Under "POS Configuration", select the port that is connected to the POS on the "Port" drop down menu. Once you have completed these selections for the installation scenario, click the "Save" button to keep these settings.

19. Select the "FMS Identification" screen and enter the six-digit FMS site identification number. Then click on the "Save" button (see Figure 24).



Figure 24. Example FMS ID Entry

20. Wait at least 30 seconds from the completion of the previous step to allow for the system to re-initialize with the new settings. Then click on the "Communication Testing" link at the lower left bottom of the System Setup column (see above figure), then click on "ATG". Click on the "Inventory" button, which will enter the command

"I20100". After several seconds, a Response should appear providing the current inventory data from the ATG. If no response is received, there is a problem either in the setup parameters or the physical connection to the ATG.

Firefox V	+								□ □ ×
(+) 10.20.95.33 https://10.20.95.	33/DLSetup/#Sci	een6				☆ マ C 🕻	🖣 🗝 Google		۹ 🍙
A Most Visited C Getting Started									Bookmarks
VEEDER-ROOT	V004.X.201	.1 🔘	2012-	02-26 04:43				vee	der Log Out
Main Menu 🗿 Home	Communic	ation Testing > ATG							🕒 Print
System Setup	Command:	120100				Send			
© FMS Heartbeat									
Select 🔶 🚯 ATG		I20100 FEB 26, 2012 10:40 AM							
Pos		999033							
С ПИ		Tom Diego Gas Sta TEST TEXT							
	Response:	IN-TANK INVENTORY TANK PRODUCT 1 QAGDJPTMW 2 3 4	VOLUME 1 3381 0 0 0	IC VOLUME 3354 0 0 0	ULLAGE 5619 0 0 0	HEIGHT 38.57 38.57 38.57 38.57 38.57	WATER 2.96 2.96 2.96 2.96	TEMP 72.23 72.23 72.23 72.23	
Click on Inventory button —	Inve s .	Inventory Clear							

Figure 25. Inventory Command Results

21. If the DL4 is connected in the Pass-Thru mode (Scenario 2) and is accepting commands from the POS and passing them through to the ATG, click on "POS" to detect the POS protocol. Click the "START" button next to "Auto Detect Protocol" and wait for the Protocol Type to appear (see example in Figure 26.

	•	10.20.95.33 https://10.20.95.	33/DLSetup/#Screen7		🚖 ⊽ C 🖁 ▾ Google	۹ 🍙
	<u>P</u>	Most Visited 🗍 Getting Started				🖪 Bookmarks
		🜔 VEEDER-ROOT	V004.X.201.1	2012-02-27 04:49		veeder Log Out
		Main Menu 🕢 Home	Communication Testing POS			🕒 Print
		System Setup	Auto Detect Protocol:	Start - Click o	n Start button	
		Communication Testing				
		FMS Heartbeat	Protocol Type:			
		ATG (Command County			
Select –		POS	Command Count.			
		■ DIM				

Figure 26. POS Protocol Type Query

Verify that this is the correct protocol that was entered in the DIM setup in Step 12. Then click on the "Stop" button (see example in Figure 27).

(10.20.95.33 https://10.20.95.	33/DLSetup/#Screen7			☆ マ C 🖁 🗧 Google	۹ 🔒
Most Visited Getting Started		🖪 Bookmarks			
VEEDER-ROOT	V004.X.201.1	0	2012-02-26 04:44		veeder Log Out
Main Menu 🗿 Home	Communication Testing POS				Print
System Setup	Auto Detect Protocol:	Stop	Click S	done	
Communication Testing					
FMS Heartbeat	Protocol Type:	VEED	ER-ROOT (BIR)		
(a) ATG	Command Count:	14			
POS	Contraine Contra				
DIM					



22. The DL4 should now be configured to collect inventory and transactional data, which will be periodically retrieved by FMS. To verify connectivity with FMS, reconnect the DL4 to the network or cell modem. Go to the "DLSetup" application's Communication Testing screen, click on "FMS Heartbeat", then click on the "Send Heartbeat" button (see Figure 28). Wait for the "Response" text to indicate PASS or FAIL. A PASS confirms that the DL4 is successfully communicating with FMS. A FAIL indicates that the connection has failed and you will need to contact FMS or the network administrator for troubleshooting assistance.

ĺ	F C	irefox ▼ TLS-450 Web Interface	+					
		10.20.95.33 https://10.20.95	.33/DLSetup/#Screen5	۹ م	^			
	2	Most Visited Getting Started	V004.X.201.1	0	2012-02-26 04:46		Veeder Log Out	s
		Main Menu O Home	Communication Testing > FM	S Hear	tbeat	S Print		
		System Setup	FMS I	: XXXX				
Calaat		Communication Testing	FMS IP Address	: XX.X	X.XX.XX		Send Heartbeat	 Click to test
Select		FMS Heartbeat						
		ATG	Response	: PAS	s 🗲			
		POS						
		OIM			└─ Test			



Figure 28. FMS Heartbeat Screen

IMPORTANT! Connectivity between the DL4 and FMS must be verified prior to completing the installation.

23. Return your laptop PC to the network settings originally set prior to the changes you made in Step 5.



