

TLS-HLD

Site Prep Manual

Notice

Veeder-Root makes no warranty of any kind with regard to this publication, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

Veeder-Root shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this publication.

Veeder-Root reserves the right to change system options or features, or the information contained in this publication.

This publication contains proprietary information which is protected by copyright. All rights reserved. No part of this publication may be photocopied, reproduced, or translated to another language without the prior written consent of Veeder-Root.

DAMAGE CLAIMS

1. Thoroughly examine all components and units as soon as they are received. If damaged, write a complete and detailed description of the damage on the face of the freight bill. The carrier's agent *must* verify the inspection and sign the description.
2. Immediately notify the delivering carrier of damage or loss. This notification may be given either in person or by telephone. Written confirmation must be mailed within 48 hours. Railroads and motor carriers are reluctant to make adjustments for damaged merchandise unless inspected and reported promptly.
3. Risk of loss, or damage to merchandise remains with the buyer. It is the buyer's responsibility to file a claim with the carrier involved.

RETURN SHIPPING

For the parts return procedure, please follow the appropriate instructions in the "General Returned Goods Policy" and "Parts Return" pages in the "Policies and Literature" section of the Veeder-Root **North American Environmental Products** price list.

Introduction	
Regulatory Agency Console Documentation	1
Related Manuals	1
Safety Symbols	2
Site Considerations	
Control Drawing	3
National Electrical Code Compliance	4
Probe- to-Console Wiring	4
Probe Junction Boxes.....	4
Probe Wiring Safety Issues	5
Selecting a Console Location	5
Console Installation	
Mounting the Console	7
Wiring the Console	9
Mag Probe Assembly	
Attaching Probe Canister Spacer Rings	10
Assembling Floats onto Probe Shaft	10
Attaching Cable Connector to Probe Canister	10
Probe Installation	
Probe Manhole Installation	13
Probe Installation	13
Probe Conduit Installation	14
Wiring Run Methods	15
Buried Rigid Conduit.....	15
Pulling Wires for Probes	15
Direct Burial Cable.....	15
Sealing Field Connections	17
Wiring Run Through Rigid Conduit.....	17
Direct Burial Cable.....	17
Connecting Probes to the Console	18
Probe Wiring Precautions	19
Input/Output Wiring Positions and Labeling	19
Connecting Probes to the Console - Observe Polarity.....	19
Applying Power to System	
TLS-HLD Cold Boot - Initial Power Up	21
TLS-HLD Cold Boot - RAM Clear	21
TLS-HLD Warm Boot	21
RS-232 Communications	
RS-232 Peripheral Equipment Requirements	22
RS-232 Connections	22
To a Device Less Than 50 Feet from the Console	22
To a Device More Than 50 Feet from the Console	22
Surge Protection for Communication Devices	23
Restricting System Programming Access	24
Serial Security	24
setup Security.....	24

Dip Switch Settings.....	24
RS-232 Serial Communication Setup	24
DB-9 Connector Pin-Outs	25

RS-232 Commands

TLS-HLD RS-232 Serial Commands	26
Function Code:	001 27
Function Code:	003 28
Function Code: 201	29
Function Code: 205	30
Function Code: 504	31
Function Code: 50C	32
Function Code: 517	33
Function Code: 601	34
Function Code: 608	35
Function Code: 881	36
Function Code: 882	37
Function Code: 883	38
Function Code: 884	39
Function Code: 902	40
Function Code: A01	41
Function Code: A02	42
Function Code: A10	43
Function Code: A11	44
Function Code: A12	45

Troubleshooting

Dual-Function Front Panel Keys	46
Probe Diagnostic Menu	46
Probe Diagnostic Report	48
Replacing the CPU Board	48
PROM Chip Replacement (Software Upgrade)	50
Replacing the Power Supply Board	53
Display Messages	53
Tank Parameters	53
Alarms	53
Alarm Cause/Action Table	54

Console Specifications

Physical Specifications.....	55
Environmental Specifications	55
Electrical Specifications.....	55
Signal Input Specifications	55
Signal Output Specifications.....	55
Front Panel User Interface	55
TLS-HLD Probe Circuit Codes	56

Figures

Figure 1.	Control Drawing - Example TLS-HLD System Site Layout	3
Figure 2.	Recommended Mounting of Console	7
Figure 3.	Console Dimensions and Designated Conduit Knockouts	8
Figure 4.	Wiring AC Power to the Console	9
Figure 5.	Installing Probe Canister Spacer Rings	11
Figure 6.	Probe Float/Boot Installation	12
Figure 7.	TLS-HLD Probe Installation Example - Underground Storage Tank.....	13
Figure 8.	TLS-HLD Probe Installation Example - Above ground Storage Tank	14
Figure 9.	Example Probe Wiring Run in Buried Rigid Conduit	15
Figure 10.	Example Probe Wiring Run Via Direct Burial Cable	16
Figure 11.	Probe Field Wiring Connection	17
Figure 12.	Epoxy Sealing Connections	18
Figure 13.	Probe Installation Directory	19
Figure 14.	Connecting Probe Wiring to Console	20
Figure 15.	Console Connected to a Remote Device Via Short-Haul Modem	23
Figure 16.	Console Dip Switch Settings	24
Figure 17.	DB9, RS-232 Pin-Outs	25
Figure 18.	Dual-Function Keys	46
Figure 19.	CPU Board Voltage Test Points	49
Figure 20.	Removing PROM Chip	51
Figure 21.	Replacing PROM Chip	52

Introduction

This manual describes the site preparation and console installation procedures for the TLS-HLD Console.

This manual assumes that you installing the TLS-HLD in a new site (before pavement is put down and with no wiring runs in place). Among the topics covered are:

- Site layout considerations.
- Installing the console and connecting wiring from the 120 or 240 Vac power panel.
- Probe assembly and installation procedures.
- Installing wiring conduit between the console and its probes.
- Probe-to-console field junction box wiring diagram.
- Attaching probe wiring to the console.
- RS-232 serial communication connection requirements and serial commands.
- Troubleshooting information that contains diagnostic and maintenance information.
- System specifications.

After the console is wired to its power source and probes, you should program the console following the setup instructions contained in the TLS-HLD Setup manual.

Regulatory Agency Console Documentation

The UL Console Form Numbers are listed by Underwriters Labs, in File Number: MH11766.

Related Manuals

577013-785	TLS-HLD Setup manual
576013-635	RS-232 Serial Interface manual
576013-859	Direct Burial Cable Installation manual

