

TLS-PC

User Guide



Notice

Veeder-Root makes no warranty of any kind with regard to this publication, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

Veeder-Root shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this publication.

Veeder-Root reserves the right to change system options or features, or the information contained in this publication.

This publication contains proprietary information which is protected by copyright. All rights reserved. No part of this publication may be photocopied, reproduced, or translated to another language without the prior written consent of Veeder-Root.

For complete warranty, technical support, and additional product information, refer to your console's Operator Manual.

VEEDER-ROOT SOFTWARE LICENSE AGREEMENT

This License Agreement ("License" or "Agreement") is a legal agreement between **Veeder-Root Company**, or its assignee ("Veeder-Root" or "Licensor") and Licensee (either an individual or a single entity, "Licensee").

LICENSEE SHOULD CAREFULLY READ THE FOLLOWING TERMS AND CONDITIONS BEFORE OPENING THE SEALED DISK PACKAGE CONTAINING THE SOFTWARE LICENSED HEREUNDER. OPENING THE PACKAGE INDICATES LICENSEE'S ACCEPTANCE OF THESE TERMS AND CONDITIONS. IF YOU DO NOT AGREE TO THESE TERMS, LICENSOR IS UNWILLING TO LICENSE THE SOFTWARE TO YOU, AND LICENSEE SHOULD NOT OPEN THE DISK PACKAGE. IF LICENSEE DOES NOT AGREE WITH THE TERMS, LICENSEE SHOULD RETURN THE PACKAGE UNOPENED, WITH DATED PROOF OF PAYMENT, WITHIN TEN (10) DAYS OF PURCHASE TO THE AUTHORIZED DISTRIBUTOR FROM WHOM LICENSEE OBTAINED IT FOR A FULL REFUND OF THE PRICE LICENSEE PAID AND LICENSEE'S MONEY WILL BE REFUNDED.

1. **LICENSE.** Licensor hereby grants to Licensee, for good and valuable consideration, a personal, non-exclusive, non-transferable license to use the Software (as defined below) on the terms and conditions specified in this Agreement. Title and ownership of the Software remain in Licensor.
2. **SOFTWARE.** "Software" shall mean the *TLS-PC™* software, including computer software and associated media and printed materials.
3. **PERMITTED USE.** Licensee's right to use the Software pursuant to this License shall be limited to the following uses:

(a) **Limited to Monitoring Licensee's own Fueling Sites.** Licensee may install and use the Software only with Veeder-Root manufactured equipment. Licensee may use the Software only to provide data services and data management to fueling sites owned or exclusively operated by it, up to the maximum number of fueling sites permitted by the particular model of Software. Licensee may not use the Software in anyway, whether to provide data services and data management or otherwise, for any fueling sites not owned or operated exclusively by it, without Veeder-Root's prior written consent, to be given or withheld in Veeder-Root's sole discretion.

(b) **Right to Install and Use.** Licensee may use the Software only in machine readable object-code form. Licensee may install and use the Software on the temporary memory or hard disk drive or other storage device of any single computer. However, Licensee may not under any circumstances have the Software installed onto the temporary memory or hard drives (or other storage devices) of two or more computers at the same time, nor may Licensee install the Software onto the hard disk drive of one computer and then use the original diskettes on another computer. If Licensee wishes to use the Software on more than one computer, Licensee must either erase the Software from the first hard drive before Licensee installs it onto a second hard drive, or else license an additional copy of the Software for each additional computer on which Licensee want to use it. Any portion of this Software merged into or used in conjunction with another program will continue to be the property of Licensor and subject to the terms and conditions of this Agreement.

(c) **Archival Copy.** Licensee shall not make or permit to be made any copies of the Software, except for backup and archival purposes, provided that the original and each copy is kept in Licensee's possession, and that Licensee's installation and use of the Software does not exceed that allowed in part (b) above. Licensee may not copy the printed materials accompanying the Software.

4. **RIGHTS AND OBLIGATIONS OF THE LICENSEE.**

- (a) Licensee agrees not to sub-license, assign, encumber, sell, rent, lease, lend, donate or otherwise transfer or dispose of

the Software or a copy of the Software to any other organization or individual, whether by transfer of the Software, or by sale of stock in, merger or other disposition of, Licensee, without Veeder-Root's prior written consent, to be given or withheld in Veeder-Root's sole discretion. Any attempt to so transfer any rights, duties or obligations hereunder without such consent is void.

(b) The Software shall not be disclosed, used or duplicated for any purpose whatsoever without the prior written permission of Licensor or its assignee. The previous sentence shall be marked on any permitted reproduction hereof in whole or in part. The use of the Software by anyone except the Licensee, or the making of a copy thereof that is not authorized by Licensor, as provided herein, is a violation of this License Agreement.

(c) Licensee may not reverse engineer, decompile, or disassemble the Software, except and only to the extent that such activity is expressly permitted by applicable law, notwithstanding this limitation.

5. TERM AND TERMINATION. The term of this Agreement shall commence on the date Licensee opens the Software package and is effective until terminated. Licensee may terminate the License at any other time by destroying the Software together with all copies, modifications and merged portions in any form. If Licensee violates any of the terms of this License Agreement, Licensor may immediately terminate this License Agreement. Upon termination of this License Agreement, the Software together with all copies, modifications and merged portions in any form, must either be returned to Licensor or destroyed, at Licensor's discretion, by Licensee, and Licensee shall have no further rights to utilize the Software from the date of such termination.

6. LIMITED WARRANTY. Licensor warrants, as the only warranties provided to Licensee, that the (i) disks and documentation in the Software package will be free from defects in materials and workmanship under normal use for a period of one (1) year from the date Licensee acquired the Software from Veeder-Root's authorized distributor, provided Veeder-Root receives the completed Software Registration Card; and (ii) the Software in the package will materially conform to the documentation that accompanies it.

The Limited Warranty set forth above is void if the failure of the Software results, in whole or part, from accident, abuse, misapplication or modification to the Software. Any replacement Software provided pursuant to this Agreement will be warranted for the remainder of the original warranty period or thirty (30) days, whichever is longer.

7. BREACH/REMEDY.

(a) If the disks or documentation in the Software package fail to conform to the limited warranty set forth in section 5, Licensee may, as Licensee's sole and exclusive remedy, obtain replacement disks or documentation free of charge if Licensee returns the defective disk or documentation to Veeder-Root (postage paid) with a dated proof of purchase. If the Software fails to operate in accordance with the limited warranty set forth in section 5, Licensee may, as Licensee's sole and exclusive remedy, return all of the Software and the documentation to the authorized distributor from whom Licensee acquired it, along with a dated proof of purchase, specifying the problem, and Veeder-Root will provide Licensee with a new version of the Software or a full refund at Veeder-Root's election.

(b) Licensee agrees that if Licensee violates this Agreement, Licensor may have no adequate remedy in money or damages and Licensor shall be entitled to an injunction against Licensee against the continuance of such violation in addition to all other remedies.

8. DISCLAIMER. LICENSOR DOES NOT WARRANT THAT THIS SOFTWARE WILL MEET LICENSEE'S REQUIREMENTS OR THAT ITS OPERATION WILL BE UNINTERRUPTED OR ERROR-FREE. LICENSOR SHALL HAVE NO OBLIGATION TO MAINTAIN OR PROVIDE SUPPORT FOR ANY COMPONENT OF THE SOFTWARE. EXCEPT AS SPECIFICALLY PROVIDED IN SECTION 5, THE SOFTWARE IS PROVIDED "AS IS" WITHOUT REPRESENTATION OR WARRANTY OF ANY KIND, WHETHER EXPRESS AND IMPLIED, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE SOFTWARE IS WITH LICENSEE.

9. LIMITATION OF LIABILITY. LICENSOR'S LIABILITY TO LICENSEE FOR ANY LOSSES SHALL BE LIMITED TO

DIRECT DAMAGES, AND SHALL NOT EXCEED THE AMOUNT LICENSEE ORIGINALLY PAID FOR THE SOFTWARE. IN NO EVENT WILL LICENSOR BE LIABLE TO LICENSEE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING LOSS OF PROFITS) EVEN IF LICENSOR HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR FOR ANY CLAIM BY ANY OTHER PARTY.

10. GOVERNING LAW; GOVERNING FORUM. This Agreement will be interpreted in accordance with and enforceable under the laws of Connecticut, without reference to its conflicts of law provision, and constitutes the entire understanding of the parties, unless modified by a writing signed by both parties. Any controversy or claim arising out of or relating to this Agreement, including without limitation, any claim based on or arising from an alleged tort, shall first be submitted to mediation using the American Arbitration Association in Hartford, Connecticut for a period of sixty (60) days. The parties agree that any and all statutes of limitation or periods of time for taking action shall be tolled during the time period that the parties are engaged in mediation. No provision of, or the exercise of any rights under, this Section shall limit the right of any party to obtain provisional or ancillary remedies such as injunctive relief from a court having jurisdiction before, during or after the pendency of any mediation. Each of the parties hereby specifically and irrevocably consents to the jurisdiction of the courts located in the State of Connecticut with respect to all matters relating to this Agreement and waives any objection it may have to the laying of venue in any such court. Except as otherwise provided, this License Agreement shall be binding upon and inure to the benefit of the parties hereto and their respective permitted successors, representatives, and assigns.

LICENSEE ACKNOWLEDGES THAT IT HAS READ THIS AGREEMENT, UNDERSTANDS IT, AND AGREES TO BE BOUND BY ITS TERMS AND CONDITIONS. LICENSEE FURTHER AGREES THAT IT IS THE COMPLETE AND EXCLUSIVE STATEMENT OF THE AGREEMENT BETWEEN LICENSEE AND LICENSOR AND LICENSOR'S AUTHORIZED DISTRIBUTOR WHICH SUPERSEDES ANY PROPOSAL OR PRIOR AGREEMENT, ORAL OR WRITTEN, AND ANY OTHER COMMUNICATIONS BETWEEN SUCH PARTIES RELATING TO THE SUBJECT MATTER OF THIS AGREEMENT.

Veeder-Root TLS-PC™ Software Warranty Registration Card

To initiate a one year warranty on your TLS-PC software, be sure to complete this information and return to Veeder-Root. The form must be returned within 14 days of installation.

TLS-PC Software Version*: _____ Date of Installation: _____

TLS-PC Software Serial No.*:

Affix serial no. sticker here

Installation Address:

Contact Person (print):

Signature:

Title:

Please include your zip code or postal code and country.


After filling in your name, etc., remove card at perforation and mail.

TLS-PC Software Version*: _____ Date of Installation: _____


TLS-PC Software Serial No.*:

Affix serial no. sticker here

*The software version number and serial number are printed on the disk label.



NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES



BUSINESS REPLY MAIL
FIRST CLASS MAIL PERMIT NO. 4 ALTOONA, PA

POSTAGE WILL BE PAID BY THE ADDRESSEE



**ATTN CUSTOMER SERVICE DEPARTMENT
VEEDER ROOT CO
PO BOX 1673
ALTOONA PA 16603-9955**






Veeder-Root Support

Calling for Help

Please use these telephone numbers when you need help:

Customer Service	
Orders, accessories and supplies, customer support assistance, nearest authorized Veeder-Root distributor	 800-873-3313  800-234-5350
<i>Monday - Friday, 8 a.m. - 6 p.m. Eastern Standard Time</i>	

Product Information	
Literature requests Sales applications information Technical applications information	 800-873-3313  800-234-5350
<i>Monday - Friday, 8 a.m. - 4:30 p.m. Eastern Standard Time</i>	

Technical Support (for Authorized Contractors only)	
Technical Service	 860-651-2753
<i>Monday - Friday, 8 a.m. - 7 p.m. Eastern Standard Time</i>	

Contents

Veeder-Root Software License Agreement.....	iii
---	-----

Veeder-Root Support

Calling for Help	ix
------------------------	----

Overview

Hardware and Software Requirements	1
Alarm Response	1
Data Monitored	2
Required Operator Training	2

Getting Started

TLS Console Installation and System Setup	3
Important Notice About Reference Manuals	3
Connecting Your PC to the TLS Console	4
Direct Connect Via Cable	4
Short-Haul Modem Connection	5

TLS-PC Software Installation	7
---	----------

Optional Feature Setups

Current Data Storage Interface	11
--------------------------------------	----

Operating the TLS-PC Program

TLS-PC Main Screen	15
Date and Time Section	16
System Status Section	16
SYSTEM NORMAL Message	16
ALARM Message (All Alarms)	16
COMM ERROR Message	19
REPORTS Section	20
PC SETUP Button	20
COMMUNICATIONS SETUP Section	20
TANK COLOR Setup	21
CONSOLE Button	22
POLLING TXRX	22
Tank Detailed Information Screens	23
EXIT Button	23
TLS-PC Minimize Icon	24
Operator Response to Alarm Conditions	24

Viewing and Printing Reports.....	25
--	-----------

Report Categories	25
To View A Report	27
To Print Out A Report	28
To Print A Report To File	30
Printing Out A Stored Report	30
BIR Manual Adjustments.....	31

Figures

Figure 1.	TLS-PC Console	3
Figure 2.	Connecting the Console to a PC via Short-Haul Modems	6
Figure 3.	Run Dialog Box.....	7
Figure 4.	TLS-PC Installation Welcome Screen	7
Figure 5.	Choose Destination Location Screen	8
Figure 6.	Exit Setup Screen.....	8
Figure 7.	Choose Directory Screen	9
Figure 8.	TLS-PC Software Installation-In-Progress Screen	9
Figure 9.	View Read Me File Prompt Screen	9
Figure 10.	TLS-PC Installation Information Screen	10
Figure 11.	TLS-PC Group Window	15
Figure 12.	TLS-PC Main Screen	15
Figure 13.	VLLD Priority Alarm Window	17
Figure 14.	VLLD Test Status Window	17
Figure 15.	PLLD Priority Alarm Window	18
Figure 16.	WPLLD Priority Alarm Window	18
Figure 17.	PLLD Test Status Window	19
Figure 18.	WPLLD Test Status Window.....	19
Figure 19.	Communications Timeout Window	20
Figure 20.	PC Setup Screen.....	20
Figure 21.	Console Mode Screen	22
Figure 22.	Tank Detailed Information Screen	23
Figure 23.	TLS-PC Program Icon	24
Figure 24.	Operational Report Menu	27
Figure 25.	Inventory Report.....	28
Figure 26.	Print Screen.....	28
Figure 27.	Print Setup Screen	29
Figure 28.	Print Setup Options Screen.....	29
Figure 29.	Print-To-File Screen.....	30
Figure 30.	Operations Report Menu	31
Figure 31.	Set Manual Adjustment Value Window.....	31
Figure 32.	BIR Manual Adjustment Entered	32

Tables

Table 1.	Data Storage Timing Intervals	13
Table 2.	Operational Menu Reports	25
Table 3.	Setup Menu Reports	26
Table 4.	Diagnostics Menu Reports	26
Table 5.	Regulatory Menu Reports	27

Overview

Veeder-Root's TLS-PC is a Microsoft® Windows® based application that allows you to monitor an operating TLS-300-PC (or TLS-300, TLS-350-PC (or TLS-350), TLS-350R-PC (or TLS-350R) Console (hereinafter called TLS Console), from an IBM® PC or compatible computer (hereinafter called PC) .

The TLS-PC software periodically polls the TLS Console and uses various system setup parameters to display a graphical representation of your station's tanks and related information. Polled data is also available in various on-screen reports. TLS Console alarms are monitored and when an alarm is detected, the TLS-PC triggers both audible and visual indicators.

Printouts of TLS-PC generated reports can easily be made on your existing office printer with a few clicks of the mouse. Also, you can choose to print any report to file for storage on your hard drive or a floppy disk.

Within the TLS Console Mode, you can reset the TLS Console's previously entered System Setup parameters.

Hardware and Software Requirements

To run TLS-PC software, your computer must have; an available serial port, a 486/33 or greater microprocessor, 4 megabytes of RAM, 2.5 megabytes of hard drive space, MS DOS 5.0 or later, and Microsoft Windows 3.1 or later. Your PC must be connected via an RS232 null-modem cable, or short-haul modem to the TLS Console. (Your Veeder-Root service contractor will select the proper interconnection method.) A printer is strongly recommended for printing out reports.

Alarm Response

TLS-PC can be used to silence alarm and warning conditions that occur on the TLS console. The Console Mode Screen is used to determine the cause of the condition and take corrective actions.

Related Manuals

576013-273	TLS-300, TLS-300C, & TLS-300i Setup Manual
576013-274	TLS-300, TLS-300C, & TLS-300i Operator's Manual
576013-610	TLS-350 & TLS-350R Operator's Manual
576013-623	TLS-350 & TLS-350R System Setup Manual

Data Monitored

TLS-PC stores and periodically receives updates of the following TLS Console system parameters:

- Tank setup information** - tank label, capacity, diameter, maximum volume, high product limit, delivery needed limit, and low product limit.
- Tank inventory levels** - volume, ullage, temperature compensated volume, product height, water volume, water height, and temperature.

Depending on which TLS console you have, you can select from a wide variety of reports both to view and to print (see Viewing and Printing Reports on page 25 for a detailed list of available reports):

- Operation menu reports** - system status, inventory, delivery history, shift inventory, sensor status, test results, and BIR reports.
- Setup menu reports** - system setup, tank setup, sensor setup, and BIR setup.
- Diagnostic menu reports** - system revision level, tank diagnostic, sensor diagnostic, and alarm histories.
- Regulatory menu report** - tank leak test history and sensor status.

Required Operator Training

Operation of TLS-PC requires that you be familiar with the Microsoft Windows environment and its terms, such as, icon, title bar, menu bar, sizing buttons, minimize, maximize, pointer, click, double-click, and drag. You should know how to open a menu, select a command, work with dialog boxes, and other basic Windows activities.

You do not need extensive database skills or special training to operate TLS-PC. This manual will provide the support you need to install and operate the application.

Getting Started

TLS Console Installation and System Setup

If your TLS Console is up and running, continue to the next paragraph. If you are installing the TLS Console, sensors, and TLS-PC software for the first time, you must install the TLS Console and sensors before installing TLS-PC software. Follow the procedures outlined in your Site Prep and Installation and System Setup manuals that are included with that equipment.

Important Notice About Reference Manuals

When using TLS-300/TLS-350/TLS-350R System Setup, Operator, and Site Preparation and Installation manuals with a TLS Console [Figure 1], references to front panel keypads and displays do not apply.




Figure 1. TLS-PC Console

The TLS Console functions identically to TLS Consoles having a front panel keypad and display; however, you must configure the TLS Console remotely using the TLS-PC software. After connecting the TLS Console via RS232 cable to a PC or compatible computer, you can enter all TLS Console system setup data while running TLS-PC software in the Console Mode.

When operating the TLS-PC software in the Console Mode, you will see on the monitor's screen, a graphical representation of the same keypads and display that are physically on the front panel of other TLS Consoles. When entering system setup data,

any reference to *pressing* a front panel key should be read as *clicking on* the identical screen displayed button after positioning the cursor over the button with the mouse. Data entries made in the TLS Console Mode are identical in every other way to data entries made pressing TLS Console front panel keys. Also, data appearing in the TLS-PC-generated front panel display will be identical to any data referenced in current TLS Console manuals as appearing in a console's front panel display.

The red ALARM/TEST key and the Status lights operate the same on this TLS Console as on all TLS Consoles.

Connecting Your PC to the TLS Console

A direct connect cable can be used between your computer (PC) and Console if the cable run is no longer than 50 feet (15.2 m). Cable runs longer than 50 feet can result in data errors, component damage, or both. If cable runs from the Console to the PC exceed 50 feet, two short-haul modems should be used, one at the PC and one at the console.

Direct Connect Via Cable

Turn off the TLS Console and your PC. Attach the male end of a null-modem cable to the RS-232 Board's 25-pin connector (DB25) under the left side of the unit. Attach the other end to the back of the PC [25-pin (DB25) or 9-pin (DB9) depending on which port is available]. Pin connections at each end of the null modem cable for the two types of PC connectors are as follows:

**Console
DB25 on RS-232 Module
Pin No. (Signal)****PC
DB25 Connector
Pin No. (Signal)**

2 (TX)	Connects to	3 (RX)
3 (RX)	“	2 (TX)
7 (Signal Ground)	“	7 (Signal Ground)

**Console
DB25 on RS-232 Module
Pin No. (Signal)****PC
DB9 Connector
Pin No. (Signal)**

2 (TX)	Connects to	2 (RX)
3 (RX)	“	3 (TX)
7 (Signal Ground)	“	5 (Signal Ground)

Short-Haul Modem Connection

For cable runs over 50 feet, we recommend an async short-haul modem, Black Box model ME800A, or equivalent. You can contact Black Box at P.O. Box 12800, Pittsburgh, PA 15241, phone: (724) 746-5500, or fax: (724) 746-0746 or via the internet, at: <http://www.blackbox.com>

Turn off the Console and your PC. See Figure 2 for a diagram detailing how to connect the Console to the PC using short-haul modems.




Figure 2. Connecting the Console to a PC via Short-Haul Modems

TLS-PC Software Installation

The TLS-PC software is contained on one 3.5" disk. To install TLS-PC, first run Windows as you normally would.

1. Insert your TLS-PC disk into the A: drive or the B: drive. From the Windows Program Manager, pull down the **File** menu and click on **Run**. The Run dialog box appears. Type the letter of the drive, followed by:\setup.exe. For example, the disk is in drive **A** [Figure 3]. Click on the **OK** button.




Figure 3. Run Dialog Box

2. The install software autoloads and the Welcome Screen appears [TLS-PC Installation Welcome Screen]].





Figure 4. TLS-PC Installation Welcome Screen

3. After reading the instructions, if you need to close any existing applications first click on the minimize button (the down arrow button on the upper right of the setup screen). The TLS-PC icon becomes the setup icon on the desktop. Exit any open applications as recommended on the Welcome screen. When you have finished, double click on the setup icon, or simultaneously press the **Alt** and **Tab** keys to

return to the setup Welcome screen. Click on the **Next>** button to continue the TLS-PC installation.

4. The Choose Destination Screen appears [Figure 5]. Follow the instructions to choose the directory in which you want to install TLS-PC. The default directory is c:\TANKGAGE. If this location suits you, click on the **Next>** button to begin the TLS-PC installation.

Important  When a newer (or the same) version of TLS-PC is loaded over an existing version, keep the same directory.




Figure 5. Choose Destination Location Screen

5. If you click on the **<Back** button, you go back to the previous screen; if you desire to exit the setup program, click on the **Cancel** button.




Figure 6. Exit Setup Screen

6. Clicking on the **Exit Setup** button stops the TLS-PC installation [Figure 6].
7. Click on the **Resume** button to continue the TLS-PC installation [Figure 6]. The Choose Destination Location Screen reappears [Figure 5].

8. If directory other than the default (TANKGAGE) is desired, click on the **Browse** button to select a different directory in which to save the TLS-PC program files. The Choose Directory Screen appears [Figure 7].




Figure 7. Choose Directory Screen

9. Type in your directory selection or choose an existing directory from the hard drive, then click the **OK** button to return to the Choose Directory Location screen. Click on the **Next>** button to begin the installation process.
10. The software is automatically installed on your computer. A dialog box illustrates the installation's progress [TLS-PC Installation Welcome Screen].



Figure 8. TLS-PC Software Installation-In-Progress Screen

11. When the software is installed a prompt screen appears [Figure 9].




Figure 9. View Read Me File Prompt Screen

12. Clicking on the **Yes** button opens a text file which may contain important information about your TLS-PC software that is not in this manual. You should read this file before starting the TLS-PC program. After you read the text file and close its dialog box, the TLS-PC installation Information screen appears [TLS-PC Installation Welcome Screen]. Click on the OK button to exit the TLS-PC installation program.



Figure 10. TLS-PC Installation Information Screen

13. This completes the TLS-PC software installation.

Optional Feature Setups

Current Data Storage Interface

The Current Data Storage Interface (for TLS-300, TLS-350, and TLS-350R) is used for computer systems to access the current UST Monitoring Systems Data without the use of additional external electrical connections. This data is provided to the computer system from Veeder-Root's TLS-PC software.

The "current data" files may be used to copy report data into many software applications such as spreadsheets and database programs. This capability can be setup and used by Information Technology or Computer Specialists.

TLS-PC defaults with the Current Data Storage features turned ON. To disable the Current Data Storage functions, edit the following file using any standard text editor or the Windows Notepad (by changing the word "ON" to "OFF", individual features may be de-selected):

C:\WINDOWS\TANKGAGE.INI

To redirect Data Storage functions to a different subdirectory, change the storage path from C:\TANKGAGE to an existing subdirectory.

The following is a **sample** TLS-PC initialization (.ini) file:

```
[Data Storage Enable]
StoragePath=C:\TANKGAGE
sShortDate=MM/dd/yy
sTime=00:00:00
StartReportTime=00:00
INVENTORY=ON
ALARM_HISTORY=ON
ALARM_STATUS=ON
DELIVERY=ON
BIRPEROD=ON
BIRSHIFT=ON
SENSOR=ON
TANKTEST=ON
LINELEAK=ON
SETUP=ON

[Data Storage Timing]
INVENTORY_TIMING=5
ALARM_HISTORY_TIMING=6
ALARM_STATUS_TIMING=6
DELIVERY_TIMING=7
ADJ_DELIVERY_TIMING=7
BIRPEROD_TIMING=9
BIRSHIFT_TIMING=9
SENSOR_TIMING=8
TANKTEST_TIMING=11
LINELEAK_TIMING=11
SETUP_TIMING=11
```

Important ☞ “sShortDate” shows a text picture of the Data Storage output format (i.e. MM/dd/yy).
“sTime” identifies the single character time separator between hours, minutes, and seconds (i.e. 08:30:00).
“StartReportTime” indicates when reports are generated (see Nos. 10 and 11 in Table 1 below).

To change the Data Storage timing interval, use the following table to determine which number should be used:



Important  *When an inappropriate value has been assigned to the Data Storage timing value, the default value will be used.*

Table 1. Data Storage Timing Intervals

Number	Interval
0	undefined, use default
1	once every 30 seconds
2	once every minute
3	once every five minutes
4	once every ten minutes
5	once every thirty minutes
6	after alarm status change
7	after a delivery is complete
8	once every hour
9	once every even hour
10	once every three hours, starting after user defined parameter StartReportTime
11	once per day, just after user defined parameter StartReportTime

For more detailed information, refer to the *Current Data Storage Interface Manual* for *TLS-300/350/350R Monitoring Systems*.

Operating the TLS-PC Program

Important  *The TLS Console must be programmed before bringing up the TLS-PC software.*

In the Windows Program Manager screen, double click on the TLS-PC Group icon and the TLS-PC group window appears. If the TLS-PC software was installed correctly, your group window should look like the group window in TLS-PC Installation Welcome Screen.




Figure 11. TLS-PC Group Window

TLS-PC Main Screen

Double click on the TLS-PC icon to start the program. The TLS-PC application starts up and the TLS-PC Main Screen appears [TLS-PC Installation Welcome Screen].




Figure 12. TLS-PC Main Screen

On the left side of the Main Screen from the top down you see:

Date and Time Section

The current date and time (from your internal PC clock) are shown here.

System Status Section

This section of the Main Screen displays SYSTEM NORMAL, ALARM, or COMM ERROR messages, and contains an ALARM/TEST button.

SYSTEM NORMAL Message

When the TLS Console is operating normally (no alarms), you will see the words SYSTEM NORMAL.

ALARM Message (All Alarms)

When an alarm is detected by the TLS Console, and polled by TLS-PC, the words SYSTEM NORMAL change to the word ALARM which flashes white then red, and the PC's internal speaker beeps. You can turn off the PC beeping by clicking on the **ALARM/TEST** button. (Clicking on this button turns off the beeper only. The word ALARM continues to flash until the problem causing the alarm has been corrected.)

Important ☞ *It is possible that a new alarm may beep and flash after the initial one has been turned off and corrected. If this happens, just repeat the above instructions as needed.*

ALARM Message (VLLD Alarms Only)

These alarms only occur if you have a Volumetric Line Leak Detector (VLLD). When an alarm is signaled, the following sequence of events will occur.

1. The words SYSTEM NORMAL change to the word ALARM which flashes white then red, and the PC's internal speaker beeps. Click on the **ALARM/TEST** button to silence the audible alarm. (Clicking on this button turns off the beeper only. (The word ALARM continues to flash until the problem causing the alarm has been corrected.)
2. A Priority Alarm window appears, in this example there is a VLLD alarm [Figure 13 on page 17]. Cover the dispenser handles or take other measures to prevent them from being lifted. If a pump handle is lifted during the LVP (Line Verification Procedure) test, the submersible pump will again be shut down and the alarms reactivated.




Figure 13. VLLD Priority Alarm Window

3. If you click on the **CANCEL** button, the Priority Alarm window disappears from the screen, but no corrective action is taken. Click on the **OK** button to initiate a LVP test on the sensor (VLLD) that caused the alarm condition. The Priority Alarm window disappears from the screen and a Test Status window appears to confirm that the LVP test is underway [Figure 14]. Click on the **OK** button to clear the dialog box.




Figure 14. VLLD Test Status Window

The time required to perform this test depends on whether 3.0 gph, 0.20 gph, or 0.10 gph pressure tests were entered during System Setup (a 0.10 gph test requires the most time to perform).

4. If the LVP test was successful and the alarm is reset (i.e., it was a false alarm), the word **ALARM** will be replaced by **SYSTEM NORMAL** in the System Status section of the Main Screen.
5. If the LVP test fails, you will hear a beep until you click on **ALARM/TEST**. The word **ALARM** will continue to flash in the System Status section of Main Screen [Figure 12 on page 15].

Another method of monitoring this alarm is to click on the **OPERATIONS** button in the **REPORTS** section of the Main Screen (Figure 12 on page 15. For more detailed information see Figure 22 on page 23), then click on **SYSTEM STATUS** in the **REPORTS** scroll window in the top center of the **OPERATIONS REPORTS MENU** screen. Once you have the **SYSTEM STATUS** report on the screen, you will see the alarm message **LINE LEAK SHUTDOWN, GRS- LINE TEST FAIL** (If the alarm resets, this message is erased).

6. If the alarm does not reset, you must call a trained technician who can verify and correct the problem before reenabling the line leak detector.

ALARM Message (PLLD and WPLLD Alarms Only)

These alarms only occur if you have a Pressure Line Leak Detector (PLLD) or a Wireless Pressure Line Leak Detector (WPLLD). When an alarm is signaled, the following sequence of events will occur:

1. The words SYSTEM NORMAL changes to the word ALARM which flashes white then red, and the PC's internal speaker beeps. Click on the **ALARM/TEST** button to silence the audible alarm. (Clicking on this button turns off the beeper only. The word ALARM continues to flash until the problem causing the alarm has been corrected.)
2. A Priority Alarm window appears; in the following examples there are PLLD [Figure 15] and WPLLD [Figure 16] alarms. Cover the dispenser handles or take other measures to prevent them from being lifted. If a pump handle is lifted during the Reenable test, the submersible pump will again be shut down and the alarms reactivated.




Figure 15. PLLD Priority Alarm Window




Figure 16. WPLLD Priority Alarm Window

3. If you click on the **CANCEL** button, the Priority Alarm window disappears from the screen, but no corrective action is taken. Click on the **OK** button to initiate a Reenable test on the sensor (PLLD or WPLLD) that caused the alarm condition. The Priority Alarm window disappears from the screen and a Test Status window appears to confirm that the Reenable test is underway [Figure 17 on page 19 and Figure 18 on page 19]. Click on the **OK** button to clear the dialog box.




Figure 17. PLLD Test Status Window




Figure 18. WPLLD Test Status Window

The time required to perform this test depends on whether 3.0 gph, 0.20 gph, or 0.10 gph pressure tests were entered during System Setup (a 0.10 gph test requires the most time to perform).

4. If the Reenable test was successful and the alarm is reset (i.e., it was a false alarm), the word **ALARM** will be replaced by **SYSTEM NORMAL** in the System Status section of the Main Screen.
5. If the Reenable test fails, you will hear a beep until you click on **ALARM/TEST**. The word **ALARM** will continue to flash in the System Status section of Main Screen [Figure 12 on page 15].

Another method of monitoring this alarm is to click on the **OPERATIONS** button in the **REPORTS** section of the Main Screen (Figure 12 on page 15). For more detailed information see Figure 22 on page 23), then click on **SYSTEM STATUS** in the **REPORTS** scroll window in the top center of the **OPERATIONS REPORTS MENU** screen. Once you have the **SYSTEM STATUS** report on the screen, you will see the alarm message **PLLD (or WPLLD) SHUTDOWN ALARM, GROSS LINE FAIL** (If the alarm resets, this message is erased).

6. If the alarm does not reset, you must call a trained technician who can verify and correct the problem before reenabling the line leak detector.

COMM ERROR Message

When the communication link between the console and the PC is broken for longer than 5 minutes; a **TLS-PC ERROR** window appears in the center of the monitor warning the operator of a Communications Timeout [Figure 19 on page 20], the words **SYSTEM NORMAL** in the **ALARM** section of the main screen changes to **COMM ERROR** and flashes red and white, and the PC internal speaker beeps. You can remove the Communications Timeout window by clicking on the **OK** button; however, the

words COMM ERROR continue to flash and the PC internal speaker beeps until the communications problem has been corrected.



Figure 19. Communications Timeout Window

REPORTS Section

The **REPORTS** section contains buttons to access four report categories; Operations, Setup, Diagnostics, and Regulatory (discussed in greater detail in the Viewing and Printing Reports section below).

PC SETUP Button

Click on the **PC SETUP** button and the PC Setup Screen appears. This screen lets you setup the communication link between your PC and the TLS Console. Also on this screen are tank color selections that appear on the Main Screen [Figure 20].




Figure 20. PC Setup Screen


COMMUNICATIONS SETUP Section

You must verify that each of the settings visible in the **COMMUNICATIONS SETUP** section of the **PC SETUP** screen are correct (click on the arrow to the right of the window to see additional options).

- Port** - Enter the local PC communication port number you used to connect to the TLS Console. Options are COM1, 2, 3, or 4.


The following settings must match the TLS Console settings. Console default settings are shown in Figure 20 on page 20. If different settings were entered during System Setup, enter those settings. If no changes were entered, use the default settings:

- Baud** - 1200 (Options are 300, 1200, 2400, 4800, or 9600)
- Parity** - ODD (Options are EVEN, ODD, or NONE)
- Data Length** - 7 (Options are 7 or 8)
- Stop Bits** - 1 (Options are 1 or 2)
- Security** - The default selection for this window is DISABLED. *If the TLS Console has security enabled then you must select ENABLED. Failure to do so will result in no communication between your PC and the TLS Console.*
- Code** - Enter the TLS Console's six-digit security code if security is enabled. All zeros should be entered if security is disabled.

Important  *For additional communications information, refer to the TLS System Setup manual.*

TANK COLOR Setup

Examine the default tank color assignments visible in the TANK COLOR SETUP section of the PC SETUP screen [Figure 20 on page 20]. Tank numbers correspond to tank number designations that were entered during the TLS Console System Setup procedure. The colors represent product levels in the respectively numbered tank cross sections on the Main Screen and on the Tank Detailed Information screens. Accept or change the default colors shown in the windows for the tanks in your facility. To make a change, click on the arrow button to the right of the color window and click on the desired color.

Important  *For consistency, you may wish to use the color code used by the station to identify their tanks.*

When you finish, click on the OK button to return to the Main Screen.

CONSOLE Button

Clicking on the CONSOLE button displays the Console Mode Screen [Figure 21].




Figure 21. Console Mode Screen

From this screen you can enter any TLS Console command (when the display asks you to press a key, you click on the similarly named button instead).

Important ☞ *This screen allows selective changes to the TLS Console's System Setup and allows you to access all operation and diagnostic functions available in the console. Click on the Exit button to return to the Main Screen.*

POLLING TXRX

Important ☞ *Communication setup using the PC Setup function must first be done before communication between the PC and TLS Console will occur.*

The words POLLING TXRX on the lower right side of the Main Screen indicate when TLS-PC transmits and receives updates from the TLS Console. TX blinks red when a request is transmitted and RX blinks red when a reply is received. This feature can assist in troubleshooting TLS-PC communication errors. For example, if you see blinking TX and no blinking RX, you could have dissimilar BAUD selections, a bad null modem cable, a faulty RS-232 Comm board, a bent or broken cable connector pin, or an inoperative TLS Console.

Tank Detailed Information Screens

On the Main Screen, click on any tank. The Tank Detailed Information screen for that tank appears [Figure 22].




Figure 22. Tank Detailed Information Screen

In addition to displaying more physical tank data than is shown on the Main Screen, the Tank Detailed Information screen also shows the tank’s current alarm limits. Click on the Exit button to return to the Main Screen. One at a time, click on each of the other tanks. As you view each Tank Detailed Information screen you will see similar information for that tank. Return to the Main Screen.

EXIT Button

Clicking on the Exit button quits the TLS-PC program.

TLS-PC Minimize Icon

You have completed the start-up procedure for TLS-PC. At this point you can stay in the Main Screen (the current condition), or you can click on the minimize button (the TLS-PC application is running, but the computer displays another active application and the TLS-PC icon is visible on the desktop or on the task bar. [Figure 23]).



Figure 23. TLS-PC Program Icon

Operator Response to Alarm Conditions

The operator must respond immediately to alarm conditions indicated by the TLS console and/or TLS-PC software program.

When an alarm or warning condition occurs, the TLS console sounds an audible alarm and the alarm and/or warning light indicators flash. (When available, the console displays information concerning the condition.)

The TLS software periodically polls the TLS console for alarm conditions. When the TLS-PC is in the Main Screen and the TLS console is not reporting an alarm, “SYSTEM NORMAL” is displayed on the screen. When TLS-PC is minimized (i.e. the TLS-PC application is running but its window is reduced to an icon at the bottom of the screen), the TLS-PC icon is continuously visible. If TLS-PC is in the Main Screen and an alarm or warning is detected, the “SYSTEM NORMAL” message changes to a flashing “ALARM” message and the internal PC speaker beeps. The TLS-PC icon flashes on and off and the internal speaker beeps, when the program is operating in the minimized state.

Important ☞ *Whenever the TLS-PC program is running and an alarm condition occurs, the internal speaker begins beeping.*

The operator may silence the TLS console audible alarm by selecting the **ALARM/TEST** button on the Main Screen. The operator should enter the Console Mode Screen by selecting the **CONSOLE** button on the Main Screen. The error message displayed on the Console Mode Screen describes the alarm and/or warning condition. The operator must refer to the Troubleshooting section of the *TLS-350 and TLS-350R Operator’s Manual* to determine the appropriate corrective actions.

Viewing and Printing Reports

The content and availability of each TLS-PC report is dependent upon the equipment contained in the system and the parameters that were entered during the TLS Console's System Setup procedure.

You can print out any TLS-PC report to your office printer at any time. You can also print any of these reports to file, saving the report on your hard drive.

Report Categories

Beneath the REPORTS section of the Main Screen are buttons for four report categories. The report(s) contained within each category are listed in the following tables.

Table 2. Operational Menu Reports

OPERATIONAL MENU REPORTS	REPORT AVAILABILITY (Y=Yes, N=No, O=Optional)				
	TLS-PC 300i with Sensors	TLS-PC 300	TLS-PC- 350	TLS-PC 350R with Line Leak	TLS-PC 350R
System Status	Y	Y	Y	Y	Y
Inventory	Y	Y	Y	Y	Y
Delivery Shift	Y	Y	Y	Y	Y
Tank Leak Test	Y	Y	Y	Y	Y
Tank CSLD Test	Y	N	Y	Y	Y
Liquid Sensor Status	Y	N	Y	Y	Y
Vapor Sensor Status	N	N	Y	Y	Y
Groundwater Sensor Status	N	N	Y	Y	Y
2Wire CL Sensor Status	N	N	Y	Y	Y
3Wire CL Sensor Status	N	N	Y	Y	Y
Universal Sensor Status	Y	Y	N	N	N
VLLD Test Results	N	N	Y	Y	N
PLLD Test Results	N	N	Y	Y	N
WPLLD Test Results	N	N	Y	Y	N
Fuel Management Report	N	N	O	O	O
BIR-Daily Row Report	N	N	N	Y	Y
BIR-Daily Column Report	N	N	N	Y	Y
BIR-Shift Row Report	N	N	N	Y	Y
BIR-Shift Column Report	N	N	N	Y	Y
BIR-Periodic Row Report	N	N	N	Y	Y
BIR-Periodic Column Report	N	N	N	Y	Y

Table 3. Setup Menu Reports

SETUP MENU REPORTS	REPORT AVAILABILITY (Y = Yes, N = No)				
	TLS-PC 300i with Sensors	TLS-PC 300	TLS-PC- 350	TLS-PC 350R with Line Leak	TLS-PC 350R
System Setup	Y	Y	Y	Y	Y
Tank Setup	Y	Y	Y	Y	Y
Liquid Sensor Setup	Y	N	Y	Y	Y
Vapor Sensor Setup	N	N	Y	Y	Y
Groundwater Sensor Setup	N	N	Y	Y	Y
2Wire CL Sensor Setup	N	N	Y	Y	Y
3Wire CL Sensor Setup	N	N	Y	Y	Y
Universal Sensor Setup	Y	Y	N	N	N
VLLD Sensor Setup	N	N	Y	Y	N
PLLD Sensor Setup	N	N	Y	Y	N
WPLLD Sensor Setup	N	N	Y	Y	N
BIR Setup	N	N	N	Y	Y

Table 4. Diagnostics Menu Reports

DIAGNOSTICS MENU REPORTS	REPORT AVAILABILITY (Y=Yes,N=No)				
	TLS-PC 300i with Sensors	TLS-PC 300	TLS-PC- 350	TLS-PC 350R with Line Leak	TLS-PC 350R
System Revision Level	Y	Y	Y	Y	Y
Tank Diagnostic	Y	Y	Y	Y	Y
Liquid Sensor Diag	Y	N	Y	Y	Y
Vapor Sensor Diag	N	N	Y	Y	Y
Groundwater Sensor Diag	N	N	Y	Y	Y
2Wire CL Sensor Diag	N	N	Y	Y	Y
3Wire CL Sensor Diag	N	N	Y	Y	Y
Universal Sensor Diag	N	N	Y	Y	Y
VLLD Sensor Diag	N	N	Y	Y	Y
PLLD Sensor Diag	N	N	Y	Y	Y
WPLLD Sensor Diag	N	N	Y	Y	Y
System Priority History	Y	Y	Y	Y	Y
System NonPriority History	Y	Y	Y	Y	Y
Tank Alarm History	Y	Y	Y	Y	Y
Liquid Alarm History	Y	N	Y	Y	Y
Vapor Alarm History	N	N	Y	Y	Y
Groundwater Alarm History	N	N	Y	Y	Y
2Wire CL Alarm History	N	N	Y	Y	Y
3Wire CL Alarm History	N	N	Y	Y	Y
Universal Alarm History	Y	Y	N	N	N
VLLD Alarm History	N	N	Y	Y	N
PLLD Alarm History	N	N	Y	Y	N
WPLLD Alarm History	N	N	Y	Y	N

Table 5. Regulatory Menu Reports

REGULATORY MENU REPORTS	REPORT AVAILABILITY (Y=Yes,N=No)				
	TLS-PC 300i with Sensors	TLS-PC 300	TLS-PC- 350	TLS-PC 350R with Line Leak	TLS-PC 350R
Tank Leak Test History and Sensor Status (Combined)	Y	Y	Y	Y	Y

To View A Report

To view a report, you first select the report category in which the desired report is contained. For example, you want to see an Inventory report which is in the OPERATIONS reports category. Click on the OPERATIONS button in the REPORTS section of the Main Screen. The OPERATONAL REPORTS MENU appears [Figure 24].




Figure 24. Operational Report Menu

Click on the arrow button to the right of the REPORTS window to see the list of available reports. Notice that only three reports appear in the list at any time. Click on the scroll bar down arrow (right of the list) to scroll through the entire list. Click on the scroll bar up arrow to scroll up to the Inventory report. Click on Inventory to select that report. The report appears on the screen [Figure 25].




Figure 25. Inventory Report

Should the lines generated by a report exceed the number visible on the screen, click on the scroll bar's up and down arrows (right of the screen) to scroll through the entire report. Clicking on the CLEAR button clears the screen.

To Print Out A Report

Once a report is displayed, you can print a copy or copies by clicking on the PRINT button in the upper right hand corner. The Print Screen appears [Figure 26].




Figure 26. Print Screen

To initially setup your printer to process TLS-PC report requests, click on the Setup button and the Print Setup Screen appears [Figure 27].




Figure 27. Print Setup Screen

Make the necessary selections to identify your printer type, paper orientation, size, etc. Click on the Options button and the Print Options Screen appears [Figure 28].




Figure 28. Print Setup Options Screen

The Print Setup Options Screen prompts you for additional print choices depending on your printer type. Make selections if necessary and click on the OK button to return to the Print Setup Screen. After making the required choices, click on the OK button to return to the Print Screen. After making the required choices, click on the OK button to print out your report.

To Print A Report To File

To save any report to your hard drive (or a floppy disk), first display the report you want to save. Click on the PRINT button in the upper right corner of the screen. After the Print Screen [Figure 26 on page 28] reappears, click in the empty Print to File box. An X appears in the box. Click the OK button and the Print-To-File Screen will appear [Figure 29].




Figure 29. Print-To-File Screen

Type in a path\file name for the report. For example, you decide to establish monthly directories on your “C” hard drive containing TLS-PC reports, further separated by the day of the month. Today is January 1 and you want to print-to-file a copy of the Inventory Report and save it on your hard drive. You type c:\Jan\inven.01 and click the OK button. A file of the inventory report is saved in the designated location on your hard drive, and you are returned to the Report Screen. Click on the Exit button to return to the Main Screen.

Printing Out A Stored Report

You can print out a report once you print it to file; however, you can only print one report at a time, and you must enter a dos command screen in Windows to do so. The procedure to print out a stored report file is as follows:

- You need to show drive designation and directory.
- Make Program Manager the active window. Double click on the **Main** group icon.
- Double click on the **MS-DOS Prompt** icon.
- Type **print**, press the space bar, type the report’s path and file name, then press **Enter**.
- Repeat this process to print additional copies or different reports.
- Type **exit** then press the **Enter** key to return to Windows.

BIR Manual Adjustments

For TLS-PC systems with Basic Inventory Reconciliation (BIR), you can enter manual BIR adjustments from TLS-PC as follows.

1. From the Main Screen, click on the **OPERATIONS** button in the REPORTS section. The OPERATIONS REPORTS MENU screen appears [Figure 1].




Figure 30. Operations Report Menu

2. Click on the **BIR Adjust?** button. The Set Manual Adjustment Value window appears on the REPORTS window [Figure 31].




Figure 31. Set Manual Adjustment Value Window

3. First select either Shift (then you must select Previous Shift or Current Shift) or Daily, the Tank number for which the adjustment will be entered, the Closing Month and Day, and then enter in the Adjustment Value window, the amount of adjustment (e.g., gallons, liters, or imperial gallons - depending on the units entered in System Setup) for the selected day.
4. Click on the **SET** button to enter the BIR adjustment value into the system. The current date and time; and the tank number, product label, adjustment closing date, and adjusted volume appears on the REPORTS screen [Figure 32].




Figure 32. BIR Manual Adjustment Entered

5. Click on the **Exit** button in the Set Manual Adjustment Value window to remove this window. Click on the **Exit** button on the OPERATIONAL REPORTS MENU to return to the Main Screen.

Sales Offices

Veeder-Root has offices around the world to serve you.

Headquarters

Veeder-Root Company
125 Powder Forest Drive
Simsbury, CT 06070-7684 U.S.A.
(860) 651-2700 FAX: (860) 651-2719

England

Veeder-Root Environmental Systems Limited
Hydrex House, Garden Road
Richmond, Surrey TW9 4NR ENGLAND
44-181-392-1355

Brazil

Veeder-Root do BRASIL
Rua ado Benatti, 92
Caixa Postal 8343
01051 Sao Paulo BRAZIL
55-11-861-2155

Germany

Veeder-Root GmbH
Uhlandstrasse 49
D-78554 Aldingen GERMANY
49 (0)7424 1400

France

Veeder-Root SARL
ZI des Mardelles
94-106 rue Blaise Pascal
93600 Aulnay-sous-Bois FRANCE
33 (0)1 4879 5599

Canada

Veeder-Root Canada
151 Superior Boulevard, Suite 24
Mississauga, Ontario, L5T 2L1 CANADA
905-670-2755

Singapore

Veeder-Root Singapore
246 MacPherson Road
#08-01 Betime Building
348578 Singapore
65 745 9265

Mexico

Veeder-Root Mexico
Prado de las Camelias
No. 4483-4
Praddos Tepeyac C.P. 45500
Zapopan, Jal., MEXICO
(52) 36-47-3750

