

# INSTALLATION INSTRUCTIONS

## HIGHLINE™ -111B BEZEL GLASS REPLACEMENT KIT K89761

---

The above kit is for field replacement of Highline-111B Bezel Glass. This kit has the LED openings.

1. Remove bezel assembly from dispensing unit. Place face down on a clean cloth.
2. If equipped with a glass window (beveled corners):
  - Remove and discard metal clamping piece securing glass.
  - Cut around sealant with a sharp knife and remove glass.

If equipped with a plastic window (holes at corners):

  - Remove four mounting screws, then remove plastic window.
3. Clean off sealant or gasket using a sharp putty knife. Be sure groove (recessed area) in bezel is free of sealant or gasketing material.
4. Place new gasket in groove.
5. Place new glass assembly on top of gasket.
6. Secure with original screws.  
Screws are to be tight, but avoid overtightening and damage to window glass.