

INSTRUCTIONS FOR INSTALLING TOTALIZER CABLE, SERIES 9800A/2600A FACTORY KIT

This instruction sheet shows how to install the totalizer cable for Series 9800A/2600A pumps and dispensers. The available kits are listed below. Refer to the table to determine the contents for each kit.

KIT SUMMARY

039851	Model 9840A, 2640A, Gallon
039852	Model 9840A, 2640A, Liter
039853	Model 9800A, 9800ATW1, 9800ATW2, 9800AXTW, Liter Model 2600A, 2600ATW1, 2600ATW2, 2600AXTW, Liter
039854	Model 9800A, 9800ATW1, 9800ATW2, 9800AXTW, Gallon Model 2600A, 2600ATW1, 2600ATW2, 2600AXTW, Gallon
039873	Model 9840AX, 2640AX, Gallon
039874	Model 9840AX, 2640AX, Liter
039837	Model 9850A, 9850AX, 2650A, 2650AX, Liter
039838	Model 9850A, 9850AX, 2650A, 2650AX, Gallon
039842	Model 9850AXTW, 2650AXTW, Liter
039843	Model 9850AXTW, 2650AXTW, Gallon

KIT CONTENTS

		039851	039852	039853	039854	039873	039874	039837	039838	039842	039843
Odometer Assy., Liter	039872	-	2	1	-	-	2	-	-	-	-
Odometer Assy., Liter, 9850A	039836	-	-	-	-	-	-	1	-	2	-
Odometer Assy., Gallon	039871	2	-	-	1	2	-	-	-	-	-
Odometer Assy., Gallon, 9850A	039826	-	-	-	-	-	-	-	1	-	2
Bracket, Odometer	015129	-	-	-	-	-	-	-	-	-	-
Pin, Spirol, 1/16 x 1/2	043220	2	2	1	1	2	2	1	1	2	2
Cable Assy., Drive 9-dig. tot	017366	2	2	-	-	1	1	1	1	-	-
Cable Assy., Drive 9-dig. tot	017365	-	-	1	1	1	1	-	-	2	2
Pin, Cotter, 3/64 x 1/2	042290	2	2	1	1	2	2	1	1	2	2
Tie-wrap	0M0042	2	2	1	1	2	2	1	1	2	2
Tie-wrap, 8"	C08126	2	2	1	1	2	2	1	1	2	2

Turn this sheet over for installation notes.

- Attach tie-wrap around plastic cable cover and through odometer bracket.
- Upper drive cable connects to pulser at front of pump (9840A/2640A AC J-Box side; 9840AX/2640AX DC J-Box side, left meter)
- Lower drive cable connects to pulser at rear of pump (9840A/2640A)
- Lower drive cable connects to pulser at front of unit (9840AX/2640AX DC J-Box side, right meter)
- For all models except 9850A, attach the C08126 tie-wrap to pulser conduit; for 9850A models, attach tie-wrap to DC conduit.

