

Gasboy RPS
Special Card Handler

Version 001

part number: C35926

Gasboy International LLC
P. O. Box 309
Lansdale, PA 19446

Copyright 2003 by Gasboy International LLC
All rights reserved.
Printed in the United States of America.

The information in this document is confidential and proprietary. No further disclosure thereof shall be made without permission from Gasboy International LLC.

Gasboy International LLC believes that the information in this document is accurate and reliable. However, we assume no responsibility for its use, nor for any infringements of patents or other rights of third parties resulting from its use. We reserve the right to make changes at any time without notice.

REVISION RECORD OF THIS DOCUMENT		
Part No.	Date Published	Release Levels
C35926	March 8, 1999	Version 001
C35926	March 12, 2003	Version 001

001

Gasboy RPS Special Card Handler

This special Card handler is used to locally authorize NTS cards with ISO number 56617101.

Cards Affected:
NTS cards

Overview

When an NTS card is swiped, it will be converted into a Gasboy Club card and locally authorized. This handler will ignore all other cards.

The first field of the club card will be the 11 digit card number taken from the account number of the NTS card.

The second field will be a 6 digit Unit number manually entered by the user.

The third field will be a 2 digit type field. The first digit will be 0,1,2, or 3 and will be taken from the Option Data Prompt field of the NTS card. The second digit of the type field will be 0 if the first digit is 0, if not, it will be derived from the manually entered data and the following table:

Type	Range	Digit
Van	70000 - 99998	1
Tractor	10001 - 11998	2
Tractor	14000 - 17999	2
Tractor	100000 - 199999	2
Switcher	12000 - 12998	3
Straight Truck	13000 - 13999	4

An NTS card will prompt for manual entry of unit number, and odometer entry. It will allow all fuels and have no limits. Price code 0 will be used unless the manual entered number is within one of the following ranges:

Contractor Owned Line haul Tractors	1000 - 9800
Contractor Owned P&D Tractor	18000 - 18999
RPS Owned P&D Tractors	10000 - 11999
RPS Owned Switch Tractors	12000 - 12999

A receipt will be printed on printer # 1 after every transaction.

Configuration

The Site Controller must be configured to prompt for vehicle #.

Sys_Par.bin

Use local verification (reader): Club

Use local verification (console): Club

Console.bin, menu 3

POS asks for auxiliary # on fuel sale: Card Encoded

POS ask for auxiliary # on merchandise: Card Encoded

Auxiliary number prompt: Enter unit # (or any other appropriate message)

Reader.bin, menu 1

Below is an example of the reader program settings that will work for RPS:

#	Ty	S/D	DISPLAY	WHILE ENTERING	OPTIONS
1	1	!	< < Slide Card < < !	!	!
2	4	8 !	\$ Amount or FILL	!\$ Amount	!
3	3	12 !	PIN ?	!Your PIN	! Optional Auto-enter Masked
4	7	6 !	Hub/Odo ?	!Hub/Odo	! Optional
5	6	6 !	Enter Unit #	!Unit #	! Optional
6	2	2 !	Select pump	!Pump	! Auto-enter
7	8	!	Please Wait	!	!
8	13	0 !	P#XX	!	!
9	14	2 !	^ Ok for \$0000.00	!	!
10	9	!		!	!
11		!	!-----END-----!	!	!