

## Technical Service Notification

### Console Software Version for site conversion to Balance ISD

**Consoles:** TLS-350 Consoles running ISD

**Notice:**

Customers converting a TLS-350 with Assist ISD to a Balance ISD must validate the TLS-350 Console Software version before performing the conversion.

The TLS-350 Software version must be 346328-100-C or later. If the console is not at the required software version the console must be upgraded to the latest certified software version listed in the balance phase II EVR Executive Order VR-204

Balance ISD was certified beginning in version 346328-100-C.

The following table indicates which TLS Console Software versions containing ISD 1.01 can be used for both ISD Assist and ISD Balance.

<b>TLS Console Software</b>	<b>Assist ISD: 1.01</b>	<b>Balance ISD 1.01</b>
346327-100-C	<b>X</b>	
346327-100-D	<b>X</b>	
346327-100-E	<b>X</b>	
346328-100-A	<b>X</b>	
346328-100-B	<b>X</b>	
346328-100-C	<b>X</b>	<b>X</b>

Consoles with incorrect software will not pass VR204-Q, Balance Phase II EVR Systems. Including ISD Systems, Exhibit 17, ISD Vapor Flow Meter Operability Test Procedure

To determine the TLS-350 Software version perform the following steps:

1. Press the [Mode] key until DIAG MODE is displayed
2. Press the [Function] key until SYSTEM DIAG is displayed
3. Press the [Step] key to Software#, the software version is now displayed

If you have any questions please contact technical Support at 800-323-1799 or at [technicalsupport@veeder.com](mailto:technicalsupport@veeder.com)