

Field Service Bulletin

Marley Pump 500 E. 59th Street Davenport, IA 52807 Tel: (800) 262-7539 (319) 391-8600 Fax: (800) 304-7502

Marley Pump Europe Gijsbert Stoutweg 8 4005 LE Tiel, Holland Tel: 31/34 461-7909 Fax: 31/34 462-2408

Marley Pump Asia 46 East Coast Road #04-04 Palace Centre Singapore 428766 Tel: 65/345-4960 Fax: 65/345-4843 Date: March 3, 2000


Attention: Red Jacket Distributors

Subject: CpT Transducer Scotchcast Kit

Improper use of the Scotchcast Kit included with the Red Jacket pressure transducer can cause *Transducer Failure*.

Step by step scotchcast kit installation instructions are include with every scotchcast kit. The scotchcast kit should be warm to the touch before inserting the transducer connections into the resin bag. The warmth indicates that two chemicals in the scotchcast kit have bounded and the epoxy is ready. All layers of the transducer cable insulation including the outer jacket must be sealed by the epoxy. If all layers of insulation are not sealed then water can wick through the unsealed insulation layer. Do not use the white wire when connecting the pressure transducer, this may be clipped.

Thank you for your continued support of Red Jacket. For additional information, please contact your Red Jacket Regional Sales Manager or Red Jacket Technical Service at 1-800-952-8348.



All wiring, including outer jacket should be completely submerged in epoxy.



FSB-311 02/00