


Let's say a customer wants to buy a hot dog and a six pack of beer at the Express Lane™ kiosk. Express Lane™ alerts the cashier at their workstation that a customer needs help with an age-restricted item.

HERE'S HOW.



FROM THE CASHIER WORKSTATION:

1. When the Customer at the Express Lane Self-Checkout kiosk enters an Age Restricted item or requests Help, Passport's POS screen shows the Control Console button flashing red.

2. The Cashier clicks "Control Console" button.



3. The Self-Checkout lanes appear, Cashier finds the Lane that needs help and assists customer as needed.

4. To return to the Cashier's selling screen, click "Swap To POS".



TA-DA! YOUR CASHIER IN TWO PLACES AT ONCE. **IT'S NOT MAGIC, IT JUST MAKES SENSE.**

