

600 SERIES NOZZLE BOOT ASSEMBLY INSTRUCTIONS

The 600 Series nozzle boot is shipped loose in the box to avoid possible detachment and breakage due to rough handling during shipping.

The following loose items should be in the box:

- 1 003807 Nozzle Boot
- 2 053903 Flat-Head Machine Screws, 1/4-20 x 1/2" long

Attach the nozzle boot to the unit using the two flat-head machine screws as shown in the illustration below.

