

Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2

Kit Part Numbers	Brief Description
RF00022-XX	G7 15 inch OVATION 2, Black Kit
RF00062-XX	G7 12 inch OVATION 2, Black Kit
RF00059-XX	G7 15 inch Ovation 2, Colored Kit



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2

Release History

Version	Prepared by	Date	Change description
0	A. Hemus	23/06/2020	Created
1	Michael Doh	8-Jul-2020	Review and updates for initial draft
2	Michael Doh	16-Jul-2020	UL comments addressed
3	Michael Doh	03-Aug-2020	UL comments addressed
4	Michael Doh	6-Aug-2020	Corrected ADA/NFC gasket part numbers
5	Jojie Adigue	22-Oct-2020	Added new colored kit (RF00059-XX)
6	Michael Doh	03-Dec-2020	Printer reference, photo and type corrections
7	Jojie Adigue	20-Jan-2021	OPT modules installed at the factory instead
8	Michael Doh	14-Feb-2021	Corrected kit contents
9	Michael Doh	02-Sep-2021	Included Canada Certification
10	Michael Doh	20-Sep-2021	Added note to review the complete document prior to installing
11	Shibani Joshi	23-Feb-2022	Pump Interface Board (PIB) install procedure added and PSU assembly P/N changed from EZ0429 to EZ0702
12	Shibani Joshi	13-Apr-2022	UL Comments addressed
13	Shibani Joshi	21-Jun-2022	UL Comments addressed

	Document Number	DCV-00537
iN/ENCO	Date Released	Jun. 2022
	Revision Number/Security level	R14 S2
Retrofit G7 12 inch or 15 inch + InvencoLink / PIB Wayne Ovation 2 (Canada &		
US) Installation Guide		

14	Shibani Joshi	28-Jun-2022	UL Comments addressed
----	---------------	-------------	-----------------------

© 2022 by Invence Group Limited All rights reserved No part of this document may be copied or reproduced in any form without prior written consent from Invenco. Invenco has taken great effort to verify the accuracy of this document but assumes no responsibility for any technical inaccuracies or typographical errors



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2

Contents

R	elease	Hist	ory	2
1	Intr	oduct	tion	6
	1.1	Тоо	Is Required	9
	1.2	Inst	allation Kit Contents	10
	1.2	.1	G7 15 inch (G7-100 SDC-15) Outdoor Payment Terminal (OPT) system, Bla	ck
	(RF	0002	22-XX):	10
	1.2	.2	G7 Outdoor Payment Terminal (OPT) system, Black (RF00062-XX):	14
	1.2	.3	G7 Outdoor Payment Terminal (OPT) system, Colored (RF00059-XX):	16
2	Saf	ety &	Compliance Information	20
	2.1	Prel	iminary Precautions	20
	2.2	Eme	ergency Total Electrical Shut-Off	20
	2.3	Tota	al Electrical Shut-Off Before Access	20
	2.4	Eva	cuation, Barricading and Shut-Off	20
	2.5	Rea	d the Manual	20
	2.6	Foll	ow the Regulations	21
	2.7	Rep	lacement Parts	21
3	Saf	ety S	ymbols and Terminology	21
	3.1	Prev	vent Explosions and Fires	22
	3.1.	.1	No Open Flames	22
	3.1.	.2	No Sparks - No Smoking	22
	3.1.	.3	Working Alone	22
	3.1.	.4	Working with Electricity Safety	22
	3.1.	.5	Hazardous Materials	23
	3.1.	.6	In an Emergency	23
	3.1.	.7	Approvals	23
	3.1.	.8	Laser Warning	23
	3.2	Con	nputer Programs and Documentation	24
4	Inst	allati	on Guide	25
	4.1	Disa	assembly Procedure	25
	4.2	Pre	Installation Procedure	42
	4.2.	.1	Replace the Panel Gaskets Error! Bookmark not define	ed.
	4.2.	.2	Install the InvencoLink Converter	42
	4.2.	.3	Install the Pump Interface Board (PIB)	42
	4.3	Inst	Allalion Procedure	43
	4.3	.1	New Door Preparation	43
	4.3	.2	install the Power Supply (EZU/UZ)	02



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2

	4.3.3	Install the New Door to the Dispenser	70
	4.3.4	Install the Cables and Wiring to the Dispenser Door	72
	4.3.5	Completing the installation	74
5	First Pov	ver-Up	74



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2

1 Introduction

The documentation provides some basic guidelines for installing the G7 or the G7 15 inch (G7-100 SDC-15) Outdoor Payment Terminal (OPT) system:

- G7 15 inch (G7-100 SDC-15) Outdoor Payment Terminal (OPT) system, Black: Kit part number: RF00022-XX
- G7 Outdoor Payment Terminal (OPT) system, Black: Kit part number: RF00062-XX
- G7 15 inch (G7-100 SDC-15) Outdoor Payment Terminal (OPT) system, Colored; Kit part number: RF00059-XX

For a double-sided installation, two of these Kits are required.

IMPORTANT NOTE: The installer must review the entire installation guide prior to starting any work on the dispenser. If the construction of the dispenser in the installation guide does not match the construction of the dispenser being retrofitted, then do not proceed with the installation and contact customer service.

This Retro-Fit Kit can be installed into either Side A or Side B of a Wayne Ovation2 dispenser;

• For a single-sided installation, or if this Kit will be installed into Side A (i.e. the first side installed) of a double-sided installation, it MAY require the pre-installation of UL Listed by Report Retrofit Kit Part Number RF00033-XX (Invenco Link Converter) before installation into the dispenser. The process is covered in §4.3.2 Install the Dispenser Invenco Link converter to the PSU Pane procedure of this instruction, by reference to the instructions in that Kit

Note: The Invenco Link is only required if the ethernet cable is not installed in the JADE Board as per step 8.b of the Disassembly process. This should be checked prior to the installation.

This installation MAY require the pre-installation of UL Listed by Report Retrofit Kit Part Number RF00100-XX (Pump Interface Board) before installation into the dispenser. The process is covered in §4.2.3 Pre-Installation Procedure of this instruction, by reference to the instructions in those Kits.



Note: The PIB Installation is only for the G7 15 inch OPT (RF00021-XX and RF00048-XX)

Note: The PIB is only required if the Current Loop Cable is not connected to the Pump Control Board as per step 8.e of the Disassembly process. This should be checked prior to the installation.

Note: The PIB can only be installed in a double-sided pump. The pre-installation will be required on side B of the dispenser.

 For each side installation, a printer kit is also required to be installed with this kit. Following the completion of the installation of this kit, it requires the installation of UL Listed by Report Retrofit Kit Part Number RF00038-XX (Retrofit G7 Black Printer Wayne Ovation, for installation with the black G7 OPT system kits RF00022-XX or RF00062-XX) or RF00058-XX (Retrofit G7 Colored Printer Wayne Ovation, for installation with the colored G7 OPT system kit RF00059-XX), by referencing the instructions in that kit (DCV-00464).

Refer to the below flowchart for further reference:



US) Installation Guide





Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2

1.1 Tools Required

The following tools are required to mount the G7 or the G7-15 inch (G7-100 SDC-15) OPT:

- Torx T25 security screwdriver
- Philips #1 screwdriver
- Philips #1 screwdriver with >5" shaft
- Flat 5mm screwdriver
- Small adjustable spanner
- Side cutters
- Cable (zip) ties
- Pliers
- ¹/₄" Socket or Nut Driver
- Small flat blade scraper or putty knife.
- Towelling cleaning rags.
- Household sticky residue remover containing limonene
- 100% Isopropyl Alcohol (IPA) cleaner.



WARNING Do NOT use power tools if working on a fuel station forecourt.

Any spark could cause an explosion.



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2

1.2 Installation Kit Contents

1.2.1 G7 15 inch (G7-100 SDC-15) Outdoor Payment Terminal (OPT) system, Black (RF00022-XX):

Unpack the G7 Retro-Fit Kit (RF00022-XX) and check that all the parts listed below are present. Also refer to the pre-installation procedure (section 6.1.) relating to the communication method parts.

Retrofit Kit Contents		
Part Number	Description	Illustration
RP00022-XX	Replacement Ovation 2 door assembly, G7 15"	



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2

EZ0702	PSU Plate Assembly with cables	
MP0985 (497-0515361)	Ovation PSU Bracket	
DK0015 (497-0518659)	PPU lens gasket, Ovation 2	



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2

EP0095 (497-0518661)	Customer Display Lens Gasket	
	Cables kit con	nprising of:
EK0127 (497-0513684)	Wayne Pump to InvencoLink	
EK0131 (497-0513384)	Cat-5e, Flexible, YELLOW	
EK0137 (497-0513683)	Wayne Pump to Pump Adaptor	
2 x EK0132 (497-0513687)	Grounding cable	



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2

Ovation Fastener kit, comprising of:

2x MN0029: #8-32 Lock Nuts (ext. washer)

Ovation 2 Fastner kit, comprising of:

29 x MS0050 (006-8625469): 3mm Hex Key Screws

6 x MW0057 (006-8625470): #8 Sealing Washers

4 x MS0253 (006-8626488): #6-19 x ¹/₂" Pan head philips screw (security switch scew)

2 x MN0077 (006-8611471): 1/4-20 Nuts



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2

1.2.2 G7 Outdoor Payment Terminal (OPT) system, Black (RF00062-XX):

Unpack the G7 Retro-Fit Kit (RF00062-XX) and check that all the parts listed below are present. Also refer to the pre-installation procedure (section 6.1.) relating to the communication method parts.

Retrofit Kit Contents		
Part Number	Description	Illustration
RP00062-XX	Replacement Ovation 2 door assembly, G7 12"	
EZ0702	PSU Plate Assembly with cables	



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2

MP0985 (497-0515361)	Ovation PSU Bracket	
DK0015 (497-0518659)	PPU lens gasket, Ovation 2	
EP0095 (497-0518661)	Customer Display Lens Gasket	



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2

Cables kit comprising of:			
EK0127 (497-0513684)	Wayne Pump to InvencoLink		
EK0131 (497-0513384)	Cat-5e, Flexible, YELLOW		
EK0137 (497-0513683)	Wayne Pump to Pump Adaptor		
2 x EK0132 (497-0513687)	Grounding cable		
	Ovation Fastener ki	t, comprising of:	
2 x MN0029 : #8-32 Lock Nuts (ext. washer)			
	Ovation 2 Fastner kit, comprising of:		
29 x MS0050 (006-8625469): 3mm Hex Key Screws			
6 x MW0057 (006-8625470): #8 Sealing Washers			
4 x MS0253 (006-8626488): #6-19 x ½" Pan head philips screw (security switch scew)			
2 x MN0077 (006-8611471): ¼-20 Nuts			

1.2.3 G7 Outdoor Payment Terminal (OPT) system, Colored (RF00059-XX):

Unpack the G7 Retro-Fit Kit (RF00059-XX) and check that all the parts listed below are present. Also refer to the pre-installation procedure (section 6.1.) relating to the communication method parts.



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2

Retrofit Kit Contents		
Part Number	Description	Illustration
RP00059-XX	Replacement Ovation 2 door assembly, G7 15", Colored	
EZ0702	PSU Plate Assembly with cables	



Document Number	DCV-00537	
Date Released	Jun. 2022	
Revision Number/Security level	R14 S2	

MP0985 (497-0515361)	Ovation PSU Bracket	
DK0015 (497-0518659)	PPU lens gasket, Ovation 2	
EP0095 (497-0518661)	Customer Display Lens Gasket	



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2

Cables kit comprising of:			
EK0127 (497-0513684)	Wayne Pump to InvencoLink		
EK0131 (497-0513384) Cat-5e, Flexible, YELLOW			
EK0137 (497-0513683) Wayne Pump to Pump Adaptor			
2 x EK0132 (497-0513687)	Grounding cable		
	Ovation Fastener kit, comprising of:		
2 x MN0029 : #8-32 Lock Nuts (ext. washer)			
	Ovation 2 Fastner ki	it, comprising of:	
	29 x MS0050 (006-8625469): 3mm Hex Key Screws		
6 x MW0057 (006-8625470): #8 Sealing Washers			
4 x MS0253 (006-8626488): #6-19 x ½" Pan head philips screw (security switch scew)			
2 x MN0077 (006-8611471): ¼-20 Nuts			



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2

2 Safety & Compliance Information

This section introduces the hazards and safety precautions associated with installing, inspecting, maintaining or servicing the G7 or G7 15 inch (G7-100 SDC-15). Before proceeding, check the relevant hazard and safety information. Fire, explosion or electrical shock could occur and cause death or serious injury if these safe service procedures are not followed.

2.1 Preliminary Precautions

You are working in a potentially dangerous environment of flammable fuels, vapour, and high voltage. Only trained or authorized individuals knowledgeable in the related procedures should install, inspect, maintain or service this equipment.

2.2 Emergency Total Electrical Shut-Off

Locate the forecourt emergency fuel shut-off valves and electrical isolation breakers. Understand how to use these, should they be required. Locate the switch or circuit breakers that shut-off all power to all fueling equipment and dispensing devices.

2.3 Total Electrical Shut-Off Before Access

Any procedure requiring access to electrical components or the electronics of a pump/dispenser requires total electrical shut-off of that unit. Understand the function and location of this switch or circuit breaker before inspecting, installing, maintaining, or servicing the Invenco OPT

2.4 Evacuation, Barricading and Shut-Off

Any procedures requiring accessing a pump/dispenser head requires the following three actions:

- An evacuation of all unauthorized persons and vehicles
- Using safety tape or cones as barricades to the effected units
- A total electrical shut-off of the affected unit(s)

2.5 Read the Manual

Read, understand and follow this manual and any other labels or related materials supplied with the equipment. If you do not understand a procedure, call an Invenco Authorized Service Centre or Invenco



Service Officer. It is imperative to your safety and the safety of others to understand the procedures before beginning work.

2.6 Follow the Regulations

Regulations in OSHR (Occupational Safety and Health Regulations), national, state and local codes, including customer requirements must be followed. Failure to install, inspect, maintain or service this equipment in accordance with these codes, regulations and standards may lead to legal citations with penalties and may affect the safe use and operation of the equipment.

2.7 Replacement Parts

Use only genuine Invenco replacement parts and retrofit kits on your installation. Using parts other than genuine Invenco replacement parts could create a safety hazard and violate local regulations.

3 Safety Symbols and Terminology



This safety alert symbol is used in this manual and on warning labels to alert you to a precaution which must be followed to prevent potential personal safety hazard. Obey safety directives that follow this symbol to avoid possible injury or death.

Signal Words

These signal words used in this manual and on warning labels tell you the seriousness of particular safety hazards. The precautions below must be followed to prevent death, injury or damage to the equipment:

DANGER:	Alerts you to a hazard or unsafe practice which will result in death or serious injury.
WARNING:	Alerts you to a hazard or unsafe practice that could result in death or serious injury.
CAUTION:	Designates a hazard or unsafe practice which may result in minor injury, property or equipment damage.

Working with Fuels and Electrical Energy



Prevent Explosions and Fires 3.1

Fuels and their vapors may explode or burn if ignited. Spilled or leaking fuels cause vapors. Even filling customer tanks will cause potentially explosive vapors in the vicinity of dispenser or island.

3.1.1 No Open Flames



Open flames from matches, lighters, welding torches or other sources can ignite fuels and their vapors.

3.1.2 No Sparks - No Smoking



Sparks from starting vehicles, starting or using power tools, burning cigarettes, cigars or pipes can also ignite fuels and their vapor. Static electricity, including an electrostatic charge on your body, can cause a spark sufficient to ignite fuels and their vapors. After getting out of a vehicle, touch the metal of your vehicle to discharge any electrostatic charge before you approach the dispenser island.

3.1.3 Working Alone

It is highly recommended that someone who is capable of rendering first aid be present during servicing. Be familiar with Cardiopulmonary Resuscitation (CPR) methods if you are working with or around high voltages. This information is available from the First Aid training providers. Always advise the station personnel about where you will be working and caution them not to activate power while you are working on the equipment. Use the OSHA Tag-out/Lockout procedures. If you are not familiar with this requirement, refer to information in the relevant manual and OSHA documentation.

3.1.4 Working with Electricity Safety

Ensure that you use safe and established practices in working with electrical devices. Poorly wired devices may cause a fire, explosion or electrical shock. Ensure that grounding connections are properly made. Take care that sealing devices and compounds are in place. Ensure that you do not pinch wires when replacing covers. Follow OSHA Tag-out/Lockout requirements. Station employees and service contractors need to understand and comply with this program completely to ensure safety while equipment is down.

For Canada: Follow all applicable requirements in Canadian Electrical Code (CE Code), CSA C22.1.

For USA: Follow all applicable requirements in NFPA 30, 30A and 70, and those of the Local Authority Having Jurisdiction for electrical wiring.



R14 S2

Retrofit G7 12 inch or 15 inch + InvencoLink / PIB Wayne Ovation 2 (Canada & US) Installation Guide

3.1.5 Hazardous Materials

Some materials present inside electronic enclosures may present a health hazard if not handled correctly. Be sure to clean hands after handling equipment. Do not place any equipment in mouth.

3.1.6 In an Emergency

Compile the following information in case of emergency:

- Location of accident (e.g. address, front/back of building, etc.) •
- Nature of accident (e.g. possible heart attack, struck by a vehicle, burns, etc.) •
- Age of victim (e.g. baby, teenager, middle-age, elderly). •
- Whether or not victim has received first aid (e.g. stopped bleeding by application of pressure etc.) •
- Whether or not victim has vomited (e.g. if swallowed or inhaled something etc.) •

IMPORTANT:

Oxygen may be needed at scene if gasoline has been ingested or inhaled. Seek medical advice immediately.

3.1.7 Approvals

Invenco develops and maintains its hardware and software products using industry-standard quality processes and is audited by various bodies.

The Invenco G7 or G7 15 inch (G7-100 SDC-15) Modules have a UL File References of E469526 and E480135 and carry labels similar to this:



The Invenco Retro-Fit Kit has UL File Reference of MH.61528

3.1.8 Laser Warning

Some modules of the G7 or G7 15 inch (G7-100 SDC-15) OPT may incorporate a barcode reader. The barcode reader incorporates a laser aiming system. The Laser has a Class 2 output power to IEC 60825-1:2007 / ANSI Z136.1



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2



3.2 Computer Programs and Documentation

All Invenco Group Ltd. computer programs (including software on discs and within memory chips) and documentation are copyrighted by, and shall remain the property of, Invenco Group Ltd. Such computer programs and documents may also contain trade secret information. The duplication, disclosure, modification, or unauthorized use of computer programs or documentation is strictly prohibited, unless otherwise licensed by Invenco Group Ltd.



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2

4 Installation Guide

- 1. Please ensure all safety procedures are followed per requirement by the customer before installing the retrofit kit.
- 2. Remove power to Pump and follow the OSHA Lock-out/Tag-out procedures.



WARNING

Failure to turn off the unit during installation of the kit may cause injury or bodily harm from electrical shock. Ensure that all power to the unit is switched off before opening the door of the unit and during kit installation.

3. This installation will require various panel replacements. The panels will be removed from the door and replaced with pre-built panels with the OPT modules pre-fitted.

4.1 Disassembly Procedure

Before installation of the equipment can take place, the existing door assembly must be removed from the dispenser. This section covers the removal of these components including:

- Removal of reused components, e.g. PPU panel
- Unused cables and wires from door components

<u>Note</u>: Throughout this disassembly procedure there are many cable assemblies that will be unplugged and will not be reused. It is up to the discretion of the installer whether to remove these cables or position them inside of the dispenser cavity. The loose cables need to be bundled and restrained using zip-ties or cable restraints. After the cables have been bundled, they must be placed in a location that will not cause obstruction, exposure, or hazard.

Note: It may be necessary to disconnect cable assemblies on various boards during this disassembly procedure in order to more easily access other components. Disconnect these cables as necessary. It is recommended that the installer of this kit either re-connect these cables immediately afterwards or mark each disconnected cable before it is unplugged to make it easier to identify when it comes time for re-installation.

	Document Number	DCV-00537
<i>iNVENCO</i> °	Date Released	Jun. 2022
	Revision Number/Security level	R14 S2
Retrofit G7 12 inch or 15 inch + InvencoLink / PIB Wayne Ovation 2 (Canada &		
US) Installation Guide		

- 1. Shut off the main power to the dispenser before beginning the deinstallation
- 2. Identify Side A and Side B.
 - a. Locate the Serial Plate on the side of the dispenser.



Serial Plate

If a Serial Plate is not present, Side B can be identified once the Pump has been opened. The IGEM Board will be located inside the electronic cabinet on Side A.

- NOTE:
- 3. Open the dispenser.
 - a. Use a Wayne Security Key to unscrew the two security bolts located on the left side of the dispenser electronics door.



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2



Security Bolts

b. Open the Electronics door and engage the Prop Rod.



Door Prop

4. Remove the PPU panel.



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2



PPU Panel Removal

a. Two wires are connected to the PPU panel. Connection J8 is power. Connection J1 is comm to the Customer Display Node. Detach both cables. The cable connected to J8 can be discarded. The connection to J1 must be retained.



Connectors J1 & J8

b. Detach all PPU Flex Cables from the PPU panel.



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2



Flex Cable Removal

Note:

Record the positions of the PPU paddles so they can be reinstalled in the correct position

c. Unscrew with a 3mm Hex Key the 6 screws holding the PPU Panel from the door and set aside to be reinstalled. Discard the Screws.



Hex Screws



- 5. Remove the Metal Cosmetic Cover.
 - a. Unscrew the 6 Hex screw and washer assemblies attaching the cover to the door. Discard the washer and screw assemblies.



Hex screws & Washers

b. Pull away the PPU Cosmetic Cover and retain.



PPU Cosmetic Cover



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2

- 6. Remove the PPU Screen Lens.
 - a. Unscrew the Lens Cover from the door using a 3mm Hex Key. Retain the Lens Cover and discard the hardware.



Lens Cover Removal

b. Remove and retain the PPU Lens.



PPU Lens

	Document Number	DCV-00537
iN/ENCO	Date Released	Jun. 2022
	Revision Number/Security level	R14 S2
Retrofit G7 12 inch or 15 inch + InvencoLink / PIB Wayne Ovation 2 (Canada &		
US) Installation Guide		

7. Remove the PPU Paddles.

Note:

Record the positions of the PPU paddles so they can be reinstalled in the correct position

a. Using a 11/32 socket wrench, remove each PPU Paddle nut and washer assembly and retain all components.



PPU Paddle Nut Removal

b. Slowly remove the PPU paddle with back gasket from the door. Feed the Flex Cables through the opening. Retain all PPU paddle components.



PPU Paddle with Gasket

8. Detach the Customer Display node.



a. Mark the wired connections to the Customer Display node including the speaker connector to the QVGA or VGA (JADE) Board.



Cable Connections



b. Detach the marked cables and wires including the speaker wire (not shown). Check if the Ethernet Cable is plugged in (marked with a green circle above),Unplug it and label it for connecting to the OPT later.

Note: If the Ethernet cable is plugged in, then the InvencoLink does not need to be installed.

Note:

Once the centre CAT cable is unplugged it will be loose. Set aside, **Do Not Discard**.



CAT Cable

c. Unscrew with a 3mm Hex Key the 6 screws holding the Customer Display node from the door, remove, and set aside to be reinstalled. Discard hardware. The display glass may be loose once removed. Use care once the Customer Display is removed. Retain the display glass as well.





Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2

Customer Display

d. Identify, mark, and detach the Comm cable attached to the QVGA/VGA (JADE) board on the door.



Detach Comm Cable

e. Identify the Pump Control Board and check for the Current Loop Connector. If the Current Loop Cable is attached here, then you don't need to install the PIB.



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2



f. Remove the security switch if present and retain. Discard the attaching hardware.


Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2



Security Switch

- 9. Remove the two Security Bolts.
 - a. Pull off the plastic captive cone from the end of the security bolt and retain.



Plastic Captive Cone

b. Pull out the security bolt and retain.



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2



Security Bolt

- 10. Remove Unused Cables and Wires from the Door Components Detach the Card Reader and QVGA/VGA (JADE) components.
 - a. Unplug all grounds and cables attaching the Card Reader to the electronics cabinet.



Card Reader Cable Removal

b. Unplug all cables attaching the QVGA/VGA (JADE) Board to the electronics cabinet.



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2



QVGA/VGA (JADE) Cable Removal

c. Detach any remaining cables or wires connecting the dispenser door to the electronics cabinet.



Remove Remaining Cables

	Document Number	DCV-00537
iNVENCO	Date Released	Jun. 2022
	Revision Number/Security level	R14 S2
Retrofit G7 12 inch or 15 inch + InvencoLink / PIB Wayne Ovation 2 (Canada &		
US) Installation Guide		

- 11. Removing the Door from the Dispenser
 - a. Detach the prop rod from the prop rod door bracket using a 4mm Hex Key. Remove and retain the now loose prop rod and connection hardware.



Prop Rod Removal

b. Unscrew the 3 screws using 3mm Hex Key holding the prop rod door bracket from the door. Remove and retain the bracket. Discard the three hex screws.



Prop Rod Bracket Removal



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2

c. Push up the top hinge pin and retain.



Top Hinge Pin Removal

d. Lean the door forward off the top hinge. Lift the door up and away from the dispenser. Retain the bottom pin. Discard the door.



Door Lifted Off Dispenser



4.2 Pre-Installation Procedure

There are one or two pre-installation procedures to be performed, depending on which side you are installing:

- If you are installing Side A, perform procedures 4.2.1 and 4.2.2.
- If you are installing Side B, perform procedure 4.2.1, and ensure you have installed Side One before continuing

4.2.1 Install the InvencoLink Converter

This Retro-Fit Kit does not include a communications method for the OPT. When this Retro-Fit Kit is being installed on Side A (i.e. the first side) of the dispenser, a communications method MAY first need to be installed.

Note: If there is an existing Ethernet cable connection in the dispenser, then the InvencoLink is not required.

If it is confirmed that the InvencoLink Converter needs to be installed, then follow the procedure outlined in the rest of this section. Otherwise proceed to §4.2.2 Pump Interface Board Procedure.

The approved communications methods are listed below.

UL Report Number	Kit Part Number	Retro-Fit Kit Description
MH61528	RF00033-XX	InvencoLink DSP232

For Side B (i.e. the second side), you MUST have Side A (i.e. the first side) already installed, and you may then proceed to §4.2.2 Installation Procedure.

For Side A (i.e. the first side), select the PSU Plate Assembly EZ0702 from this Retro-Fit Kit package and apply the communications method selected from the table above, following the installation instructions supplied with that Kit (DCV-00465).

Once the communications method has been installed onto the PSU Plate Assembly, proceed to §4.3 Installation Procedure.

4.2.2 Install the Pump Interface Board (PIB)

When this Retro-Fit Kit is being installed on Side B of the dispenser, a Pump Control method MAY first be installed for the OPT as per the note in the Introduction section of this manual, as repeated below.

Note: The PIB is only required if the Current Loop Cable is not connected to the Pump Control Board as per step 8.e of the Disassembly Process. This should be checked prior to the installation.



If it is confirmed that the Pump Interface Board needs to be installed, then follow the procedure outlined in the rest of this section. Otherwise proceed to §4.3 Installation Procedure.

The approved Pump Control methods are listed below.

UL Report Number	Kit Part Number	Retro-Fit Kit Description
MH61528	RF00100-XX	Pump Interface Board (PIB)

Note: The PIB can only be installed in a double-sided pump.

The pre-installation will be required on side B of the dispenser.

For Side B (i.e. the first side), select the PSU Plate Assembly from this Retro-Fit Kit package and apply the Pump Control method selected from the table above, following the installation instructions supplied with that Kit (DCV-00634).

Once the Pump Control method has been installed onto the PSU Plate Assembly, proceed to §4.3 Installation Procedure.

4.3 Installation Procedure

This section follows from the Disassembly procedure above, and assumes the pump is still open. References to "left-hand" and "right-hand" are as viewed into the pump on the Side you are working on.

4.3.1 New Door Preparation

1. Drill PPU Flex Cable and Attachment Stud Holes to the replacement Ovation 2 Door assembly (RP00022-XX, RP00062-XX or RP00059-XX)





Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2

Caution:

Use care when drilling to align the holes and centre them as indicated.



a. Identify the amount and location of PPUs according to the removed PPU plate from the old dispenser door.



PPU Plate

b. Begin drilling the PPU Flex Cable hole on the indention corresponding to the correct PPU location using a 3/8 drill bit. Plunge the hole to clean up the edges.

Caution:

Verify the PPU positions prior to drilling.



Drilling PPU Flex Holes



c. Repeat the process until all needed PPU Flex Cable holes are drilled.

Caution:

Verify the PPU positions prior to drilling.

- 2. Drill the PPU Attachment Bolt holes.
 - a. Identify the bolt hole wells corresponding to the drilled Flex Cable holes. these will be located above the Flex Cable hole.



Identifying Bolt Holes

b. Drill holes using a 3/16 drill bit in each identified bolt well following the indention as a centring guide. Plunge the holes to clean up the edges.

Caution:

Verify the PPU positions prior to drilling.



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2



Drilling Bolt Wells

- c. Repeat the process until all needed PPU attachment bolt holes are drilled.
- 3. Install the PPU Components

Warning:

The following steps must be completed prior to beginning the installation process at the pump dispenser. Power tools like drills cannot be used near the pump dispensers.

a. Install the PPU Paddles to the door. Route the top PPU Flex Cable through the drilled Flex Cable Hole from the outside.

Note:

Verify the PPU paddle corresponds with the proper PPU locations recorded during the reinstallation process.



PPU Paddle Installation



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2

b. Route the lower flex cable through the Flex Cable Hole from the outside and pull the cables through the door until the PPU paddle's bolts line up into the bolt wells.



Routing Cable

c. Insert the bolts into the drilled bolt holes in the bolt wells.



If the PPU paddle does not sit flush, plunge the bolt holes to open the area for the bolt until the paddle does sit flush against the door.

d. Attach the PPU paddles to the door by hand tightening the retained nuts and washers to the PPU paddle bolts on the back side of the new dispenser door.



Attaching PPU Paddles

e. Use a 11/32 socket wrench to tighten the nuts to the dispenser door. Repeat until all PPU paddles have been installed.



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2



Tighten Paddles in Place

- 4. Install the retained PPU Screen Lens.
 - a. Remove the gasket material from the PPU Glass Lens Pane. Clean the surface of the glass where the gasket was removed.





b. Install the new PPU Lens Gasket (DK0015 or 497-0518659) to the PPU Glass Lens Pane. Install the new gasket ensuring the gasket is properly seated around the glass lens pane, by firmly pushing the gasket into place around the lens.



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2



Seating the Gasket



c. Install the PPU Lens into the lens recess in the new door.

Installing the PPU Lens

d. Place the retained Lens Cover over the lens, making sure the cover properly fits in the lens recess.



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2



Fitting Retained Lens Cover

e. Use the 8 supplied screws (MS0050 or 006-8625469) to tighten the cover to the screen with a 3mm Hex Key. Alternate tightening each screw, starting in the centre and radiating out to apply even pressure for a proper water seal.



Sealing the screen

- 5. Install the metal cosmetic cover.
 - a. Place the previously retained metal cosmetic cover over the PPU paddles and screen assembly.



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2



Cosmetic Cover

b. Turnover and attach the metal cover with the 5 sealing washers (MW0057 or 006-8625470) and screws (MS0050 or 006-8625469) assemblies where indicated.



To properly thread the screws into the cover, push in the cover from the front opposite each screw location while installing each screw.



Attaching the Cosmetic Cover

c. Install the ground cable (EK0132 or 497-0513687) to the last (6th) screw and washer assembly.



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2



Ground Cable

d. Install the screw, cable, and washer assembly to the upper left corner as indicated below.



Upper Left-Hand Corner

- 6. Install the PPU panel.
 - a. Place the previously retained PPU board onto the door with the screens facing



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2

forward and lining up the positioning key posts.



Positioning the PPU Panel

b. Attach the PPU board to the door with 6 screws (MS0050 or 006-8625469) with a 3mm Hex Key.



Attaching the PPU Board

c. Plug in PPU paddle connections to the PPU board. the white LED flex cable plugs into the lower connector, the brown ACT flex cable plugs into the upper connector.



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2



Plug in PPU Paddles

7. Install Retained Door Components

Replace the gasket on the Customer Display.

Note:

Sometimes the Customer Display glass pane will adhere to the metal Customer Display bracket. Use care when removing the glass pane to not damage the metal bracket and speakers or crack the glass.

a. Remove the gasket from around the Customer Display glass pane. Clean the surface of the glass where the gasket was removed.



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2



Remove Old Gasket

b. Install the new provided gasket (EP0095 or 497-0518661) around the glass pane.



Install New Gasket



US) Installation Guide

c. Install the Customer Display glass pane to the dispenser door. First, line up the glass pane with the top display opening. Verify the correct orientation: The speakers should be pointed to the inside of the dispenser. The display decal should be upright and readable from the front of the dispenser door.



Check Orientation

d. Place in the glass pane and check to make sure the gasket is seated in the opening correctly. There should be no gaps.



Check Gasket Seating

e. Install the retained customer display with 5 screws (MS0050 or 006-8625469) using a 3mm Hex



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2

Key to the positions indicated below. Be sure to route the speaker cables through the openings to avoid pinching or trapping them before tightening down the customer display metal bracket.



Install Customer Display



f. On the bottom left corner of the customer display, install the screw with the grounding cable (EK0132 or 497-0513687).

Grounding cable onto the screw.

g. Install the screw cable assembly to the customer display where indicated below.



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2



h. Install the Prop Rod door bracket previously retained using 3 hex screws (MS0050 or 006-8625469).



Prop Door Bracket

i. Install the security switches if present using the 4 provided screws (MS0253 or 006-8626488).



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2



Switch Locations



Install with 2 screws per switch

- 8. Install the security bolts.
 - a. Insert the previously retained security bolts into the security bolt holes in the front of the door on the left-hand side.



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2



Inserting the Security Bolts

b. Install the retained plastic captive cone to the bolt on the back side as indicated below.



Plastic Captive Cone



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2

4.3.2 Install the Power Supply (EZ0702)

- 1. Install the PSU Panel to the pump
 - a. Install the Ovation 2 Installation bracket (MP0985) with two nuts (MN0029) on the PSU panel with the orientation as shown on the Ovation wing.



Ovation 2 Installation Bracket

b. Install the PSU Panel to the right side of the dispenser using the 2 supplied nuts (MN0077) to the bottom studs already in the dispenser cabinet.



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2



PSU Panel to RHS

- 2. Install Ovation 2 Power Cable Harness
 - a. Install the Ovation 2 Power Cable (EK0137) single connector end to the PSU Universal power connector.



Connect Power Cable

- 3. Plug in the Power Cable Harness to the Dispenser Power board.
 - a. Unplug the AC Power In cable from the AC Distribution board.



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2

Note:

To identify the AC in cable, trace it back to the conduit into the dispenser cabinet.



AC Disconnected

b. Plug in the AC Power In cable to the Power Cable Harness.



AC Power into Power Cable Harness

c. Plug in the Power Cable Harness to the AC Distribution board.



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2



Power to the Distribution Board

d. If installing the Side B PSU, daisy chain the Side A PSU into the Side B PSU and plug the Cable Harness into the Power Distribution Board.



This step only applies if the InvencoLink is being installed

- 4. Install Invenco Link Dispenser Cables
 - a. Install the Wayne Comm Cable adapter (EK0127 or 497-0513684) to the Dispenser Invenco Link.

Note:

This is only needed during the side A installation.



Wayne Cable Adapter

b. Install one of the Dispenser Comm Cables previously identified to the Cable Adapter.

Note:

Verify the correct cables match when connected. For example, brown to brown, purple to purple.



Comms Cables

5. Install the Network Cable.



- 6. This step applies only if the InvencoLink is being installed (Side A only)
 - a. Install yellow CAT network cable (EK0131 or 497-0513384) into the Invenco Link LAN 1 terminal (for Side A).

Note:

Use the LAN 2 terminal for Side B installation.



Yellow Cat Cable

- 7. This step applies only if the PIB is being installed (Side B only)
 - a. Identify the Wayne Current Loop cable (EK0243) that is screwed on the PIB terminal on one end. Trace the other end of the cable to identify the connector and plug it into the Pump Control Board.



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2



Pump Control Board



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2





b. Gather the DC Power cable from the EZ0702 PSU Plate Assembly and, the EK0131 Yellow patch cable (if the InvencoLink is being installed), or the EK0243 the Wayne Current Loop Cable (if the PIB is being installed) place them in the bottom of the pump cabinet near the side you are installing, ready for connection.



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2

4.3.3 Install the New Door to the Dispenser

- a. Replace the retained lower pin into the lower dispenser door frame hinge.
- b. Install the new dispenser door onto the lower pin and rotate the door up into the upper hinge.



New Door

c. Install the retained upper pin into the door hinge.



Upper Door Pin

d. Reinstall the retained Prop Rod to the dispenser door.



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2



Retaining Prop Rod

e. Install the Prop Rod to the Prop Rod Door Assembly with a 4mm hex key and the previously retained hardware. Place the washer between the prop rod and door assembly and tighten the retained hex screw from the bottom of the assembly as shown.



Prop Rod Retaining Hardware



Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2

4.3.4 Install the Cables and Wiring to the Dispenser Door

a. Reinstall the marked cables to the Customer Display Node.



Reinstall Cables

b. Reinstall the marked cables to the PPU board.

Note:

Note:

Install the other end of the red and black power cable previously installed in the last step to the J8 connection on the PPU panel in place of the discarded white power cable.



PPU Cables Reinstalled

c. Plug in the corresponding EK0131 yellow CAT5 LAN cable (if the InvencoLink is being installed), otherwise the ethernet cable that was unplugged from the dispenser in the disassembly procedure


Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2

Retrofit G7 12 inch or 15 inch + InvencoLink / PIB Wayne Ovation 2 (Canada & US) Installation Guide

(step 8.b), into the Ethernet socket and ensure it clips into place . Plug in the G7 power cable from the Invenco PSU Assembly to the G7 APC (mounted on the SDC screen assembly):



APC Connections

d. This step only applies if the PIB is being installed.

Identify the two USB cables plugged in the PIB. Trace the other end of one of the cables and plug into a spare USB port on the G7 15 inch SDC. It can be any of the 4 USB ports. (Each of the two USB cables will need to be plugged into Side A and Side B).





Document Number	DCV-00537
Date Released	Jun. 2022
Revision Number/Security level	R14 S2

Retrofit G7 12 inch or 15 inch + InvencoLink / PIB Wayne Ovation 2 (Canada & US) Installation Guide

4.3.5 Install the Printer Door and Gasket

- a. Install the printer door and gasket with the G7 Printer Wayne Ovation Kit. Follow the G7 Wayne Ovation Printer Kit Installation Instructions (DCV-00464). Acquire the Printer Retrofit G7 Printer Wayne Ovation 2, UL Listed by Report Retrofit kit part number RF00038-XX (when installing with the black kits) or RF00058-XX (when installing the colored kit). Start at the Installation Sections. Deinstallation should already be completed.
- b. Attach all grounding wires to the PSU Grounding Stud shown below.



Grounding Stud

4.3.6 Completing the installation

- a. Route all cables around and away from seals, gaskets, and sharp edges.
- b. Repeat the process for Side B of the dispenser.
- c. Close and seal the pump with the security bolts using the Wayne Security Key. Power can be returned to the dispenser

Caution:

Follow local regulations for certification and inspection prior to returning power or reopening the dispenser for costumers.

5 First Power-Up

Once the installation is complete and the wiring is certified (if necessary), power may be applied.

	Document Number	DCV-00537
iN/ENCO	Date Released	Jun. 2022
	Revision Number/Security level	R14 S2
Retrofit G7 12 inch or 15 inch + InvencoLink / PIB Wayne Ovation 2 (Canada &		

US) Installation Guide

The G7 OPT takes a couple of minutes to complete its start-up phase, during which several information screens will be presented.

The terminal will display the following screen whilst attempting to connect to the LAN. This screen will persist until a connection can be made:



If the terminal is successful in connecting to the LAN it will display the following screen and the rest of the start-up sequence will continue:

