

Encore<sup>®</sup> and Eclipse<sup>®</sup> Series

# Owner's Manual

MDE-3893T

#### **Computer Programs and Documentation**

G-SITE and Passport Systems

All Gilbarco Inc. and/or Veeder-Root Company computer programs (including software on diskettes and within memory chips) and documentation are copyrighted by, and shall remain the property of, Gilbarco Inc. and/or Veeder-Root Company. Such computer programs and documents may also contain trade secret information. The duplication, disclosure, modification, or unauthorized use of computer programs or documentation is strictly prohibited, unless otherwise licensed by Gilbarco Inc. and/or Veeder-Root Company.

#### Federal Communications Commission (FCC) Warning

This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense. Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate this equipment.

#### Approvals

E165027

#### Gilbarco is an ISO 9001:2008 registered company. California Air Resources Board (CARB): Underwriters Laboratories (UL):

UL File#	Products listed with UL	Executive Order #	Product
MH1941	All Gilbarco pumps and dispensers that bear	G-70-52-AM	Balance Vapor Recovery
	the UL listing mark.	G-70-150-AE	VaporVac
MH8467	Transac System 1000 and PAM 1000		*
E105106	Dell DHM Minitower		

#### National Conference of Weights and Measures (NCWM) - Certificate of Conformance (CoC):

Gilbarco pumps and dispensers are evaluated by NCWM under the National Type Evaluation Program (NTEP). NCWM has issued the following CoC:

CoC#	Product	Model #	CoC#	Product	Model #
02-019	Encore	Nxx	02-036	Legacy	Jxxx
02-020	Eclipse	Exx		G-SITE Printer (Epson)	PA0307
02-025	Meter - C Series	PA024NC10		G-SITE Distribution Box	PA0306
	Meter - C Series	PA024TC10	02.027	G-SITE Keyboard	PA0304
02-029	CRIND	_	02-037	G-SITE Mini Tower	PA0301
02-030	TS-1000 Console	_		G-SITE Monitor	PA0303
	TS-1000 Controller	PA0241		G-SITE Printer (Citizen)	PA0308
	Distribution Box	PA0242	02-038	C+ Meter	T19976
	Meter - EC Series	PA024EC10	02-039	Passport	PA0324
	VaporVac Kits	CV	02-040	Ecometer	T20453
			05-001	Titan	KXXY Series

#### Trademarks

#### Non-registered trademarks

Non-registered trademarks			Registered trademarks		Service marks	
Applause™ Media System	G-SITE <sup>®</sup> Link™	PAM <sup>™</sup> 5000	Titan™	CRIND®	Making Things Better® VaporVac®	GOLD <sup>SM</sup>
CIM™	G-SITE® Lite™	SMART Connect™	Ultra-Hi™	Dimension® Series	MPD <sup>®</sup>	
C-PAM <sup>™</sup>	Highline™	SMART CRIND™	ValueLine™	e-CRIND®	Passport®	
Ecometer™	Horizon™	SMART Meter™		Eclipse <sup>®</sup>	Performer®	
ECR™	Insite360 <sup>™</sup>	SmartPad™		Encore®	The Advantage® Series	
EMC™	MultiLine™	Super-Hi™		G-SITE®	Transac <sup>®</sup>	
FlexPay™	Optimum™ Series	Surge Management Sys	stem™	Gilbarco®	Transac® System 1000	
G-CAT™	PAM	Tank Monitor™		InfoScreen®	Trimline®	
Gilbert™	PAM <sup>™</sup> 1000	TCR™		Legacy®	TRIND®	

Additional U.S. and foreign trademarks pending.

Other brand or product names shown may be trademarks or registered trademarks of their respective holders.



## **Table of Contents**

### 1 – Introduction

Purpose	 1-1
Intended Users	 1-1
Scope	 1-1
Related Documents	 1-1
Abbreviations and Acronyms	 1-2

### 2 - Important Safety Information

3 – Introducing Encore/Eclipse Series		
Encore 300/500		
Encore 550		
Encore S Series		
Diesel Exhaust Fluid	(DEF) Dispenser	
	Americans with Disabilities Act (ADA) Requirements	
Eclipse Series	·····	
Understanding Date Codes and Serial Numbers		
- 0	Understanding Date Codes	
	Understanding Model Codes	
Common Functions.	g	
	Displaving Last Transaction	
	Displaying Pump Totals for Encore/Eclipse Units	
	Grade Number Reference Chart	3-14
Operating Units		
eperennig enne i i i i	Console Mode (Two-wire)	3-16
	Standalone Mode	

### 4 – Preparing to Service Units

4 – Preparing to Service Units	
Important Considerations for DEF Dispensers	
Important Considerations for Units with Ecometers	s™
Important Considerations When Changing Fuel Ty	ypes
Dispensing Gasoline/Ethanol Blends	
Important Requirements for E85 Units	
Call Gilbarco First	
Service Preparation	
Before Making Servic	ce Call
Description of Proble	m
Warranty Service	
Station Security	
Enhancing Security	
Additional Security in Encore S Series Units	4-
Important Installation	Information
Unit Commissioning .	
Error Codes	
Replacement Parts	
Specialized Training.	

1-1

2-1

### 5 – Maintaining Units

Conoral Safaty Con	oiderationa	E 1
General Salety Cons		
Periodic inspections		
<b>D</b> · · · <b>N</b> · · ·		
Printer Maintenance		
	Printer Paper Specifications	
	Changing FlexPay 6 A2-09 Device Printer Paper	
	Changing CRIND Device Printer Paper	5-15
	Cleaning Printer	5-16
	Printer Paper Ordering Information	5-16
	Changing Receipt Paper in M00317A00X Printer	5-17
	Changing Receipt Paper in USB Printer (M04119A001)	5-20
	Changing Receipt Paper in USB Sliding Printer (M06972A001)	5-23
	Changing Receipt Paper in USB Sliding Printer for Encore S Series I	E-CIM Bezel
	(M07885A001)	5-26
	Cleaning CRIND Device in M00317A00X Printer	5-30
	Clearing Paper Jams in FlexPay 6 A2-09	5-30
	Clearing Paper Jams in USB Printer (M04119A001)	5-32
	Clearing Paper Jams in USB Sliding Printer (M06972A001)	5-34
Special Maintenance		5-35
I	Cleaning and Detailing Unit.	
	Painted Plastics and Metals	5-37
	Graphics	5-37
	Display Lenses	5-38
	Stainless Steel Sheathing	5-38
	Waxing Dispenser	
Glossary		Glossary-1
Index		Index-1

Page ii

5-1

## **1 – Introduction**

## **Purpose**

This manual provides instructions for safely operating, programming, and maintaining Encore® 300/500/550/S and Eclipse® pumps/dispensers (hereafter referred to as units, unless otherwise specifically stated).

## **Intended Users**

This manual is written for the owners and operators of Encore and Eclipse units.

## Scope

The following information is provided in this manual on Encore and Eclipse units:

- Operating the units
- Programming Encore and Eclipse units
- Preparing the units for service
- Maintaining the units

## **Related Documents**

Document Number	Title	GOLD℠ Library
MDE-3802	Encore and Eclipse Site Preparation Manual	<ul> <li>Encore and Eclipse</li> <li>Encore and Eclipse Installers</li> <li>Footprint and Elevation Library</li> <li>Site Prep</li> </ul>
MDE-3985	Encore Installation Manual	<ul><li>Encore and Eclipse</li><li>Encore and Eclipse Installers</li><li>Footprint and Elevation Library</li></ul>
MDE-3986	Eclipse Installation Manual	<ul><li>Encore and Eclipse</li><li>Encore and Eclipse Installers</li></ul>
MDE-4732	Encore and Eclipse Series Owner's Programming Manual	Encore and Eclipse
PT-1798	Consumable Parts List	Parts Manual
PT-1936	Encore Series Pumps and Dispensers Illustrated Parts Manual	<ul><li>Parts Manual</li><li>Encore and Eclipse Installers</li><li>Encore and Eclipse</li></ul>
TRP-1856	Major Software Release	Gilbarco® Extranet

## **Abbreviations and Acronyms**

Term	Description
ADA	Americans with Disabilities Act
ASC	Authorized Service Contractor
ASTM	American Society for Testing and Materials
СС	Command Code
CIM™	Customer Interface Module
CRIND®	Card Reader in Dispenser
CSC	Customer Specified Contractor
DEF	Diesel Exhaust Fluid
DLT	Displaying Last Transaction
FC	Function Code
FCC	Federal Communications Commission
FF	Flexible Fuel
GOLD	Gilbarco Online Documentation
IFSF	International Forecourt Standards Forum
J-box	Junction Box
LCD	Liquid Crystal Display
LED	Light Emitting Diode
LON	Local Operating Network
MOC	Major Oil Company
MPD®	Multi Product Dispenser
NEC®	National Electrical Code
NFPA	National Fire Protection Association
OSHA	Occupational Safety and Hazard Administration
PCI-PED	Payment Card Industry PIN Entry Device
POS	Point of Sale
PPP	Programmable Pump Preset
PPU	Price per Unit
STP	Submersible Turbine Pump
TRIND®	Transmitter/Receiver in Dispenser
UL®	Underwriters Laboratories
USB	Universal Serial Bus
VR	Vapor Recovery
W&M	Weights and Measures

## 2 – Important Safety Information

Notes: 1) Save this Important Safety Information section in a readily accessible location.

> 2) Although DEF is non-flammable, Diesel is flammable. Therefore, for DEF cabinets that are attached to Diesel dispensers, follow all the notes in this section that pertain to flammable fuels.

This section introduces the hazards and safety precautions associated with installing, inspecting, maintaining, or servicing this product. Before performing any task on this product, read this safety information and the applicable sections in this manual, where additional hazards and safety precautions for your task will be found. Fire, explosion, electrical shock, or pressure release could occur and cause death or serious injury, if these safe service procedures are not followed.

#### **Preliminary Precautions**

You are working in a potentially dangerous environment of flammable fuels, vapors, and high voltage or pressures. Only trained or authorized individuals knowledgeable in the related procedures should install, inspect, maintain, or service this equipment.

#### **Emergency Total Electrical Shut-Off**

The first and most important information you must know is how to stop all fuel flow to the pump/dispenser and island. Locate the switch or circuit breakers that shut off all power to all fueling equipment, dispensing devices, and Submerged Turbine Pumps (STPs).

### WARNING



The EMERGENCY STOP, ALL STOP, and PUMP STOP buttons at the cashier's station WILL NOT shut off electrical power to the pump/dispenser. This means that even if you activate these stops, fuel may continue to flow uncontrolled.

You must use the TOTAL ELECTRICAL SHUT-OFF in the case of an emergency and not the console's ALL STOP and PUMP STOP or similar keys.

#### Total Electrical Shut-Off Before Access

Any procedure that requires access to electrical components or the electronics of the dispenser requires total electrical shut off of that unit. Understand the function and location of this switch or circuit breaker before inspecting, installing, maintaining, or servicing Gilbarco equipment.

#### Evacuating, Barricading, and Shutting Off

Any procedure that requires access to the pump/dispenser or STPs requires the following actions:



- · An evacuation of all unauthorized persons and vehicles from the work area
- · Use of safety tape, cones, or barricades at the affected unit(s)
- · A total electrical shut-off of the affected unit(s)

#### Read the Manual

Read, understand, and follow this manual and any other labels or related materials supplied with this equipment. If you do not understand a procedure, call the Gilbarco Technical Assistance Center (TAC) at 1-800-743-7501. It is imperative to your safety and the safety of others to understand the procedures before beginning work.

#### **Follow the Regulations**

Applicable information is available in National Fire Protection Association (NFPA) 30A; Code for Motor Fuel Dispensing Facilities and Repair Garages, NFPA 70; National Electrical Code (NEC), Occupational Safety and Health Administration (OSHA) regulations and federal, state, and local codes. All these regulations must be followed. Failure to install, inspect, maintain, or service this equipment in accordance with these codes, regulations, and standards may lead to legal citations with penalties or affect the safe use and operation of the equipment. **Replacement Parts** 

Use only genuine Gilbarco replacement parts and retrofit kits on your pump/dispenser. Using parts other than genuine Gilbarco replacement parts could create a safety hazard and violate local regulations.

#### Federal Communications Commission (FCC) Warning

This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense. Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate this equipment.

### Safety Symbols and Warning Words

This section provides important information about warning symbols and boxes.

Alert Symbol



This safety alert symbol is used in this manual and on warning labels to alert you to a precaution which must be followed to prevent potential personal safety hazards. Obey safety directives that follow this symbol to avoid possible injury or death.

#### Signal Words

These signal words used in this manual and on warning labels tell you the seriousness of particular safety hazards. The precautions below must be followed to prevent death, injury, or damage to the equipment:



DANGER: Alerts you to a hazard or unsafe practice which will result in death or serious injury. WARNING: Alerts you to a hazard or unsafe practice

that could result in death or serious injury. CAUTION with Alert symbol: Designates a hazard or

unsafe practice which may result in minor injury. **CAUTION** without Alert symbol: Designates a hazard or unsafe practice which may result in property or equipment damage.

### Working With Fuels and Electrical Energy **Prevent Explosions and Fires**

Fuels and their vapors will explode or burn, if ignited. Spilled or leaking fuels cause vapors. Even filling customer tanks will cause potentially dangerous vapors in the vicinity of the dispenser or island.

DEF is non-flammable. Therefore, explosion and fire safety warnings do not apply to DEF lines.

#### No Open Fire



Open flames from matches, lighters, welding torches or other sources can ignite fuels and their vapors.

#### No Sparks - No Smoking



Sparks from starting vehicles, starting or using power tools, burning cigarettes, cigars or pipes can also ignite fuels and their vapors. Static electricity, including an electrostatic charge on your body, can cause a spark sufficient to ignite fuel vapors. Every time you get out of a vehicle, touch the metal of your vehicle, to discharge any electrostatic charge before you approach the dispenser island.

#### **Working Alone**

It is highly recommended that someone who is capable of rendering first aid be present during servicing. Familiarize yourself with Cardiopulmonary Resuscitation (CPR) methods, if you work with or around high voltages. This information is available from the American Red Cross. Always advise the station personnel about where you will be working, and caution them not to activate power while you are working on the equipment. Use the OSHA Lockout/Tagout procedures. If you are not familiar with this requirement, refer to this information in the service manual and OSHA documentation.

#### Working With Electricity Safely

Ensure that you use safe and established practices in working with electrical devices. Poorly wired devices may cause a fire, explosion or electrical shock. Ensure that grounding connections are properly made. Take care that sealing devices and compounds are in place. Ensure that you do not pinch wires when replacing covers. Follow OSHA Lockout/Tagout requirements. Station employees and service contractors need to understand and comply with this program completely to ensure safety while the equipment is down.

#### **Hazardous Materials**

Some materials present inside electronic enclosures may present a health hazard if not handled correctly. Ensure that you clean hands after handling equipment. Do not place any equipment in the mouth

### 

In the event of inclement weather, including snow, ice, or flooding that makes driving conditions dangerous, please avoid servicing units. Always use available door stops to secure upper doors against unwanted/unexpected movement, especially during high winds. If necessary, reschedule service to avoid damage to the equipment. Weather may change unexpectedly; be aware of local weather conditions. During service, if conditions develop making service unsafe, close the unit(s) and proceed to a safe location.

#### 

The pump/dispenser contains a chemical known to the State of California to cause cancer.

### 

The pump/dispenser contains a chemical known to the State of California to cause birth defects or other reproductive harm.



Gilbarco Veeder-Root encourages the recycling of our products. Some products contain electronics, batteries, or other materials that may require special management practices depending on your location. Please refer to your local, state, or country regulations

Please refer to your local, state, or country regulation for these requirements.

### In an Emergency

#### Inform Emergency Personnel

Compile the following information and inform emergency personnel:

- Location of accident (for example, address, front/back of building, and so on)
- Nature of accident (for example, possible heart attack, run over by car, burns, and so on)
- Age of victim (for example, baby, teenager, middle-age, elderly)
- Whether or not victim has received first aid (for example, stopped bleeding by pressure, and so on)
- Whether or not a victim has vomited (for example, if swallowed or inhaled something, and so on)

#### MARNING



Gasoline/DEF ingested may cause unconsciousness and burns to internal organs. Do not induce vomiting. Keep airway open.

Oxygen may be needed at scene. Seek medical advice immediately.

#### 

DEF generates ammonia gas at higher temperatures. When opening enclosed panels, allow the unit to air out to avoid breathing vapors. If respiratory difficulties develop, move victim away from source of exposure and into fresh air. If symptoms persist, seek medical attention.

### 



Gasoline inhaled may cause unconsciousness and burns to ls, mouth and lungs. Keep airway open.

Seek medical advice immediately.

#### 



Gasoline/DEF spilled in eyes may cause burns to eye tissue.

Irrigate eyes with water for approximately 15 minutes.Seek medical advice immediately.

### 



Gasoline/DEF spilled on skin may cause burns. Wash area thoroughly with clear water. Seek medical advice immediately.

### \Lambda WARNING

DEF is mildly corrosive. Avoid cont with eyes, skin, and clothing. Ensure that eyewash stations and safety showers are close to the work location. Seek medical advice/recommended treatment if DEF spills into eyes.

**IMPORTANT**: Oxygen may be needed at scene if gasoline has been ingested or inhaled. Seek medical advice immediately. **Lockout/Tagout** 

Lockout/Tagout covers servicing and maintenance of machines and equipment in which the unexpected energization or start-up of the machine(s) or equipment or release of stored energy could cause injury to employees or personnel. Lockout/Tagout applies to all mechanical, hydraulic, chemical, or other energy, but does not cover electrical hazards. Subpart S of 29 CFR Part 1910 - Electrical Hazards, 29 CFR Part 1910.333 contains specific Lockout/Tagout provision for electrical hazards.

### **Hazards and Actions**



#### WARNING

Spilled fuels, accidents involving pumps/dispensers, or uncontrolled fuel flow create a serious hazard.

Fire or explosion may result, causing serious injury or death.

Follow established emergency procedures.

DEF is non-flammable. However it can create a slip hazard. Clean up spills promptly.

The following actions are recommended regarding these hazards:



Fuel Spill

- Do not go near a fuel spill or allow anyone else in the area.
- Use station EMERGENCY CUTOFF immediately. Turn off all system circuit breakers to the island(s).
- Do not use console E-STOP, ALL STOP, and PUMP STOP to shut off power. These keys do not remove AC power and do not always stop product flow.
- · Take precautions to avoid igniting fuel. Do not allow starting of vehicles in the area. Do not allow open flames, smoking or power tools in the area.
- · Do not expose yourself to hazardous conditions such as fire, spilled fuel or exposed wiring.
- · Call emergency numbers.

This page is intentionally left blank.

## 3 – Introducing Encore/Eclipse Series

This chapter provides illustrations of the Encore and Eclipse units and their components. Refer to this chapter when you perform the procedures in this manual.

## Encore 300/500

The Encore 300/500 units, which are similar in appearance are shown in Figure 3-1. However, each series has its own hardware/software package. For information on programming the unit, refer to "Programming Encore 300" in *MDE-4732 Encore and Eclipse Series Owner's Programming Manual*. All options may not be available on your unit.



### Figure 3-1: Encore 300/500 Units

## Encore 550

The Encore 550 unit has an enhanced appearance for the columns and canopy, when compared to the Encore 300/500 units. Figure 3-2 shows an Encore 550 unit with SMART Meter<sup>™</sup> dispenser and its components. For information on programming the unit, refer to "Programming Encore 500 and 550, Encore S Series and Eclipse" in *MDE-4732 Encore and Eclipse Series Owner's Programming Manual*. All options may not be available on your unit.

### Figure 3-2: Encore 550 Unit



## **Encore S Series**

The Encore S series units offer a refined style that delivers a simplified customer layout, resulting in effective fuel time. With the S series unit, the retailer also receives the benefit of increased security against fuel fraud, which includes:

- A separate printer door that has a barrier, restricting access to the inside of the unit
- A security latch below the main door, placed behind the lower panel door.

For more information on the additional security features of the Encore S series, refer to "Additional Security in Encore S Series Units" on page 4-7.

Figure 3-3: Encore S Series Unit





Figure 3-4: Encore S Series - FlexPay™6 A2-09



Figure 3-5: Front View of A2-09 (G6-400) OPT

Figure 3-6: Rear View of A2-09 (G6-400) OPT





Figure 3-7: Encore S Series - FlexPay 6 M1-15

## **Diesel Exhaust Fluid (DEF) Dispenser**



Figure 3-8: DEF Dispenser (When Tank Is Not Installed Underground)

### Americans with Disabilities Act (ADA) Requirements

### **IMPORTANT INFORMATION**

To meet the reach requirements as specified by ADA, the island of the dispenser must not be higher than 6 inches tall.

### Figure 3-9: ADA Requirements



## **Eclipse Series**



Figure 3-10 shows an Eclipse unit and its components.

### Figure 3-10: Eclipse Unit

## **Understanding Date Codes and Serial Numbers**

This section provides information on the date and model codes for the Encore series and Eclipse units.

### **Understanding Date Codes**

A two-letter date code is stamped on the serial plate before the serial number. This code shows the month and year of manufacture. Refer to the date code to determine the age of the equipment for warranty purposes.

The following tables lists the date code on an Encore or Eclipse unit:

Month Codes			
A = January	E = May	J = September	
B = February	F = June	K = October	
C = March	G = July	L = November	
D = April	H = August	M = December	

Year Codes				
J = 2000	N = 2004	T = 2008	A = 2012	E = 2016
K = 2001	P = 2005	U = 2009	B = 2013	F = 2017
L = 2002	R = 2006	W = 2010	C = 2014	
M = 2003	S = 2007	X = 2011	D = 2015	

### **Understanding Model Codes**

The model numbers are located as shown in Figure 3-1 on page 3-1, Figure 3-2 on page 3-2, Figure 3-4 on page 3-4, and Figure 3-10 on page 3-9.

For Encore 300/500/550 units, the model number uses a two-letter and one-number model code stamped on the serial plate. For Encore S units, the model number uses a two-letter and a one-number model code listed on the Underwriters Laboratories (UL) Weights and Measures (W&M) label that is located behind the printer door.

To determine the model code on a Gilbarco Encore 300/500/550/S series unit, refer to the following table.

*Note: Not all models are available in an Encore 300 (E300), Encore 500/550 (E500/E550), or Encore S series version.* 

N	Х	X
Encore	<b>A</b> = Multi-hose Dispenser	<b>0</b> = 1 Grade <b>1</b> = 2 Grade <b>2</b> = 3 Grade <b>3</b> = 4 Grade <b>4</b> = DEF only
	<b>C</b> = Multi-hose Pump	<b>0</b> = 1 Grade <b>1</b> = 2 Grade <b>2</b> = 3 Grade <b>3</b> = 4 Grade
	<b>G</b> = Single-hose	<ul> <li>0 = 3 Grade Dispenser</li> <li>1 = 3 Grade + 1 Dispenser</li> <li>2 = 3 Grade Pump</li> <li>3 = 3 Grade Pump + 1</li> <li>4 = 2 Grade Single-hose MPD</li> <li>5 = 2 Grade Single-hose Pump</li> </ul>
	J = Multi-hose Blender	<ul> <li>0 = 3 Grade Blender Dispenser</li> <li>1 = 3 Grade Blender Pump</li> <li>2 = 4 Grade Blender + 1 Dispenser</li> <li>3 = 4 Grade Blender + 1 Pump</li> <li>4 = 3 + 2 Grade Blender Dispenser</li> <li>5 = 5 + 0 Multi-hose Hybrid Blender</li> <li>6 = 4 + 1 Multi-hose Hybrid Blender</li> </ul>
	L = X+1 Blender	<ul> <li>0 = 2 + 1 Grade Blender Dispenser</li> <li>1 = 3 + 1 Grade Blender Dispenser</li> <li>2 = 4 + 1 Grade Blender Dispenser</li> <li>3 = 3 + 1 + 1 Grade Blender Dispenser</li> <li>4 = 2 + 1 Grade Blender Pump</li> <li>5 = 3 + 1 Grade Blender Pump</li> <li>6 = 4 + 1 Grade Blender Pump</li> </ul>
	N = X+0 Blender	<ul> <li>1 = 3 + 0 Grade Blender Dispenser</li> <li>2 = 4 + 0 Grade Blender Dispenser</li> <li>3 = 5 + 0 Grade Blender Dispenser</li> <li>5 = 3 + 0 Grade Blender Pump</li> <li>6 = 4 + 0 Grade Blender Pump</li> <li>7 = 5 + 0 Grade Blender Pump</li> </ul>
	P = Ultra High Flow	<ul> <li>3 = Ultra-Hi™ Master</li> <li>4 = Ultra-Hi Combo</li> <li>5 = Ultra-Hi Satellite</li> <li>6 = Ultra-Hi Master Dispenser - Single-sided Dual Product Unit</li> <li>8 = Ultra-Hi Satellite Dispenser - Single-sided Dual Product Unit</li> <li>A = Ultra-Hi Master + DEF</li> <li>B = Ultra-Hi Combo + DEF</li> </ul>
	<b>R</b> = Special	0 = No Hydraulics 1 = Robot 2 = Simulator 3 = Pumpless Pump 4 = No Electronics

### Encore 300/500/550/S Series

Examples:

- 1 A serial plate stamped "CJ-NA0" contains the following information:
  - Date code [CJ] This unit was manufactured in March 2000.
  - Model code [NA0] This unit is a single-grade, multi-hose, Encore dispenser.
- **2** A UL W&M label that lists "CP-NA0" contains the following information:
  - Date code [CP] This unit was manufactured in March 2005.
  - Model code [NA0] This unit is a single-grade, multi-hose, Encore S dispenser.

The following table lists the model code on a Gilbarco Eclipse unit:

Ecli	pse	Units
------	-----	-------

E	Х	X
Eclipse	<b>G</b> = Single-hose MPD	<b>0</b> = 3 Grade
	L = X + 1 Blender, 4 Hose	<ul> <li>0 = 2 + 1 Grade Blender Dispenser</li> <li>1 = 3 + 1 Grade Blender Dispenser</li> <li>2 = 4 + 1 Grade Blender Dispenser</li> <li>3 = 5 + 1 Grade Blender Dispenser</li> </ul>
	N = X + 0 Blender, 2 Hose	<ul> <li>0 = 2 + 0 Grade Blender Dispenser</li> <li>1 = 3 + 0 Grade Blender Dispenser</li> <li>2 = 4 + 0 Grade Blender Dispenser</li> <li>3 = 5 + 0 Grade Blender Dispenser</li> </ul>

Note: Not all models are available in an Eclipse unit.

Example:

A serial plate stamped "GM-EN1" contains the following information:

- Date code [GM] This unit was manufactured in July 2003.
- Model code [EN1] This unit is a three-grade, two-hose, Eclipse blender dispenser.

## **Common Functions**

This section provides information on the common functions of the Encore series and Eclipse units.

### **Displaying Last Transaction**

If power supply is interrupted, information about the previous sale (last transaction) remains visible on the main display for at least 15 minutes.

### **Displaying Pump Totals for Encore/Eclipse Units**

You can view pump totals for Encore and Eclipse units on the main and PPU displays by using the manager keypad located behind the CIM door or oven door on side 1 of the dispenser. The keypad's magnetic backing allows easier handling and input.

- Notes: 1) For Encore 300/500/550 and Eclipse units, to identify side 1 (A) of the pump or dispenser, refer to the section titled "Programming Orientation" in MDE-4732 Encore and Eclipse Series Owner's Programming Manual.
  - 2) For Encore S series units, to identify side 1 of the unit, see Figure 3-4 on page 3-4.

The manager keypad is shown in Figure 3-11.

### Figure 3-11: Manager Keypad



Note: To enter the Command Codes (CCs) required to place the pump/dispenser in standalone mode or to program prices directly at the unit, refer to "Standalone Mode" on page 3-16.

## 🕂 WARNING

To avoid potential electric shock, do not touch any wiring or electronic component(s) behind the CIM/oven door or main door.

The following table explains how to access the manager keypad:

Model Series	Steps to Locate the Manager Keypad
Encore 300/500/550/S series	<ul><li> Open CIM door on side 1 (A)</li><li> Keypad is attached (by magnet) behind the door</li></ul>
Eclipse	<ul><li> Open oven door on side 1 (A)</li><li> Keypad is attached (by magnet) behind the door</li></ul>

The location of data in the displays is shown in Figure 3-12.

*Note: To see illustrations that show the location of these displays, refer to "Introducing Encore/Eclipse Series" on page 3-1.* 

### Figure 3-12: Location of Data



The following table lists the manager keypad and instructions to display pump totals for Encore and Eclipse units:

То	Press	Result
Display totals	<ul><li> \$Total for Money</li><li> Vol Total for Volume</li></ul>	Side digit flashes
Select side	<ul><li>1—Side 1 (A)</li><li>2—Side 2 (B)</li></ul>	Side digit flashes
Select grade	ENTER and 1-8 for grades 1-8.	Grade digit flashes
Toggle between side and grade	ENTER	Toggles flashing digit between side and grade digit
Exit	CLEAR	Exits the operation

### **Grade Number Reference Chart**

Туре	Grade
Encore 300	
Dual	1
Quad (Four-hose)	1, 2
Multi-Product Dispenser (MPD)	1, 2, 3
6H BI	1, 2, 3
3 + 0 Bl	1, 2, 3
3+1 BI	1, 2, 3, 6
5+0 BI	1, 2, 3, 4, 5
Encore 500	
Dual	1
Quad	1, 2
MPD	1, 2, 3
3 + 0 Bl	1, 2, 3
6H BI	1, 2, 3
4 Grade MPD	1, 2, 3, 4
5 + 0 Bl	1, 2, 3, 4, 5
3 +1 BI	1, 2, 3, 6
Encore 550	
3 + 0 BI	1, 2, 3

Туре	Grade
Multi-hose Bl	1, 2, 3
MPD	1, 2, 3, 4
Single-hose	1, 2, 3, 4
4 + 0 Bl	1, 2, 3, 4
5 + 0 Bl	1, 2, 3, 4, 5
2 + 1 Bl	1, 2, 6
3 + 1 Bl	1, 2, 3, 6
Multi-hose+1 Bl	1, 2, 3, 6
4 + 1 Bl	1, 2, 3, 4, 6
Encore 500 S/700 S	
Dual	1
Quad	1, 2
MPD	1, 2, 3
3 + 0 Bl	1, 2, 3
6H BI	1, 2, 3
4 Grade MPD	1, 2, 3, 4
5 + 0 Bl	1, 2, 3, 4, 5
3 +1 Bl	1, 2, 3, 6
3 + 0 Bl	1, 2, 3
Multi-hose Bl	1, 2, 3
Multi-hose Hybrid Blender	
5 + 0 MHHB	1, 2, 3, 4, 5
4 + 1 MHHB	1, 2, 3, 4, 6
MPD	1, 2, 3, 4
Single-hose	1, 2, 3, 4
4 + 0 Bl	1, 2, 3, 4
5 + 0 Bl	1, 2, 3, 4, 5
2 + 1 Bl	1, 2, 6
3 + 1 Bl	1, 2, 3, 6
Multi-hose+1 Bl	1, 2, 3, 6
4 + 1 Bl	1, 2, 3, 4, 6
Eclipse	
2 + 0 Bl	1, 2
MPD	1, 2, 3
3 + 0 Bl	1, 2, 3
4 + 0 Bl	1, 2, 3, 4
5 + 0 Bl	1, 2, 3, 4, 5
2 + 1 Bl	1, 2, 6
3 + 1 Bl	1, 2, 3, 6
4 + 1 Bl	1, 2, 3, 4, 6
5 + 1 Bl	1, 2, 3, 4, 5, 6

## **Operating Units**

The Encore and Eclipse units can dispense fuel in one of the following two modes:

- Console mode (two-wire) Authorization and payout occurs at the console
- Standalone mode Authorization and payout occurs at the pump

This section provides instructions for operating the units in either mode.

Note: For the location of components, refer to the illustrations in *"Introducing Encore/Eclipse Series"* on page 3-1.

### **Console Mode (Two-wire)**

Consoles can be set up in a pre-authorized mode where a sale is automatically allowed, or in an authorization mode where a sale requires initiation by a cashier.

To operate a unit in authorization mode, proceed as follows:

*Note: Step 1 can occur before or after steps 2 and 3.* 

- 1 Authorize the unit at the console.
- 2 Remove the nozzle and lift the pump handle, if required.
- **3** Select the grade and/or payment form, if required.
- **4** Dispense the fuel.
- **5** Return the nozzle to the nozzle boot.
- 6 Pay out the fuel transaction at the console.

### **Standalone Mode**

Standalone mode does not involve the console with the sale. To operate a unit in a pre-authorized mode, proceed as follows:

- 1 Remove the nozzle and lift the pump handle, if required.
- 2 Select the grade and/or payment form, if required.
- **3** Dispense the fuel.
- **4** Return the nozzle to the nozzle boot.

## 4 – Preparing to Service Units

This chapter provides instructions for collecting information on any unit-related problems that a Gilbarco trained Authorized Service Contractor (ASC) or Customer Specified Contractor (CSC) will require for servicing. Providing complete information can shorten the time ASCs/CSCs spend troubleshooting the problem and enable them to have the correct parts required for service.

## 

Do not attempt to service an Encore or Eclipse pump/dispenser yourself without special, qualified training. Servicing an Encore or Eclipse pump/dispenser incorrectly could result in severe injury or death. Only Gilbarco-trained ASCs/CSCs must service an Encore or Eclipse pump/dispenser.

## 

Do not make unapproved modifications to Gilbarco equipment. Doing so could result in improper equipment operation and violation of state and local codes, and could also create a safety hazard. Consult your ASC/CSC, distributor, or Gilbarco for approved modifications and kits.

## **Important Considerations for DEF Dispensers**

## CAUTION

Applicable during installation and operation of the dispenser: DEF freezes at approximately 11 °F (-11.5 °C). Power to the dispenser and heater must always remain ON in cold weather. If power is lost and the temperature drops below this point, the system must be inspected for freeze damage before restart. For sites that experience occasional power losses or for sites that are located in very cold climates, it is recommended that a backup power generator be used to maintain constant power to the dispenser. Do not use any additives to lower the freezing point of DEF. Additives of any type must not be used in DEF. Freezing can cause damaged or inoperative hose breakaways, fluid lines or components, valves, nozzles, and meters.

Prolonged storage at temperatures above 77  $^\circ\text{F}$  (25  $^\circ\text{C})$  can impair the quality of DEF and reduce its shelf life.

## CAUTION

DEF is mildly corrosive. It can corrode components that are made from incompatible materials and reduce their integrity. The use of incompatible materials may lead to leaks and spills, and can contaminate and degrade the DEF. When dispensing DEF, verify with the manufacturer if the material of all plumbing components are compatible with the DEF being dispensed.

### CAUTION

Do not use prover cans meant for engine fuel with DEF or vice versa. Use stainless steel prover cans for DEF. DEF and engine fuel must not be mixed with each other or contaminated by each other. Otherwise, damage to a vehicle's engine or pollution control devices could occur. DEF crystallizes as its water base evaporates. Pouring out liquid will not guarantee that no corrosive DEF remains in the prover can. DEF must not be contaminated with Diesel fuel, contaminants, or other fluids or materials. Such contamination can cause serious damage to vehicle catalytic converters.

- Conventional fluid handling precautions are also applicable to DEF.
- DEF is non-flammable and not explosive.
- When exposed to air, the water in DEF will evaporate and result in development of urea crystals. Crystals may be fine and sharp. They will dissolve in water
- Clean any DEF spill with water and dry the area with clean rags, especially areas that contain metallic parts. Ensure that spilled DEF does not re-enter the tank. Spilled DEF can be slippery and will corrode metallic parts. Wear eye protection and rubber gloves during any cleanup activity.
- DEF can be returned to the storage tank only if it is not contaminated. Contaminated DEF must be disposed off in an environmentally safe manner. Do not dump DEF in storm sewers or any location where the fluid or its constituents may enter a waterway.
- DEF is much heavier than fuels such as gasoline. Be careful to avoid injury when lifting heavier Prover Cans, by using proper safe lifting techniques.

## \land WARNING

When stored at temperatures above 100 °F (37 °C), DEF may break down into ammonia. Ensure that you avoid inhaling any toxic ammonia vapors when opening cabinets, tank vaults, or other areas where DEF may have leaked or been spilled.

## 

DEF can cause serious eye injury if sprayed in the eyes or may affect those with sensitive skin. Wear protective gloves and eye protection as required. Flush eyes immediately with water, if sprayed.

Ensure that eyewash stations and safety showers are close to the workstation location.

## Important Considerations for Units with Ecometers™

Units must always use the M008007B010 (gasoline) or M08007B030 (diesel) filter manufactured by PetroClear® filter.

To maintain warranty, the unit requires use of a special filter type as mentioned above. It potentially allows lesser contaminant to pass through it during normal unit operation as compared to other filters and prevents nozzles from snapping shut. The filter has a standard mounting and is similar in cost to current filters. The filter contains a slightly higher load spring. In addition, it has improved internal sealing. The filter will also potentially improve the reliability of other hydraulic devices in the dispenser such as valves.

## **Important Considerations When Changing Fuel Types**

## 

Certain special alternative fuels such as E85 and additives can degrade pump/dispenser performance or integrity if the dispensers are not designed for use with such fuels. Additionally, converting to certain standard fuels (gasoline, diesel, kerosene, and so on) from alternative fuels such as those with ethanol (E85), methanol, or biodiesel or from alternative fuels to standard fuels can degrade dispenser performance or integrity. Similar effects can also occur when converting units to different standard fuel types. As per UL 87A requirements, units dispensing E85 fuel must not be used to dispense any other type of fuel such as Gasoline.

Leaks and potential environmental hazards can result or components may fail prematurely.

To avoid these issues, follow the guidelines as described in this section.

Follow the guidelines given below when changing fuel types for a pump/dispenser or using alternative fuels or fluids:

- 1 Verify with your Gilbarco ASC or distributor if the fuel that you will use is compatible with the pumps/dispensers that dispense the fuel.
- 2 For Flexible Fuel (FF) dispensers, do not use standard hydraulic parts used in other Gilbarco pumps/dispensers in these units. Standard dispenser parts may not be compatible with the fluids.
- **3** Biodiesel fuels must be to American Society for Testing and Materials (ASTM) standards for biodiesel fuels. Mixes of diesel with cooking oils, other plant or animal derived oils, and so on are not considered biodiesel. Use of such mixes may void warranty on the hydraulic components of the unit.
- 4 Review the latest copy of the unit's warranty statement regarding use of the fuel.
- 5 Certain fuels (especially fuels enhanced with alcohol) when first used in tanks previously containing a different fuel may clean out the tanks and force a large amount of contaminant into the dispenser. Apart from abnormally clogging filters, this large quantity of contaminant may damage certain dispenser components. Do not run units without filters at such times. It is normally required that tanks and lines be cleaned of all water, sediment and contaminant before such conversions, to minimize potential unit downtime or damage. Damage to hydraulic components from contamination when not using filters is not covered by warranty. Consult your ASC or Gilbarco distributor for recommendations.
- 6 Do not use any equipment that was formerly used to store or dispense any other fuel or liquid with DEF. Dispensers designed for use with DEF must only be used with DEF.
- 7 Although conversions from one fuel to an equivalent fuel (say from another supplier) generally do not create issues, it is recommended that after making any fuel type conversions (including those to alternative fuels such as E85 or back), all units be visually inspected for leaks two days, one week, and one month after fuel conversion. Have your ASC repair any leaks found. This must be done also for standard fuels when significant new additives are incorporated.

*Note: This does not apply to FF model dispensers.* 

- 8 It is recommended that whenever making non-equivalent fuel conversions, all units be checked for calibration within one month after the fuel conversion.
- **9** Some non-equivalent fuel conversions must change the pump/dispenser filter type previously used. For any changes required, consult your ASC or Gilbarco Distributor.

## **Dispensing Gasoline/Ethanol Blends**

The blending option provided on these dispensers is intended for the blending of gasoline/ethanol blends designated as E85 with gasoline or gasohol (E10 maximum) to achieve an intermediate gasoline/ethanol blend.

### **IMPORTANT INFORMATION**

Standard gasoline or gasohol (E10 maximum) must not be dispensed through the same hose as that used for dispensing higher ethanol blend fuels (E11 to E85).

## **Important Requirements for E85 Units**

The following equipment and materials are required to properly service the E85 units:

### UL-listed E85 Hose (Q13486)

- Veyance<sup>SM</sup> Flexsteel<sup>®</sup> Futura<sup>™</sup> Ethan-All for E85
- Veyance Flexsteel Futura for E25

Note: Extended reach hoses not available for the E85 applications.

### UL-listed E85 Nozzle (M11298)

OPW<sup>®</sup> 21GE Note: Approved for use with the E85 dispensers, as required under UL 87A.

### UL-listed E85 Swivel (N23748-04)

OPW 241 TPS-0492 Note: Approved for use with E85 dispensers, as required under UL 87A.

UL-listed E85 Shear Valve (T19695-23) OPW 10P-0152E85 Note: Approved for use with E85 dispensers, as required under UL 87A.

### UL-listed E85 Breakaway (N23010-10)

OPW 66V-0492 Note: Approved for use with E85 dispensers, as required under UL 87A.

### Filter

Use only filters specifically marked for use with E85.

### **UL-listed Pipe Sealant**

Use only UL-listed TPS PTFE pipe sealant manufactured by SAF-T-LOC International Corp.

### **UL-listed Teflon® Tape**

Use only UL-listed Taega Technologies Inc. Teflon tape. *Note: Teflon tape must be used only at the inlet pipe connection.* 

## **Call Gilbarco First**

Before calling an ASC/CSC, call the Gilbarco Help Desk at 1-800-800-7498. The Help Desk may be able to resolve the issue for you.

## **Service Preparation**

Use an ASC/CSC to efficiently service and maintain your Encore and Eclipse units. Gilbarco trains and certifies ASCs/CSCs to service and maintain Encore and Eclipse units in a safe manner. Warranty service must be performed by an ASC/CSC only.

### Before Making Service Call

Before you make a service call, perform the following tasks:

- Obtain complete information from station personnel about the problem. Provide any history that may help (whether the unit has a recurring problem, or the problem has been observed for the first time, and so on).
- Mention the associated hose number(s) along with the problem.
- Confirm that the tank has fuel.
- Confirm that the power, pump lights, and circuit breakers are on.
- For electronic units, write down and report any error codes displayed.

*Note:* For information on recording and clearing error codes, refer to "Error Codes" on page 4-9.

### **Description of Problem**

Provide the ASC/CSC with a complete and accurate description of the problem, including all symptoms and error codes. Ensure that you give the service personnel as complete and accurate information as possible. It will help ensure faster and potentially less costly repairs and keep downtime costs to a minimum.

### Warranty Service

## **IMPORTANT INFORMATION**

All warranty service must be performed by an ASC/CSC. Failure to use an ASC/CSC to perform warranty service could result in loss of warranty coverage.

## **Station Security**

In any manufacturer's unit, it may be impossible, even with a detailed security arrangement, to stop a knowledgeable, unobserved, and experienced thief. It is possible to reduce the probability of a theft attempt, if security measures are designed into the station layout and security-minded actions are planned into the site's operation. The following recommendations are intended to decrease the probability of theft by observance and/or incorporating obstacles that deter criminal activity.

### **Enhancing Security**

To enhance security, proceed as follows:

- 1 Design stations where employees have full, unobstructed view of all fueling locations. Do not block employee view with merchandise displays or other obstructions. If full view is not possible, utilize video surveillance equipment. Equipment monitoring must be made obvious and signs stating their use must be posted.
- 2 Enter new programming access code, as default codes are commonly known. Only trusted station employees and involved ASCs/CSCs must know these codes. Store the codes in a safe and secure location known to all station management personnel. Unit service can be costlier, if these codes are lost.
- **3** Use unit security kits when available. For areas subject to high risk of theft, consider the additional security of special keys/locks to replace the standard locks. Such keys and locks can be obtained from local locksmiths. This enhancement is extremely effective in preventing theft modes using the keypad with the additional benefits of preventing potential tampering with other dispenser devices.
- **4** Remove the keypads from the units and store them in the station or other safe locations. The keypads must be accessible to station management or service people when required. A sign out system can be used to track who last used the keypad.
- **5** Suggest that the station monitor "pump total" and "station total" reports comparatively. Theft can be noted as fuel dispensed will still be recorded in "pump totals" (although not in "station totals"), if a thief use the manager keypad. When this will not prevent the theft that has already occurred, it will alert the station as to whether security measures are working or must be applied.
- 6 Plan to use modular programming "time-out" functions that shut down the unit if no pulser activity occurs for a preselected time. Consult your ASC and determine if there is any optional software that can be used on your units to enhance security.
- 7 Remind station personnel to be alert to any unit off-line message at the Point of Sale (POS), accompanied by suspicious activity at the pump/dispenser.
- 8 Plan to provide periodic/frequent inspection of equipment security provisions to verify their integrity.
- **9** At installation and thereafter, ensure that lower door levers are adjusted correctly and do not allow the panels to be removed easily without a key or tool. If you suspect that keys are available to thieves in your area, consider using special locks and keys available from locksmiths.
- **10** Be alert to dispensers being "off-line" or equivalent at the POS. Fuel theft could be occurring especially if the customer is pumping fuel.
- **11** For units left powered during off hours, ensure that power to the Submersible Turbine Pumps (STPs) is turned off.

## **Additional Security in Encore S Series Units**

The Encore S series units have been designed with security in mind to prevent/minimize the probability of fuel theft.

In addition to security features that have been built into the Encore units so far, such as the CIM, lower panel locks and keys, and the PIN code-secured manager keypad, the Encore S series unit comes with the following additional security features:

- A separate printer door (with a lock) that restricts access to the inside of the unit.
- A security latch that may be used to secure the lower part of the main door (bezel). See Figure 4-1 on page 4-8.
- An improved design that does not enable a person to open the main door without first removing the lower panel door.
- An option to install hinge sensors that will send an alert to the POS whenever the main/lower panel doors are opened.

To optimally utilize the additional security features installed in the Encore S series units, proceed as follows:

- 1 Close and lock the main door, using the main door lock located to the left of the main door. To identify the location of the lock, see Figure 3-1 on page 3-1.
  - Notes: 1) When closing the main door, remember to push inward and then lock the door to ensure that the inner lining is sealed to prevent rain water from seeping into the main door.
    - 2) If you do not close the main door properly, you will have problems when removing or reinstalling the lower panel door.
- 2 Place the security latch in the locked position. *Note: You may use a padlock (optional) to secure the latch.*

**3** Place the lower panel door and lock it using the lower panel lock.



#### Figure 4-1: Security Latch - Open and Locked Positions



2) ASCs must be aware of any lock changes or added locks in order to service the unit. The keys must be available to the ASCs.

### Important Installation Information

To ensure that your equipment provides safe and reliable operation, verify the following:

- Hose breakaways for drive-off protection must be installed. For breakaways to properly function, the pumps must be anchored to the island with bolts.
- Dispensers and some self-contained pumps must use shear valves. Refer to the local and state codes.
- Proper operating and safety warning signs must be used at the station. Refer to the local and state codes and consult the oil company.
- Station emergency stop buttons must be used. Refer to the state and local codes.
- Isolation relays must be used with dispensers. Refer to the national, state, and local codes.
- Shear valve linkage must be free of obstructions so that the valve can close properly during a fire or accident.
- Ensure that the installers follow all other requirements and recommendations in *MDE-3802 Encore and Eclipse Site Preparation Manual*, *MDE-3985 Encore Installation Manual*, and *MDE-3986 Eclipse Installation Manual*.

### **Unit Commissioning**

Unit commissioning is a valuable service included in the purchase price of most dispensers. During commissioning, the ASC/CSC inspects and verifies if the units have been properly installed and operate as intended. Some unit training is also given to station employees as part of the process. You must ensure that the units are commissioned shortly after installation. Improper installation can void warranty or result in poor unit performance.

### **Error Codes**

If an error or malfunction occurs, the Liquid Crystal Display (LCD) on the main display may flash and alternately display the error code and the normal readout. Some error codes can appear at the PPU. These must not be confused with numbers that may flash when power is first applied to the unit. These numbers represent software versions and other similar information, and are not error codes.

### **Recording Error Codes**

Error codes provide an excellent service and troubleshooting tool for ASCs/CSCs and will ensure that the ASC/CSC brings the correct part to the site for a quick repair. Record all error codes and provide the list to your ASC/CSC. The ASC/CSC uses these codes to diagnose and repair unit problems, which results in less down time.

### **Clearing Error Codes**

In some cases, you can permanently clear error codes from the unit. To clear an error code, proceed as follows:

- 1 For EC 44 pump handle on at power up, replace handle, power down, and then power up. One instance of this error code does not normally require a service call.
- 2 If the error code still appears, power down the unit, wait for one minute, and then restore power using the station circuit breaker.
- **3** If the error code still appears or reappears at a later time, record the error code and call your ASC/CSC for assistance.

### **Replacement Parts**

Use only genuine Gilbarco replacement parts and retrofit kits on your unit.



Gilbarco replacement parts are required to maintain warranty.

### **Specialized Training**

For safety reasons, do not attempt to service an Encore or Eclipse unit yourself, unless you have been trained and certified to do so.



Do not attempt to service an Encore or Eclipse pump/dispenser yourself. Only a Gilbarco-trained ASC/CSC must service an Encore or Eclipse pump/dispenser. Servicing an Encore or Eclipse pump/dispenser incorrectly could result in severe injury or death.

To receive specialized training for servicing Encore and Eclipse units, contact an ASC/CSC or distributor. Training may be available locally or at various regional centers.

ASCs/CSCs and distributors may charge a nominal training fee. For more information, contact your nearest distributor.
# 5 – Maintaining Units

This chapter provides information on the following aspects of pump/dispenser maintenance:

- Periodic Inspections
- Periodic Maintenance Requirements
- Special Maintenance Instructions

## CAUTION

DEF is mildly corrosive. To avoid damage to components in the vicinity of the dispenser, avoid use of materials that could be corroded, or use protective coatings.

## CAUTION

Do not open the electronics cabinet to change paper, to remove cash acceptor cassettes, or to perform any other tasks when it is raining. The moisture from the rain can damage the pump/dispenser.

# **General Safety Considerations**

Safe operation of the equipment is very important to your customer and you. The following recommendations are in addition to those found in the sections that follow and "Important Safety Information" on page 2-1.

- 1 Do not allow the customer to use damaged units or broken components with sharp edges.
- 2 Do not allow the customer to use units with missing doors or panels or with doors open.
- 3 Ensure that the adequate and readable instructions are clearly given on the units or nearby areas for potential safety hazards such as static electricity fueling hazards, use of unapproved containers, and so on. Place signs where fueling customers will notice and can read them.
- **4** Do not use long hoses beyond recommendations that may present a trip hazard. Use hose retrievers in good operating condition, when long hoses are used.
- **5** Do not allow the customer to use units which do not have hose breakaways installed on them.
- 6 Do not allow the customer to use units with hoses and/or nozzles removed from either side.

7 Do not allow the customer to use units that are leaking fuel.

# 

DEF, flexible fuels such as biodiesel, high alcohol percentage fuels such as E85, and so on may be incompatible with certain plumbing materials and hydraulic components.

Use of incompatible materials or components with alternative fuels such as E85 or DEF can result in leaks or unexpected failures of components resulting in fire or explosion or environmental damage. When installing components in E85 units, refer to "Important Requirements for E85 Units" on page 4-4.

When dispensing alternative fuels such as E85 or DEF, verify with the manufacturer if the material of all plumbing components are compatible with the fuels or DEF being dispensed.

# **Periodic Inspections**

The Gilbarco Encore FlexPay<sup>™</sup> IV is a Payment Card Industry PIN Entry Device (PCI-PED) payment device. As a result, the equipment owner is responsible for regular inspection of the device for signs of tampering or replacement and tracking of all events in the life cycle of the device, including: installation, maintenance events, audit events, inspection events, removal from site, and decommission. As a convenience, Gilbarco offers Insite360<sup>™</sup> Encore, which can assist with asset-level tracking.

## **Performing General and Component Maintenance Inspections**

This section provides instructions for scheduling two types of maintenance inspections:

- General inspections
- Component inspections

Note: This section does not include special inspections such as those required when changing fuel types. For those requirements, refer to "Important Considerations When Changing Fuel Types" on page 4-3.

#### Safety Warnings

You are performing inspections and maintenance in a potentially dangerous environment of flammable fuels/vapors and high voltage. To prevent injury when inspecting a unit at the islands, follow all safety precautions in "Important Safety Information" on page 2-1.

# 🕂 WARNING

You are performing inspections and maintenance in a potentially dangerous environment of flammable fuels/vapors and high voltage. Failure to adhere to the safety precautions in this manual may cause fire or explosion, resulting in severe injury or death. Read and adhere to all safety precautions before performing any maintenance activity.

## **General Inspections**

Perform a general inspection of each unit as follows:

- Every week to ensure that all units are operating properly
- Whenever you receive a complaint about potential unit problems

As part of your general inspection, inspect the entire pump or dispenser for the following indications:

- External damage
- Leaks
- Exposed sharp or similar edges that may cause cuts
- Missing parts, doors, and so on.
- Safety hazards when fueling, such as slippery surfaces, trip hazards, missing warning signs, and so on.

Replace any missing or damaged warning labels. Gilbarco also strongly recommends that ASCs/CSCs periodically inspect the equipment as outlined in the next subsection.

# 

If you find any leaks or damage, stop using the pump/dispenser, and contact your local ASC/CSC. Fire, explosion, or electrical shock could result, if you continue to use leaking or damaged pumps/dispensers.

# 

To prevent injury to customers or yourself, block customer access to the pump/dispenser with cones or similar equipment, when inspecting.

## **Component Inspections**

To schedule component inspections, refer to the following table. Generally, the station owner must only *inspect* for damage or problems with the units. For safety reasons, several tasks in the following table, including *all* repairs, must be performed only by an ASC/CSC. To determine if an ASC/CSC must perform a task, refer to the column titled "Who Performs the Inspection/Repair" on page 5-4.

# 

Do not attempt to perform any task that is noted "ASC/CSC only" in the "Who Performs the Inspection/Repair" column on page 5-4. Performing those tasks incorrectly could result in severe injury or death.

## 

If you find a leak during an inspection, stop using the pump/dispenser, and contact your local ASC/CSC. Fire, explosion, or electrical shock could result, if you continue to use a leaking or damaged pump/dispenser.

Recommended Frequency	Who Performs the Inspection/Repair			
Once a week or when changing the printer paper	Keypad/ Printer	<ul> <li>While checking/changing printer paper, also inspect the keypad:</li> <li>1. The A2-09 keypad is a touchpad on the glass.</li> <li>The keys are back-lit.</li> <li>The numbers must be illuminated when the keypad is active. If the numbers don't light up when the keypad is active, then check the keypad for signs of tampering or an overlay.</li> <li>The key is flat. Inspect from the front and the side to make sure that nothing has been overlayed. Use your hands to make sure the surface is smooth.</li> </ul>	Owner	
Once a month	Belts	Recommended Belt Tensions: Tighter belt tensions can cause wear and premature failures for both pump and motor bearing. Loose belts result in low flow or pulley/belt failures. Use the following ratings: • 65-75 lbs (30-34 Kgf) for new belts • 50-65 lbs (28-30 Kgf) for old belts	Owner - Inspect     ASC/CSC only - Repair     and test	
		CAUTION Belts and pulleys can pinch finge Injuries may result. Avoid placing between belts and pulley. Never belt on pulley.	ers and hands. g fingers or hands turn power on to fit	
		<ol> <li>On the link belts, check all tabs for correct positions (inward).</li> <li>Check the belt tension. If there is more than 1 inch of play on one side of belt, then tighten the belts by tightening the idler pulley against the belt. If there is excessive play, then replace the belt with the next shorter length belt</li> </ol>		

Once a week or if F a customer p complaint arises	Replacing	Refer to the instructions in "Changing Receipt Paper	Ownor
	pinio, papo	in M00317A00X Printer" on page 5-17 or "Changing Receipt Paper in USB Printer (M04119A001)" on page 5-20 or "Changing Receipt Paper in USB Sliding Printer (M06972A001)" on page 5-23 or "Changing Receipt Paper in USB Sliding Printer for Encore S Series E-CIM Bezel (M07885A001)" on page 5-26.	Gwnei
Once a week or if C a customer p complaint arises	Correcting printer jams	Refer to the instructions in "Clearing Paper Jams in FlexPay 6 A2-09" on page 5-30 or "Clearing Paper Jams in USB Sliding Printer (M06972A001)" on page 5-34.	Owner
Once a week [	Displays	<ol> <li>Inspect displays for proper reading of all digits.</li> <li>Verify if the displays are properly backlit.</li> </ol>	Owner - Inspect     ASC/CSC only - Repair     and test
At least once a H week or if a customer	Hoses	1. Inspect each hose for leaks and damage.	Owner - Inspect     ASC/CSC only - Repair     and test
		If you find a leak, stop using the pump/dispen your local ASC/CSC. Fire, explosion or electri result, if you continue to use a damaged pum	ser, and contact ical shock could p/dispenser.
		2. Inspect each hose for the following wear or damage: • Bulges • Cracks • Cuts • Flattened spots • Reinforcement showing • Soft spots • Splits • Weaknesses	
		<ul> <li>Tears</li> <li>Consult the hose manufacturer for any additional inspections required.</li> <li>Note: If repair is required, call an ASC/CSC.</li> </ul>	

Do not attempt to make these repairs yourself. Doing so could result in severe injury or death.

Recommended Frequency	Components	Recommended Maintenance	Who Performs the Inspection/Repair
Once a week or if a customer complaint arises	Hose retrievers	<ol> <li>Inspect hose retrievers for frayed or broken cables.</li> <li>Inspect hose retrievers for cables wrapped around hoses.</li> </ol>	Owner - Inspect     ASC/CSC only - Repair     and test
		Notes: 1. If repair is required, call an ASC/CSC. 2. When hose retrievers are used, the breakaway whip hose must be attached to the nozzle, and the breakaway coupling attached to the whip hose, with the retriever clamp positioned between the breakaway coupling and the dispenser outlet casting. When retrievers are not used, the breakaway whip hose is attached to the dispenser outlet casting and the breakaway coupling is attached to the other end of the breakaway whip hose.	
		WARNING Do not attempt to make these repairs yoursel result in severe injury or death.	f. Doing so could
Once a week or as notified about a potential problem	Nozzles and boot area	<ol> <li>Inspect nozzles for the following:</li> <li>Damage</li> <li>Leaks</li> <li>Loose nozzle spouts</li> <li>Missing parts, such as retainer springs and splash guards</li> </ol>	Owner - Inspect     ASC/CSC only - Repair     and test
		A WARNING	
		If you find a leak, stop using the pump/dispen your local ASC/CSC. Fire, explosion, or electr result, if you continue to use a damaged pum	ser, and contact ical shock could p/dispenser.
		<ol> <li>Inspect vapor recovery boots (bellows) for proper seal and signs of damage.</li> <li>Consult the nozzle manufacturer for any additional required inspections. <i>Note: If repair is required, call an ASC/CSC.</i></li> </ol>	
		Do not attempt to make these repairs yoursel result in severe injury or death.	f. Doing so could

Recommended Frequency	Components	Recommended Maintenance	Who Performs the Inspection/Repair
Once a week, or as notified about a potential leak unit		<ul> <li>Breakaways</li> <li>Couplings</li> <li>Hose outlet castings</li> <li>Hoses</li> <li>Nozzles</li> <li>Swivels</li> <li>Look for any signs of fuel or fuel staining around the base of the dispenser, especially at the side columns and at the upper housing.</li> <li>Review all documentation provided by each component's manufacturer for additional inspection information.</li> <li>If a leak is found, stop using the unit, and make arrangements to repair the leak.</li> </ul> <b>MARNING</b> If you find a leak, stop using the pump/dispenser, and contact your local ASC/CSC. Fire, explosion, or electrical shock coul result, if you continue to use a damaged pump/dispenser. Do not attempt to make these repairs yourself. Doing so couracult in severe injury or death	
		result in severe injury or death.	f. Doing so could
Once a week or after drive-offs	Breakaways	1. Inspect breakaways for secure connection to hose and for any leaks.	<ul> <li>Owner - Inspect</li> <li>ASC/CSC only- Repair and test</li> </ul>
		WARNING If you find a leak, stop using the pump/dispen your local ASC/CSC. Fire, explosion, or electr result, if you continue to use a damaged pump	ser, and contact rical shock could p/dispenser.
		<ol><li>Consult the breakaway manufacturer for any additional required inspections.</li></ol>	
		<ol> <li>Notes:</li> <li>If repair is required, call an ASC/CSC.</li> <li>Some breakaways are not repairable. Check with the ASC/CSC whether the breakaway is repairable before the ASC/CSC attempts to reassemble the breakaway.</li> <li>A leak inspection within the hydraulics cabinet is also required. See the relevant section, later in this chapter.</li> </ol>	
		Do not attempt to make these repairs yourself result in severe injury or death.	. Doing so could
Once a week or as required	Wash unit	Clean with Simple Green <sup>®</sup> all purpose cleaner (or equivalent). Do not wash with a high-pressure hose. Refer to "Cleaning and Detailing Unit" on page 5-35.	Owner

Recommended Frequency	Components	Recommended Maintenance	Who Performs the Inspection/Repair
Once a week or upon complaint of improper reading of cards	Card Reader	Clean the card reader with a Card Reader Cleaning Card (Q11482) weekly or if the card reader is not reading credit cards properly.	Owner
		Cleaning of card readers periodically may prevent future service calls. Card readers that do not work because of lack of periodic cleaning are not covered by warranty.	
		CAUTION	
		Do not use a pressure washer to clean the pu	ımp/dispenser.
Once a week or if a customer complaint arises	Card-reader slot and contactless reader	<ul> <li>Are there any wires of any kind coming out of the Card Slot? <ul> <li>There should be no visible wires at all on or around the Card Slot.</li> </ul> </li> <li>Is the OPT finish uninterrupted and consistent across the Card Slot? <ul> <li>There should be no cracks, holes or bumps of any kind.</li> </ul> </li> <li>Does the card slot acceptor light: <ul> <li>Flash green when it is ready and waiting to accept a card?</li> <li>Turn red when a card is inserted and a transaction is processing?</li> <li>Turn blue only when the card can be safely removed?</li> </ul> </li> <li>Does the Contactless Reader: <ul> <li>Show one steady green light when ready to accept a payment?</li> </ul> </li> </ul> <li>Note: Remember, if your Invenco OPT does not look or act like it should, do not use it. Contact TAC immediately for further assistance.</li>	Owner
Once a month	Bulbs (Eclipse only)	Where bulbs are used, verify if all light box bulbs are illuminated.	Owner - Inspect     ASC/CSC only - Repair     and test
		To avoid injury when inspecting the bulbs, us sturdy non-conductive fiberglass step ladder. manufacturer safety instructions.	e a safe and Follow ladder
		Do not rest the ladder against the dispenser.	
		Block off area where you will be working.	

Recommended Frequency	Components	Recommended Maintenance	Who Performs the Inspection/Repair
Once a month, after drive-offs, or as notified about a potential leak	Leaks, within the lower hydraulics cabinet	<ol> <li>Whenever possible, Gilbarco recommends removing power to the unit before performing these inspections.</li> <li>Block the unit area to prevent customers from operating the unit during inspection.</li> <li>Remove the lower panels slowly and carefully to avoid any fuel being sprayed in the cabinet (especially if a drive-off has occurred). Wear eye protection.</li> <li>Inspect all hydraulic connections and seals, including the following:         <ul> <li>Meters</li> <li>Valves</li> </ul> </li> <li>If wetness or dripping fuel is found, stop using the unit, and make arrangements to repair the leak. <i>Note: Some staining of parts around seals is normal and does not indicate a problem. Look for dripping or wet surfaces.</i></li> <li>Monitor repaired places closely.</li> </ol>	• Owner - Inspect • ASC/CSC only - Repa and test
			WARNING           To prevent injury when inspecting self (equipped with pumps and electric m place your hands near the belts, pulle Do not allow anyone to use either sid when inspecting. Block the pump/displock the nozzle to the nozzle hook.
		WARNING If you find a leak, stop using the pump/dispen your local ASC/CSC. Fire, explosion, or electr result, if you continue to use a damaged pump	ser, and contact ical shock could o/dispenser.
		<b>WARNING</b> Do not attempt to make these repairs yoursel result in severe injury or death.	f. Doing so could

## CAUTION

Ę

To prevent potential injury, wear eye protection when performing these inspections.

New Installations -Filter change After 50,000 and strainer gallons (200,000 cleaning liters), or after one month

Replace filters, and clean strainers regularly. Note: Water alert filters may fail prematurely if water passes through them.

Only an ASC/CSC must perform these tasks.

Recommended Frequency	Components	Recommended Maintenance	Who Performs the Inspection/Repair
After first filter change - Every 300,000 gallons (1.1 million liters), every six months, or when fuel delivery rate significantly slows.		WARNING     Do not attempt to perform any of these tasks y Performing these tasks incorrectly could result or death.  Note: Most complaints regarding continual slow flow r caused by clogged filters	yourself. t in severe injury rate from the dispenser are
Every three months	Clean CRIND device printer	<ul> <li>Clean the CRIND device M00317A00X Printer using the Printer Cleaning Card Q13400. Follow instructions in "Cleaning CRIND Device in M00317A00X Printer" on page 5-30 (use Moore Wallace M05194B001).</li> <li>Clean the CRIND device M04119A001 [Universal Serial Bus (USB)] Printer using the M05194B001 Cleaning Kit. Follow instructions included in the kit.</li> </ul>	Owner
Every three months	Clean CRIND device display	Clean the CRIND device display regularly with a mild detergent and soft cloth using Moore Wallace M05194B001 Cleaning Kit. Be careful not to scratch the display. Do not use an abrasive cleaner, or glass cleaner or detergent that contains ammonia. Ammonia will damage plastic display windows and door materials.	Owner
Every six months	Inspect and lubricate shear valves	<ul> <li>To check valve operation, perform the following tasks:</li> <li>1. Trip the valve.</li> <li>2. Authorize the hose at the console, if required.</li> <li>3. Lift the operating handle.</li> <li>4. Place the discharge nozzle in an approved container.</li> <li>5. Squeeze the nozzle operating lever. If flow continues after several seconds, the valve is defective and must be serviced or replaced.</li> <li>6. Place a few drops of SAE10 oil on shear valve body shaft.</li> <li>7. Open and close valve with a wrench several times.</li> <li>8. Place valve back in service. <i>Note: If repair is required, call an ASC/CSC.</i></li> </ul>	<ul> <li>Owner - Inspect and lubricate</li> <li>ASC/CSC only - Repair</li> </ul>
		CAUTION	

If you are not sure which device is the shear valve or have not been trained regarding its use or service, have the ASC/CSC inspect and lubricate this device for you.

#### 

Do not attempt to make these repairs yourself. Doing so could result in severe injury or death.

Recommended Frequency	Components	Recommended Maintenance	Who Performs the Inspection/Repair
Every six months	Pump pulleys, belts, and belt tension	1. Remove power to the unit.	Owner - Inspect     ASC/CSC only - Repai and test
		To prevent an injury, remove power to the pur before you start the maintenance activity.	np/dispenser
		CAUTION	
		To avoid injury, avoid getting your fingers in a between the pulley and belt during an inspect	pinch point ion.
		<ol> <li>Inspect belts for fraying/cracks.</li> <li>Inspect pulleys for excessive wear in grooves and excessive bearing play.</li> <li>Ensure that there is no more than 1 inch of play on either side of the belt, by pressing the belt midway between the two pulleys. Note: If repair is required, call an ASC/CSC.</li> </ol>	
		Do not attempt to make these repairs yourself result in severe injury or death.	f. Doing so could
Every six months	Nozzle hooks and shafts	<ol> <li>Lubricate with silicone grease, if required.</li> <li>Check for damage.</li> <li>Ensure that the locking tab locator is not broken. The locking tab locator helps hold the nozzle in the nozzle boot and enables the station owner to lock the nozzle boot with a clasp padlock. <i>Note: If repair is required, call an ASC/CSC.</i></li> </ol>	Owner - Inspect     ASC/CSC only - Repa     and test
		<b>WARNING</b> Do not attempt to make these repairs yourself result in severe injury or death.	f. Doing so could
Every six months	Door locks	Lubricate with a graphite lubricant or lock oil. Follow manufacturer's instructions. Do not over-lubricate.	Owner
Every 12 months or as required in harsh climate	Polish unit	Polish metal parts with Nu Finish <sup>®</sup> car polish. Refer to "Cleaning and Detailing Unit" on page 5-35.	Owner

Recommended Frequency	Components	Recommended Maintenance	Who Performs the Inspection/Repair
When other components are serviced	Eclipse unit fiberglass	Look for loose fiberglass skins, missing brackets, and missing mounting hardware.	<ul> <li>Owner - Inspect</li> <li>ASC/CSC only - Repair</li> </ul>
		Note: If repair is required, call an ASC/CSC.	
		\land WARNING	
		Do not attempt to make these repairs yourself. result in severe injury or death.	Doing so could
Every six months (annually for Encore 550) or if fuel inventory discrepancies exist.	Meter calibration	Have the unit meters checked for proper calibration and corrected as required. High volume stations may require more frequent calibration checks when compared to the low volume stations.	<ul> <li>Owner - arranges for service</li> <li>ASC/CSC - tests and re-calibrates, if required</li> </ul>
For Units with Ec	ometer		
Yearly	Ecometer calibration	Have the unit meters checked for proper calibration and corrected as required. Ecometers with proper air purging during installation will not generally vary from initial calibration settings.	<ul> <li>Owner - arranges for service</li> <li>ASC/CSC - tests and re-calibrates, if required</li> </ul>
For Units Equipp	ed with DEF		
Once a week, especially during cold weather	DEF hose retriever and nozzle door mechanism	Verify if the hose retrieves properly. Verify if the nozzle door opens and closes properly. From a half-way lifted position, the door must close completely unassisted, after the nozzle has been placed back into the nozzle holder.	• Owner - Inspect • ASC - Repair
		CAUTION	
		During cold weather, a hose retriever that doe properly or a nozzle door that does not self clo cause freezing of the nozzle, hose, or other co prevents DEF from being dispensed or may c components that results in leaks.	es not retract ose properly may omponents. This ause damage to
After a DEF spill occurs	Dispenser and surrounding metallic	Flush the DEF spill with water and dry the area with clean rags, especially areas that contain metallic parts.	Owner
	components	Note: Spilled DEF can be slippery and will corrode metallic parts.	
		CAUTION	
		DEF is mildly corrosive. Handle with care. We and rubber gloves during any cleanup activity.	ar eye protection

# **Printer Maintenance Requirements**

## **Printer Paper Specifications**

- FlexPay 6 A1-05 (G6-300) A2-09 (G6-400)
  - Receipt Paper Dimensions: 2.25 in x 380 ft Thermal Paper, 3.2 Mil
- Company: Iconex
- Part Number (SKU#): 9078-3390
- Part Number Link: https://www.iconexstore.com/en\_us/9078-3390-en-us.html
- Hengstler Printer
  - Company: Moore Wallace
  - Part Number: M04809B017 (Blank Roll), M04809B018 (Low Paper Marks)
  - Contact Information: 1-800-416-8151
    - *Note: Hengstler Printer Paper will not work with FlexPay 6 A1-05 (G6-300) and FlexPay 6 A2-09 (G6-400).*

## Changing FlexPay 6 A2-09 Device Printer Paper

*Note: Ensure that you use a correct paper for the successful operation of the printer.* 

Place the paper roll in the correct position, then take the spindle and insert it through the middle of the paper roll.
 *Note: The paper tension flap is spring loaded so you will need to apply some pressure.*

Figure 5-1: Placing Paper Roll



2 Ensure that the paper has a clean-cut edge, then insert the edge into the marked slot.

If the mechanism is closed (side arrows aligned), the printer will automatically grip the paper and feed it through. Otherwise feed it through manually.

#### Figure 5-2: Placing Paper into the Marked Slot



The correct paper position is as seen in the below figure.



#### Figure 5-3: Correct Paper Loaded Position

**3** Use the feed buttons to move the paper back or forward.

Note: Pushing both buttons will cut the paper.





4 Feed the paper through the terminal until it appears out of the chute at the front.

Cut the excess paper using both feed buttons.

## Figure 5-5: Paper Release Location



## **Changing CRIND Device Printer Paper**

This section provides instructions for cleaning and changing paper for the following CRIND device printers:

- M00317A00X
- M04119A001: USB printer that is affixed to the door and can accommodate paper rolls of up to 4 inches in size.
- M06972A001: USB sliding printer that can accommodate paper rolls of up to 6 inches in size.

These printers can be distinguished by identifying the large blue colored mounting screws (pins) that are found only on the M04119A001 and M06972A001 Printers.

#### Figure 5-6: USB Printer with Blue Mounting Pins



Ensure that you follow the correct set of instructions based on the type of printer.



## CAUTION

When the units are wet or when it rains, avoid changing paper for units without overhead canopies. If this cannot be prevented, use a dry rag to wipe off the moisture from the door area especially around the door edges. Avoid dripping water on the printer or other electronic components when opening the door. This will cause them to fail prematurely as a result of corrosion.

## **Cleaning Printer**

Cleaning the printer regularly may help print quality and increase the life-span of the printer. When cleaning the printer, use Moore Wallace M05194B001 Cleaning Kit. For details, refer to "Special Maintenance Instructions" on page 5-35.

## **Printer Paper Ordering Information**

The printer paper is sold as a blank roll or with low paper marks. Paper rolls with low paper marks alert the station about the paper level being low. The following table lists the information for ordering printer paper:

Vender	Туре	Part No.	Printer Type
Moore Wallace Customer Service 1-800-416-8151	Blank Roll (4")	M04809B012	<ul><li>M04119A001 (USB)</li><li>M00317A00X Printer</li></ul>
	Low Paper Marks (4")	M04809B014	<ul><li>M04119A001 (USB)</li><li>M00317A00X Printer</li></ul>
Nakagawa Mfg (USA)	Blank Roll (4")	N60125BN	M04119A001 (USB)
1-800-609-0608	Low Paper Marks (4")	N60125DN	M04119A001 (USB)
Moore Wallace Customer	Blank Roll (6")	M04809B017	M06972A001 (Sliding)
Service 1-800-416-8151	Low Paper Marks (6")	M04809B018	M06972A001 (Sliding)

*Notes: 1) Use of improper paper can result in poor quality print, shortened printer life or frequent printer jams, which may not be covered by warranty.* 

2) It is important that all operators be trained in proper paper changing technique for problem-free operation.

## Changing Receipt Paper in M00317A00X Printer



## Figure 5-7: M00317A00X Printer

## CAUTION

Avoid touching any wires or circuit boards during paper replacement, as static electricity from your fingers may damage the unit.

To replace the receipt paper in the M00317A00X Printer, proceed as follows:

- **1** Remove the paper roll core.
- 2 Raise cover over printer head.

#### Figure 5-8: Printer Cover - Opening



**3** Pull the paper release lever towards you.

#### Figure 5-9: Paper Release Lever - Releasing



4 Inspect and remove any paper from the printer chute (paper shards in the printer chute can cause a subsequent printer jam).



#### Figure 5-10: Paper Between Rollers

5 Feed the new paper into the inlet until the paper passes over the stainless steel V-shaped cutter and out of the chute exit at the front of the dispenser.

*Note: The paper must run straight into the chute. Straighten and center the paper as required when feeding.* 

Figure 5-11: Paper Feed



6 Push the paper release lever completely in the forward direction (away from you).

Figure 5-12: Paper Release Lever - Locking



7 Close the cover over the printer mechanism completely. Any gaps may lead to paper jams later.

Figure 5-13: Printer Cover - Closing



8 Tear the excess paper at the chute opening.

## Changing Receipt Paper in USB Printer (M04119A001)

#### Figure 5-14: USB Printer



## CAUTION

Avoid touching any wires or circuit boards during paper replacement, as static electricity from your fingers may damage the unit.

To replace the receipt paper in the USB printer, proceed as follows:

- **1** Remove the paper roll core.
  - *Note:* To prevent paper from being trapped inside the printer, the printer automatically reverses the last short receipt left from the paper roll. Remove such receipts along with the paper roll core, if present.

Figure 5-15: Paper Removal



Note: In Encore S series, the printer is installed in an inverted manner, as you open the printer door as shown in Figure 5-16. Apart from the way in which the printer is installed, the procedure for changing the receipt printer paper remains as explained in this section.



#### Figure 5-16: Printer in Encore S Series Unit

**2** Locate the paper removal trigger on the left-hand side of the printer. This is located directly under the "Remove Paper" trigger decal. For the exact location of the trigger, see Figure 5-17 on page 5-22.

**3** Press the trigger when gently pulling the paper to cleanly remove the paper from the paper feed path.



#### Figure 5-17: Paper Removal - Trigger Decal

4 Place the new roll of paper in the paper bucket. For orientation, see Figure 5-18.

Figure 5-18: Paper Feeding into Printer





5 Feed the paper into the printer inlet following the direction of arrows on the printer. Note: If the gears rattle when loading the paper, press trigger and feed the paper simultaneously.

The paper will automatically feed through the printer after the initial feed is done manually.

## Changing Receipt Paper in USB Sliding Printer (M06972A001)



Figure 5-19: USB Sliding Printer

## CAUTION

Avoid touching any wires or circuit boards during paper replacement, as static electricity from your fingers may damage the unit.

To replace the receipt paper in the sliding printer, proceed as follows:

- **1** Remove the paper roll core.
  - *Note:* To prevent paper from being trapped inside the printer, the printer automatically reverses the last short receipt left from the paper roll. Remove such receipts along with the paper roll core, if present.

Figure 5-20: Paper Removal



Figure 5-21: Printer in Encore S Series Unit



- 2 Locate the paper removal trigger on the right side of the printer. This is located directly under the "Remove Paper" trigger decal. For the exact location of the trigger, see Figure 5-22.
- **3** Press the trigger when gently pulling the paper to completely remove the paper from the paper feed path.



#### Figure 5-22: Paper Removal - Trigger Decal

4 Place the new roll of paper in the paper bucket. For orientation, see Figure 5-23.

Figure 5-23: Feeding Paper into Printer





5 Feed the paper into the printer inlet following the direction of arrows on the printer. Note: If the gears rattle when loading the paper, press trigger and feed the paper simultaneously.

The paper will automatically feed through the printer after the initial feed is done manually.

# Changing Receipt Paper in USB Sliding Printer for Encore S Series E-CIM Bezel (M07885A001)

To change the receipt paper in the printer, proceed as follows:

- *Note: The USB Sliding Printer for Encore S Series E-CIM (M07885A001) is capable of holding a receipt paper roll of 6 inches.*
- 1 Insert the printer key and turn it to the left to open the printer door.

#### Figure 5-24: Inserting Printer Key



**2** Open the printer door and pull out the slide completely.



## Figure 5-25: Opening Door and Pulling out Slide

**3** Pull the empty paper spindle from the cable clamp. *Note: The unit is shipped with the spindle held by the cable clamp.* 

Figure 5-26: Pulling Paper Spindle



Figure 5-27: Spindle



**4** Insert the spindle in a new paper roll and slide it into the spindle slot with the paper feeding from over the top.



Figure 5-28: Inserting New Paper Roll

**5** Remove any small pieces of paper behind the printer head.

- 6 Feed the paper into the printer using the built-in ramp as a guide.
  - *Note:* Ensure that the paper is fully fed before you proceed. If the paper is not fed, check if the paper is jammed.

#### Figure 5-29: Feeding Paper into Printer



7 Push the printer slide back in and feed the paper through the slot. Close the printer door and turn the key to the right to lock it.



#### Figure 5-30: Pushing Printer Slide

8 Pull to tear paper.

## Cleaning CRIND Device in M00317A00X Printer

Clean the CRIND device in the M00317A00X Printer using Printer Cleaning Cards (Q13400) every three months. Cleaning the printer will eliminate most print quality problems.

To clean the CRIND device's printer, proceed as follows:

- 1 Remove the paper and paper roll from the printer. Refer to "Changing Receipt Paper in M00317A00X Printer" on page 5-17 (steps 1 to 4).
- 2 Insert a printer cleaning card into the inlet.
- 3 Manually advance the cleaning card through the roller bars using the round feed knob near the paper release lever.
- 4 Replace the paper roll and re-install the receipt paper. Refer to "Changing Receipt Paper in M00317A00X Printer" on page 5-17.

## **Clearing Paper Jams in FlexPay 6 A2-09**

If the red LED near the printer chute is lit and there is a beep every few seconds, this indicates a paper jam. If you need to clear a paper jam, remember:

- Don't use anything sharp it could damage the printer.
- Be gentle. If you take the paper roll out, you should be able to see where the paper is jammed and free it with a little bit of patience and a gentle touch.
- Any damage done to the printer while clearing a paper jam is not covered by warranty.

To clear a paper jam, proceed as follows:

**1** Remove the paper roll if necessary by pulling out the spindle. You can then lift the roll up and pull.

#### Figure 5-31: Pulling Out the Spindle



**2** Pull the white lever on the side of the printer mechanism. This should disengage the printer platen.

Figure 5-32: Pulling the White Lever



Figure 5-33: Disengaging the Printer Platen



3 Carefully remove any jammed paper. Do not use sharp objects.

When the paper jam is cleared, push the printer platen back in its original position until the lever clicks back in place.

**4** You can now reload the paper roll.

#### Figure 5-34: Reload the Paper Roll



## Clearing Paper Jams in USB Printer (M04119A001)



To clear a paper jam, proceed as follows:

1 Pull the right blue pin and lift the printer control module to expose the jam. Note: In Encore S series units, the printer is installed in an inverted manner. Hence, pull the left blue pin to lift the printer control module and expose the jam.



#### Figure 5-35: Printer Control Module

2 Press the printer head release trigger on the left side of the printer and remove the paper. Note: In Encore S series units, the printer is installed in an inverted manner. Hence, the printer head release trigger is on the right side of the printer.

#### Figure 5-36: Printer Head Release Trigger



- **3** Tear paper at the paper feed and at the paper chute.
- **4** Gently pull the paper through the module, until it is completely removed. Leave no shards in the unit, especially in the printer chute. *Note: Rotate the gears to release the shards, if required.*
- **5** Lower the module back on the paper bucket and push the right blue pin in place.

#### Figure 5-37: Printer Module - Removal of Shards



## Clearing Paper Jams in USB Sliding Printer (M06972A001)



To clear a paper jam, proceed as follows:

1 Release the right blue pin by pulling it upward, and tip the printer control module forward to expose the jam.



#### Figure 5-38: Printer Control Module

**2** Press the printer head release trigger on the right side of the printer during the paper removal process.

**3** Gently pull the paper through the module until it is completely removed. Leave no shards of paper in the unit. Check the paper chute and ensure that it is clear. Lower the module back on the paper bucket and push the right blue pin in place. *Note: You can rotate the gears to release shards.* 

Figure 5-39: Use Gears to Remove Shards



4 Place the printer control module back and push the right blue pin back in place.

# **Special Maintenance Instructions**

The following are the special maintenance instructions to be followed:

## **Cleaning and Detailing Unit**

The following is a list of recommendations for cleaning dispensers:

- Special considerations
- Painted plastics and metals
- Graphics
- Display lenses
- Stainless steel sheathing
- Waxing the dispenser

## **Materials Required**

- Safety glasses
- Flexible rubber gloves
- Concentrated Simple Green all purpose cleaner
- Soft bristle nylon brush
- Spray bottle filled with water
- Empty spray bottle (to use with prepared cleaning mixture)
- White cotton cloths
- Nu Finish car polish
- Safety cones or barricades
- Cotton or paint-safe microfiber cloth or washing mitt
- Two large buckets (for the cleaning solution and rinsing debris)

#### Special Considerations

- Do not use fuels or acetone.
- Avoid citrus-based cleaners, household detergents, cleaners that contain sodium hydroxide, strong solvents, or acids.
- Do not use waxes, harsh abrasives, or cleaners that contain ammonia on the textured door surfaces as ammonia can damage plastics.
- Simple Green cleaner is the recommended cleaner for all surfaces. Avoid deicers as they may damage graphics.
- Do not spray the cleaner or rinse water onto or into the card reader, receipt printer, cash acceptor, or electronic display areas of the unit.
- Nu Finish is the recommended polish. Do not use any wax-based polishes. Do not apply the Nu Finish polish to electronic displays or nozzle boots.
- Avoid high pressure washers and constant direct spray from a water hose or high pressure water hoses on the dispenser doors/cabinet. Rinse water must be applied as a gentle spray.
- DEF is mildly corrosive with metals. Do not allow dried or wet DEF to remain on metallic parts on or near the dispenser for more than a day.

## **Routine Cleaning**

Perform the following routine cleaning weekly or as required:

- 1 Place safety cones or other devices to barricade the units being cleaned.
- 2 Wear safety glasses and flexible rubber gloves.
- **3** In the empty spray bottle, prepare a mixture of one (1) part Concentrated Simple Green cleaner to 10 parts water.

## CAUTION

Do not spray the cleaning mixture and water in or onto the card reader, receipt printer, cash acceptor, or electronic display area, as it may damage the equipment and will not be covered by warranty.

- 4 Spray the prepared cleaning mixture on the unit from bottom to the top. Streaking may occur if sprayed from the top down.
- 5 Scrub the unit with a soft bristle nylon brush in a circular motion from bottom to top. Scrub long enough to cause the cleaning solution to foam. For best results, two scrubbing cycles are recommended.
- 6 Rinse the unit thoroughly from the top to the bottom, ensuring that all the cleaner is removed. For best results, brush the unit when rinsing. Cleaner that dries on the unit will attract dirt.
- 7 Dry the unit with a clean white cloth.
- 8 Remove barricade(s) and cleaning supplies from the unit area.
### **Deep Cleaning and Detailing**

Perform the following deep cleaning and detailing as required - at least once a year. This helps restore the original color to the painted surfaces.

- 1 Perform steps 1 to 8 on page 5-36 of the routine cleaning procedure except, in step 3 on page 5-36, prepare a mixture of one (1) part Concentrated Simple Green cleaner to one (1) part water.
- 2 Using a new clean white cloth, apply the Nu Finish polish to the cloth and apply the polish to the painted or metal surfaces of the unit.

## **IMPORTANT INFORMATION**

• Do not apply the Nu Finish polish to textured surfaces.

• Do not apply the Nu Finish polish to electronic displays or nozzle boots.

- **3** Wipe surface of the unit with a clean white cloth.
- **4** Remove barricade(s) and cleaning supplies from the unit area.

## **Painted Plastics and Metals**

Gilbarco has tested and recommends the following products for cleaning painted plastics and metals:

- Simple Green All Purpose Cleaner
- CAF OTIS Super Concentrate Multi-surface Cleaner
- Windex<sup>®</sup> Ammonia-free
- Dawn<sup>®</sup> Ultra Platinum Dishwashing Liquid
- Simoniz® Tru Blue Liquid Cleaner

The following cleaning products specifically designed for automotive (car washes) use are also recommended:

- Armor  $All^{\mathbb{R}}$
- Duragloss®
- Mothers®
- Meguiars®
- Turtle Wax®

## Graphics

For regular cleaning of graphics, use the cleaners for "Painted Plastics and Metals".

*Note:* For difficult-to-remove ground-in dirt, apply Nu Finish polish to the soft bristle nylon brush and rub the surface.

## **Display Lenses**

To clean display lenses, proceed as follows:

- 1 Wash display lenses with a mild cleaner (such as Simple Green, Windex ammonia-free, or Simoniz TruBlue) and lukewarm water using a clean sponge or a soft cloth.
- 2 Rinse well with clean water (avoid high pressure washers or high pressure water hoses).
- 3 Dry thoroughly with a chamois or moist cellulose sponge to prevent water spots.

*Note:* Do not scrub or use brushes on these products; their coating is UV-resistant, not mar-resistant.

## **Stainless Steel Sheathing**

- For regular cleaning of stainless steel sheathing, use the cleaners referred in "Painted Plastics and Metals" on page 5-37.
- For hard to remove stains and slight rust, use Bar Keepers Friend®.

## Waxing Dispenser

Gilbarco recommends the following for waxing dispensers:

- Wash with Simple Green and then wax with Nu Finish Car Polish.
- Apply a good quality car wax for protection. The latest synthetic polymer-based waxes (such as Meguiar's Ultimate Wax, Mothers California Gold® Synthetic Wax, and Turtle Wax ICE® Liquid Polish) provide long lasting protection.

*Note: Avoid waxes on the lens, grade selection buttons, and nozzle boots as irregular application may cause poor appearance.* 

# Glossary

## Α

#### **Allocation Volume**

The maximum amount of product the unit will dispense, if programmed.

#### **Alternative Fuels**

Any fuel other than straight gasoline, diesel fuel, or kerosene. Alternative fuels containing ethanol such as E85, methanol, MTBE, biodiesel, and other potential significant additives.

#### **Authorized Service Contractor (ASC)**

A Gilbarco-trained and authorized service contractor.

### В

**Bellows** Refer to "Vapor Recovery Boots" on Glossary-6.

#### **Boot Area**

The part of the unit where the nozzle is stored.

#### Breakaway

Device attached to the hoses on pump/dispensers that detaches if a customer drives off with the nozzle still attached to the cars; the device protects against gasoline being spilled and a resulting fire, and it minimizes damage to the pump/dispensers in the event of a drive off and stops fuel flow through the separated hose.

### С

#### CIM

Customer Interface Module; the portion of the electronics through which the dispenser interfaces with the customer (for example, displays and card readers).

#### **CIM Door**

(Customer Interface Module) Door on the unit that provides access to the manager keypad and some electrical components of the unit.

#### Command Code (CC)

Two-digit number used in programming the unit; this code indicates which setting to configure.

#### **Component Inspections**

Periodic inspections of various unit components performed by the station manager; the station manager must look for signs of damage and wear for each component.

Note: For a list of components and the recommended frequency of inspection, refer to "Component Inspections" on page 5-3.

#### Console

A system (such as the G-SITE® system) that is located inside the store and controls unit operation.

#### **Console Mode**

Refer to "Two-wire Mode" on Glossary-6.

#### Couplings

Plumbing used to join pipes or hoses together; refer to "Breakaway" on Glossary-1.

#### Cradle

Refer to "Boot Area" on Glossary-1.

#### **CRIND (Card Reader in Dispenser) Device**

A device that reads the magnetic code on a debit or credit card; located inside the unit.

#### **Customer Specified Contractor (CSC)**

Contractor selected by customer.

#### D

#### **Date Code**

Two-letter code that is stamped on the Encore/Eclipse unit before the serial number; shows the month and year of manufacture.

#### DEF

It is a clear, colorless, non-toxic, non-flammable, non-combustible liquid. It is made up of 32.5% urea with the balance distilled or deionized water. Urea and water are completely miscible and do not separate in storage. DEF is mildly corrosive.

#### Dispenser

A device that uses an STP in the storage tank to move fuel from the storage tank.

#### **Display**, Main

Refer to "Main Display" on Glossary-4.

#### **Displaying Last Transaction (DLT)**

After a power failure, procedure for displaying the last transaction at a unit that occurred before the unit lost power; automatic with the LCD main display.

#### **Drive Offs**

Situations where customers forget to remove the nozzles from the tanks in their cars and drive away from the unit; the hose detaches from the unit at the breakaway.

### Ε

#### Ethernet

A local area network technology that provides communication between the unit and the pump controller.

#### **Error Codes**

Codes that appear on the main display when an error occurs; these codes are useful to ASCs in diagnosing any problems with the unit.

### F

#### Function Code (FC)

When programming a unit, a two-digit number used to indicate which setting to configure.

### G

#### **General Inspections**

Weekly inspections of all of units on the site performed by the station manager; the station manager must ensure that all units are operating properly, that no warning labels are missing, and that there is no evidence of damage or sharp edges.

#### Grade

Level of fuel, such as unleaded or premium.

#### **Graphite Lubricant**

Type of lubricant used on the door locks of units.

### Η

#### **Hose Outlet Castings**

Fuel discharge port on the unit where the hose is attached to the unit.

#### **Hose Retriever**

Device (option) at the unit that retracts and pulls the hose close to the unit after the customer has completed fueling.

#### **Hydraulic Connections**

Any fuel-handling hardware where castings, hoses, and pipes are joined through threads, O-rings, or other seals.

### I

#### IFSF

International Forecourt Standards Forum; forum of international oil companies with the common objective of harmonizing equipment inter connectivity and communication standards for use in the petroleum retail business

#### Inspections

Refer to "Component Inspections" on Glossary-1 and "General Inspections".

### J

#### Junction Box (J-box)

The explosion-proof box on the unit that contains the main electrical connections between the unit and the main power and data source.

### L

### LCD

The alphanumeric display on the main display.

#### Lock Oil

Type of lubricant used on the door locks of units.

#### LON

Local Operating Network.

#### Μ

#### **Main Display**

Light Emitting Diode (LED) display on the front of the unit that shows various information about the unit, such as the following:

- Programming options
- Selected grade and price for the current transaction

#### Manager Keypad

An input device consisting of a separate grid of numerical and function keys arranged for efficient data entry; located behind the locked CIM door on the unit.

#### Meter

Device in the unit that measures fuel flow.

#### Major Oil Company (MOC) CRIND Device

System that uses a single data loop to communication through the G-SITE system to both CRIND devices and the unit.

#### **Mode of Operation**

Refer to "Operation Mode" on Glossary-5.

### Ν

#### National Fire Protection Association (NFPA)

An international nonprofit organization dedicated to protecting lives and property from the hazards of fire; publishes 280 recognized codes and standards, including the *National Electrical Code*.

#### Nozzle

On the unit, the projecting part at the end of the hose that regulates and directs the flow of fuel.

#### **Nozzle Hook**

In the boot area on the unit; place upon which the nozzle rests when the unit is not in use.

### 0

#### **Occupational Safety and Hazard Administration (OSHA)**

U.S. agency that develops and enforces regulations for the safety and health of workers engaged in interstate commerce.

#### **Operation Mode**

Configuration of the unit that determines whether authorization and payout occurs at the console (two-wire mode) or at the unit (standalone mode).

#### **Oven Door**

Oven door on the unit that provides access to the manager keypad and some electrical components of the unit.

### Ρ

#### Personal Identification Number (PIN)

Password used by the station manager to program the unit; different PINS are used for different levels of programming.

#### Price per Unit (PPU)

The price of each unit of gasoline dispensed.

#### **Programmable Pump Preset (PPP)**

Feature that allows customers or attendants to preset the dollar or volume amount of a transaction before fueling.

#### **Programming Commands**

Programming commands used to configure settings on the unit; most commonly configured on site by the station owner or operator

#### Pump

A device that uses a self-contained pumping unit and motor to move fuel from the storage tank.

#### **Pump Controller**

Refer to "Console" on Glossary-2.

#### **Pump Pulleys**

Ordinary pulley wheels used on self-contained suction pumps and motors.

### S

#### Seals

Substances used to prevent seepage of gasoline or vapor from the unit.

#### **Serial Plate**

Mounted on side 1 of Encore units; mounted on left column of Eclipse units.

#### **Shear Valves**

Device at the base of all dispensers and some pumps that shuts off the fuel flow in case of a vehicle impact or fire at the base of the unit.

#### **Silicone Grease**

Type of lubricant used on the nozzle hooks and shafts of units.

#### **Standalone Mode**

Authorization and payout occur at the pump.

#### Submersible Turbine Pump (STP)

Submersible turbine pump in underground storage tank (UST).

#### Swivels

A fastening that permits the free turning of attached parts to the unit.

### Т

#### **Two-wire Mode**

A communication mode with the unit where authorization and payout occur at the console.

### V

#### Vapor Hoses

Multi-wall hoses that reduces the amount of fuel vapor that escapes into the atmosphere when a customer is dispensing fuel.

#### **Vapor Recovery**

Process of capturing emissions and returning them to an underground storage tank, reducing the amount of volatile organic compounds emitted into the atmosphere.

#### Vapor Recovery Boots

Device inside the nozzle that reduces the amount of fuel vapor that escapes into the atmosphere when a customer is dispensing fuel.

# Index

### A

Acronym table 1-2 ADA Requirements 3-5 Advertising Panel 3-6

## В

barrier 3-3 Blender Dispenser 3-8 Blender Pump 3-8 Branding 3-6 broken cables 5-6 Bulges 5-5

## С

canopy 3-2 car washes 5-33 catalytic converters 4-2 Changing the Printer Receipt Paper 5-14 Cleaning 5-32 Cleaning and Detailing 5-33 Cleaning Cards Printer (Q13400) 5-28 Codes Error 4-9 Command Code 1-2 Component inspections 5-3 Console mode 3-13 See Two-wire mode. contaminate 4-1 corrode 4-1 Couplings 5-7 Customer Interface Module 1-2

## D

Date code 3-9 Diesel Exhaust Fluid 1-2 display lenses 5-34 DLT 3-9

## Ε

E85 Units 4-4 Important Requirements 4-4 electrical shock 5-6 Emergency In Case Of 2-3 Error Codes 4-9 Error codes 4-9 Clearing 4-9 Recording 4-9 explosion 5-6

## F

Flattened spots 5-5 Flexible Fuel 1-2 fuel staining 5-7

## G

General inspections 5-2 Glossary 1-1

## Н

Hinge sensors 4-7 hydraulics cabinet 5-7

## I

Inspections Component 5-3 General 5-2 Installing Printer Paper 5-15, 5-18

L

Liquid Crystal Display 1-2

### Μ

magnetic backing 3-10 Maintaining the units 1-1 Maintenance Safety warnings 5-2 Major Oil Company 1-2 Mode Standalone 3-13 Two-wire 3-13 Model code 3-9

## 0

Operating pumps/dispensers 3-13 Operating the units 1-1 Operation Standalone mode 3-13 Two-wire mode 3-13 outlet casting 5-6

## Ρ

painted plastics and metals 5-33 Parts Replacing 4-9 Performing General and Component Maintenance Inspections 5-2 Printer Cleaning Card (Q13400) 5-28 Printer Paper Ordering Information 5-14 Printer Paper, Installing 5-15, 5-18 pumps/dispensers 1-1

## Q

Q13400 Printer Cleaning Card 5-28

## R

Receipt Paper, Installing 5-15, 5-18 Reinforcement 5-5 Replacement parts 4-9 retrievers 5-6

## S

Safety Maintenance 5-2 Serial Plate 3-6 Service Preparing for 4-1 Warranty 4-5 Servicing the Pumps/Dispensers 4-1 Shear Valve 3-2 SMART Meter 3-2 Soft spots 5-5 splash guards 5-6 spouts 5-6 stainless steel sheathing 5-34 Standalone mode 3-13 standalone mode 3-10 Station Security 4-5 Swivels 5-7

## Т

Transaction Displaying last 3-9 Tuxedo Stripe 3-6 Two-wire mode 3-13

## U

Underground 3-4 Unions 3-2 Unit Commissioning 4-9 Units 1-1 Universal Serial Bus 1-2 Urea Tank 3-4

### V

Vapor Recovery 1-2

### W

Warranty service 4-5 waxing dispensers 5-34

*CRIND*<sup>®</sup>, *Eclipse*<sup>®</sup>, *Encore*<sup>®</sup>, and *Gilbarco*<sup>®</sup> are registered trademarks of Gilbarco Inc. GOLD<sup>SM</sup> is service mark of Gilbarco Inc.

All product names, logos, and brands are the property of their respective owners and are for identification purposes only. Use of these names, logos, and brands does not imply endorsement.



© 2024 Gilbarco Inc. 7300 West Friendly Avenue · Post Office Box 22087 Greensboro, North Carolina 27410 Phone (336) 547-5000 · http://www.gilbarco.com · Printed in the U.S.A. MDE-3893T Encore® and Eclipse® Series Owner's Manual · July 2024